


Operating Instructions

Sartorius Combics 3

Models CISL3 | CIS3

Indicators



Intended Use

Combics 3 is a precise and rugged indicator that produces reliable weighing results for the demanding tasks of daily quality control. The indicator has a stainless steel housing and is easy to operate. Additional features include:

- Large keys with positive click action
- Numeric and alphabetic input
- Large, backlit, fully graphical dot-matrix display
- Plain-text user guidance
- Connectivity for two weighing platforms
- Automatic initialization when the Combics is switched on
- Automatic taring when a load is placed on the weighing platform
- Optional control through an external computer

Advantages in routine weighing tasks:

- Fast response times
- Independence from location of platform installation
- Designation of weight values with up to 4 lines of alphanumeric text
- Range of interfaces for flexible use
- Security through password protection
- Easy to clean and disinfect

Symbols

The following symbols are used in these instructions:

- denotes general operating instructions
- indicates instructions for exceptional cases
- > describes the outcome of an operating step
- ⚠ indicates a hazard

Hotline:

For advice on the use of these applications, just call or fax your local Sartorius office. For the address, please visit our Internet website at: www.sartorius.com

Contents

2	Intended Use	60	Service
3	Contents	60	Activating the Service Mode
4	Warnings and Safety Precautions	61	Configuring the Analog/Digital Converter
5	Getting Started	64	Service Menu
5	Equipment Supplied	75	Geographical Data
5	Installation Instructions	81	Calibration/Adjustment, Linearization, Preload
6	General View of the Equipment	97	Error Codes
8	Connecting the Combits to AC Power	98	Care and Maintenance
9	Connecting the External Rechargeable Battery Pack	98	Repairs
9	Connecting a Bar Code Scanner	98	Cleaning
9	Installing the Verification Adapter for Use in Legal Metrology	98	Safety Inspection
10	Operating Design	98	Recycling
10	Data Input	99	Overview
12	Display	99	Specifications
14	Configuration	100	Dimensions (Scale Drawings)
14	Setting the Language	101	Accessories
15	Navigating in the Operating Menu	104	Declarations of Conformity
16	Defining Password Protection for the Operating Menu	106	EC Type-approval Certificate
17	Printing the Parameter Settings	108	Plates and Markings
18	Operating Menu Overview (Parameters)		Appendix
28	Operation		General Password
28	Weighing $\Delta\Delta$		Guide to Verification (on CD-ROM)
29	Device Parameters		
30	Tare Function in Weighing		
31	Numeric Input for Weighing		
33	Weighing with Variable Tare Values		
35	Data ID Codes		
38	Calibration and Adjustment		
41	Data Output Functions		
43	Interface Port		
45	Generating SBI Data Output		
46	Configuring Printouts		
48	Sample Printouts		
51	Data Output Format		
52	External Keyboard Functions (PC Keyboard)		
53	Data Input Format		
54	Pin Assignment Chart		
58	Cabling Diagram		

Warnings and Safety Precautions

Safety Information

- To prevent damage to the equipment, read these operating instructions carefully before using your Combics.
- ⚠ Do not use this equipment in hazardous areas/locations.
- ⚠ The indicator may be opened only by trained service technicians.
- ⚠ Disconnect the indicator from power before connecting or disconnecting peripheral devices.
- ⚠ If you operate the equipment under ambient conditions subject to higher safety standards, you must comply with the applicable installation regulations.

Installation

- Proceed with extreme caution when using pre-wired RS-232 connecting cables, as the pin assignments may not be compatible with Sartorius equipment. Check all pin assignments against the cabling diagrams and disconnect any lines that are not assigned. The operator shall be solely responsible for any damage or injuries that occur when using cables not supplied by Sartorius.
- ⚠ Use only standard cables that have protective grounding conductors. The protective conductor must not be disconnected for any reason.
- ⚠ If there is visible damage to the equipment or power cord, unplug the equipment and make sure it cannot be used for the time being.
- Connect only Sartorius accessories and options, as these are optimally designed for use with your Combics. The operator shall be solely responsible for installation and testing of any modifications to Sartorius equipment, including connection of cables or equipment not supplied by Sartorius. Contact Sartorius for detailed operating specifications in accordance with the Standards for immunity to interference.
- If you have any problems with your Combics, contact your local Sartorius office, dealer or service center.

IP Protection

- CISL models are rated to IP44 (with Option L1: IP65); CIS models are rated to IP67.
- The IP65/IP67 protection rating is ensured only if the rubber gasket is installed and all connections are fastened securely (including the caps on unused sockets). Weighing platforms must be installed and tested by a certified technician.
- If you install an interface port after setting up your indicator, keep the protective cap in a safe place for future use. The cap protects the interface connector from vapors, moisture and dust or dirt.

Using the Equipment in Legal Metrology

- When the indicator is connected to a weighing platform and this equipment is to be verified, make sure to observe the applicable regulations regarding verification. Please read and observe the “Guide to Verification” on the enclosed CD. When connecting a Sartorius weighing platform, observe the permitted weighing range as listed in the Declaration of Conformity.
- If any of the verification seals are damaged, make sure to observe the regulations and standards applicable in your country in such cases. In some countries, the equipment must be re-verified.

Getting Started

Unpacking the Combics

- After unpacking the equipment, please check it immediately for any external damage.
- If you detect any damage, proceed as directed in the chapter entitled “Care and Maintenance,” under “Safety Inspection.”
- Save the box and all parts of the packaging for any future transport. Unplug all connected cables before packing the equipment.

Equipment Supplied

- Indicator
- Operating instructions (this manual)
- Special accessories as listed on the bill of delivery, if ordered

Installation Instructions

- 1) Connecting a weighing platform to the Combics indicator: see the page after next.
- 2) Configuring the A/D converter: see the chapter entitled “Service” to configure the following:
 - Trade | Standard
 - Weighing capacity, readability
 - Calibration weight
 - mV/V | Geographical data
 - Linearization, calibration/adjustment
- 3) Adjusting the weighing platform: see “Calibration and Adjustment” in the chapter entitled “Operation.”
- 4) Configuring application programs: see the enclosed “Basic Application Programs” manual.
- 5) Connecting an interface, printer or Alibi memory:
Model CISL: use the 25-pin connector
Model CIS: see page 57.
- 6) Activating the interface, printer or Alibi memory in the operating menu:
 - Configure the following for COM1/2 or UniCOM:
 - Printout format
 - Printed lines/areas for the particular printer

Installation

Choose a location that is not subject to the following negative influences:

- Heat (heater or direct sunlight)
- Drafts from open windows and doors
- Extreme vibrations during weighing
- Excessive moisture

NOTE: This equipment has been tested and found to comply with the limits pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications.

For information on the specific limits and class of this equipment, please refer to the Declaration of Conformity. Depending on the particular class, you are either required or requested to correct the interference.

If you have a Class A digital device, you need to comply with the FCC statement as follows: “Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.”

If you have a Class B digital device, please read and follow the FCC information given below:
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Before you operate this equipment, check which FCC class (Class A or Class B) it has according to the Declaration of Conformity included. Be sure to observe the information of this Declaration.

Conditioning the Indicator

Condensation can form on the surfaces of a cold indicator when it is brought into a substantially warmer area. You can prevent this by conditioning the indicator for about 2 hours at room temperature, leaving it unplugged from AC power.

Indicator not In Use

Switch off the equipment when not in use.


Seal on Indicators Verified for Use in Legal Metrology in the EU*

A sticker with the “Sartorius” logo was affixed to the indicator as a control seal following verification. This seal will be irreparably damaged if you attempt to remove it, in which case verification will become null and void and the indicator will have to be re-verified.

* including the Signatories of the Agreement on the European Economic Area

General View of the Equipment


Display and Keypad: Combics 3



Display and Keypad

- 1 LEDs (for checkweighing and classification)
- 2 Toggle to alphabetical input
- 3 Alphanumeric keypad
- 4 CF key (clear function)
- 5 Settings: Access Setup program
- 6 Toggle to the application program | application-specific information
- 7 Data output key
- 8 Gross/net; 2nd unit or 10x higher resolution (depending on the settings)
- 9 Tare key
- 10 Zero key
- 11 Toggle to different weighing platform
- 12 On/off key
- 13 Function keys
- 14 Graphic-capable dot-matrix display


Rear view: CISL models



Rear View

- 15 COM1: RS-232C interface
- 16 Power cord with country-specific plug
- 17 Menu access switch (standard operating mode or legal metrology mode)
- 18 Connector for weighing platform
- 19 Vent valve; torque: 1.5 Nm
- 20 COM2 | UniCOM interface


Rear view: CIS models




Installing the Weighing Platform

The connecting cable should be installed by a trained, certified Sartorius technician.


- ⚠ Installation work that affects the IP67 protection rating must be performed with extreme care.
- ⚠ Any installation work that does not conform to the instructions in this manual will result in forfeiture of all claims under the manufacturer's warranty.
- ⚠ Make sure the equipment is disconnected from power before performing any installation, maintenance or repair work.
- ⚠ An IP67-protected cable gland is installed on the indicator at the factory.




- To open the indicator, remove the four screws from the front panel and remove the panel.



- Use the connecting cable from the weighing platform to connect the indicator.
- ⚠ The cable gland is installed at the factory. Please use extreme caution when performing any work on the equipment that affects this cable gland. Use a torque wrench and tighten the cable gland to 5 Nm.



- Prepare and install the cable as follows:
 - Route the cable through the cable gland.
 - Close and tighten the cable gland in accordance with the applicable regulations.
 - Remove the insulation from a section of the cable end. The shielding (1) must have contact with the clamps (2).
- Expose approx. 15 cm (6 inches) of the individually isolated wires (3) for installation.
- Route the cable through the cable gland.
- Make sure the shield is in contact with the clamps.



- Connect the cable to the weighing platform as follows:
 - Expose approximately 5 cm (2 inches) of the isolated wires for installation.
 - Remove the casing from approximately 1 cm (1/2 inch) of the wires and attach ferrules to the wire ends.
 - Fit the ferrite ring over wires 3 and 4.
 - Attach the wires securely to the screw terminals.


Pin Assignments:

No.	Signal name	Meaning
1	BR_POS	Bridge supply voltage (+)
2	SENSE_POS	Sense (+)
3	OUT_POS	Measuring voltage positive
4	OUT_NEG	Measuring voltage negative
5	SENSE_NEG	Sense (-)
6	BR_NEG	Bridge supply voltage (-)

- △ Refer to the data sheet or operating instructions for the weighing platform for details on the assignment of wire colors to signals. Isolate any lines that are not used.

Weighing platforms with 4-conductor technology:

- △ When connecting a load receptor that uses 4-conductor technology, connect wire 1 (BR_POS) to wire 2 (SENSE_POS) and wire 6 (BR_NEG) to wire 5 (SENSE_NEG).



Connecting the Combiics to AC Power


- Check the voltage rating and the plug design.
- The indicator has a built-in power supply which can be operated with a supply voltage of 100 V to 240 V. The power connection must be made in accordance with the regulations applicable in your country.
- To power a device of protection class 1, make sure the electrical outlet (mains supply) is properly installed with a protective grounding conductor (protective earth, PE).

Safety Precautions

If the electrical outlet does not have a protective grounding conductor, have a certified electrician install equivalent protection. The protective conductor must not be disconnected at any time.

Connecting Electronic Peripheral Devices

- Make absolutely sure to unplug the indicator from AC power before you connect or disconnect a peripheral device (printer, PC, etc.).




Warmup Time

To ensure accurate results, the indicator must warm up for 30 minutes before operation. Only after this time will the indicator have reached the required operating temperature.


- Using Equipment Verified as Legal Measuring Instruments in the EU*
- Allow the equipment to warm up for at least 24 hours after initial connection to AC power.

* including the Signatories of the Agreement on the European Economic Area



Installing the Verification Adapter for Use in Legal Metrology (on verifiable models only)

- Remove the nut located on the back of the indicator.
- Use the slotted screw to install the adapter plate.



- Affix the control seal over the adapter plate.


Connecting the External Rechargeable Battery Pack (Accessory; Order No. YRB10Z)

⚠ Disconnect the equipment from power.

- Installation:
CISL3 models: Connect a 25-pin D-Sub male connector (connecting cable YCC02-RB01) to the COM2 port
CIS3 models: Please see “Pin Assignment Charts” in this manual, page 54 (implemented via the YCC02-RB02 connecting cable or as Option L2).

Hours of operation: up to 40, depending on the weighing platform connected; without options. The Combics automatically switches to battery operation in the event of a power outage. Once the mains supply is restored, the Combics automatically switches back to normal operation.

Battery Symbol

Battery fully charged: 

Battery drained: 

Connecting a Bar Code Scanner (Accessory; Order No. YBR02CISL)

⚠ Disconnect the equipment from power.


- Installation:
CISL3 models: Connect a 25-pin D-Sub male connector to the COM2 interface. To connect both a bar code scanner and an external rechargeable battery, please use the YTC01T-connector.

CIS3 models: Please see “Pin Assignment Charts” in this manual, page 54 (implemented via the YCC02-BR02 connecting cable or as Option M8).

Operating Design

You can use the Combics 3 to collect weight values from two weighing platforms, calculate and display weight values through application programs, and assign IDs to the samples weighed.

Configure the indicator Setup menu for the desired application program first (printer settings, etc.). Then you can begin weighing.



Operating Elements: Combics 3

Data Input

Keypad Input

Labeled Keys


Some keys have a second function, activated by pressing and holding the key for at least 2 seconds. Whether a function is available depends on the indicator operating state and Setup menu settings.

- On/off (in standby mode, OFF is displayed.)
- When two platforms are connected, this key toggles the display between the two readouts.
- Zero the scale
 - Cancel calibration/adjustment
- Press briefly: Tare the weighing platform.
 - Press and hold (> 2 sec.): Activate calibration/adjustment
- Toggle between 1st and 2nd weight unit, or gross and net values, or normal and 10-fold higher resolution, depending on operating menu settings.

- Press briefly: Print
 - Press and hold: Print GMP footer
- Press and hold: Toggle to info mode
- Access to Setup program
 - Exit the Setup program
- Press briefly: Quit application program or delete input character
 - Press and hold: Delete entire input string
- Enter numbers, letters and other characters
- Toggle between numeric and alphabetic input

Soft Keys

The functions of active soft keys are indicated by symbols and abbreviations in the last line on the display:



Abbreviations in this example:

1st ID: Store the first ID line

ESC: Cancel input

Symbols used for soft key functions:

- ◀: Return to initial state
- ⏮: Next higher menu level
- : Show items under selected entry
- ⬆: Move up one position in I/O window
- ⬇: Move down one position in I/O window
- ⏵: Confirm selected parameter setting

Numeric Input Through the Keypad

- Enter numbers one digit at a time:
Press **[0]**, **[1]**, **[2]** ... **[9]** as needed
- Store input:
Press the required key (e.g., press **[T+]** to store manual tare input)
- Deleting a digit:
Press **[CF]** briefly
- Deleting entire input string:
Press and hold **[CF]** (> 2 sec.)

Text Input Through the Keypad

- Press the **[ABC]** key
 - > "ABC" is displayed
- Press the key on which the desired letter is printed repeatedly, until that letter is displayed.
 - If the next character is on the same key, press the **↓** soft key or wait 2 seconds before entering it.
- Entering a space: Press the **[0]** key
- Entering punctuation or special characters:
Press the **[1]** or **[.]** key repeatedly until the desired character is displayed, then press the **↓** soft key to insert it.
- Deleting characters:
Press **[CF]** briefly
- Deleting entire input string:
Press and hold **[CF]** (> 2 sec.)
- Return to numeric input mode:
Press the **[ABC]** key
- > 123 is displayed
- Store input:
Press the required soft key (for example, **1st ID**)

Input Through the Weighing Platform

You can store the weight on the weighing platform; for example, as a tare weight (press the **[T+]** key)

Input Through the Digital I/O Port

You can connect a remote hand switch or foot switch to the input control line, for use with all application programs. Assign one of the following functions to this switch in the Setup menu, under **Device parameters - Control input:**

- Print key
- Print key -> 2 sec
- Tare key
- Tare key -> 2 sec
- Fn key
- WP toggle key
- Combined zero/tare function

Input Through the COM Port

See page 53, "Data Input Format."

Input Through a Bar Code Scanner or External Keyboard


Input is analogous to indicator keyboard input:

- Weight values for tare memory
- Reference weight values for the Counting, Neutral Measurement and Weighing in Percent applications
- Numeric values
- Product identifiers

Select a menu item under **Device parameters - Bar code** to define how scanned data is handled. The menu items available are explained in the following:

Select **Reference**, **Tare** or **ID1** to save the scanned value as a reference, tare or ID value. The bar code itself may designate the value type. Select **Input without activating a function** to have the value displayed only.

Display Modes



There are two display modes: one is used during weighing and the other when working with the operating menu (Setup program).

Display Mode During Weighing (Main Display)

This display is subdivided into nine sections.

Lines for metrological data:

These lines show:

WP 1 / 2	Active weighing platform
R 1 / 2	Current weighing range of the active weighing platform (with multiple range scale connected)
Max	Upper limit of the weighing range in the active weighing platform
Min	Lower limit of the weighing range in the active weighing platform (verified models only)
e	Verification scale interval of the active weighing platform (verified models only)
d	Scale interval d of the active weighing platform

Application, printing and battery symbols:

The application symbol indicates the selected program; e.g.,
⏏ for the Counting application.
🖨 Printing mode active
🖨 GMP printing mode active

The battery symbol 🔋 indicates the charge level of the external rechargeable battery.

Bar Graph

The bar graph shows the percentage of the weighing platform's capacity that is "used up" by the load on the scale (gross value).

0%	Lower limit
100%	Upper limit

The following symbols indicate tolerance levels for Checkweighing:

▬▬▬▬▬▬▬▬▬▬	Bar graph with 10% markings
▬▬▬▬▬▬▬▬▬▬	Minimum in Checkweighing
▬▬▬▬▬▬▬▬▬▬	Target in Checkweighing
▬▬▬▬▬▬▬▬▬▬	Maximum in Checkweighing

Plus/minus sign:

+ or - for weight or calculated values;
○ when the weighing platform is zeroed or tared.

Measured value/result line:

This field shows weight values, calculated values and input characters.

Unit and stability:

When the weighing system reaches stability, the weight unit or calculation unit is displayed here.

Tare in memory, calculated values:

The following symbols may be displayed here:

⚖	Calculated value (cannot be used in legal metrology)
NET	Net value (gross weight minus tare)
B / G	Gross value (net value plus tare)

Text lines:


These lines show value IDs and user guidance texts.

Soft key labels:

Shows abbreviations or symbols indicating soft key functions.

Display Mode for Configuration and Information (Setup)

This display is divided into three sections.



Status line:

Indicates the function of the current screen page. In the Setup program, this line shows the "path" to the data displayed.


Input and output window:

For input and display of detailed information; e.g., for the selected application. Selected items are displayed inversely (white letters on a black background).

Soft key labels:

See the description on page 10.

Example: Display in “Setup” mode



◻ marks the current menu setting

Setting parameters:

- Press **>** or **<** to select a setting
- Press **>>** to confirm a parameter setting
- Press **SETUP** to exit the Setup menu

Error Codes

- If a key is inactive, “-----” and/or “No function” is displayed (2 sec.) and an acoustic signal (double-beep) is emitted
- Temporary errors are displayed for 2 seconds in the measured value/result line (e.g., **INF 09**); fatal errors are displayed steadily (e.g., **ERR 101**) until the Combics is reset (switched off and then on again).

Error codes are described in detail under “Error Codes” on page 97.

Data Output

Printer

You can connect two strip or label printers to the Combics. You can have printouts output at the press of a key or automatically. Printout formats are user-definable. You can also configure separate summarized printouts, and print lists of the active menu settings. See “Printing,” page 46, for details.

Digital Input/Output Interface

The digital I/O interface is supported by the Checkweighing and Classification applications.

Checkweighing

The output device has a number of control functions. Four data outputs transfer signals for “less than,” “equal to,” “greater” and “set.” You can define whether the outputs are always active or are activated only at stability, only within the checkweighing range, only within the checkweighing range at stability, or switched off.

Classification

Four data outputs transfer signals indicating which class the load is in (1, 2, 3, 4 or 5) and whether the minimum load is exceeded (Set). You can define whether the outputs are always active, activated only at stability, or off. See “Classification” in the enclosed “Basic Application Programs” manual for details.

COM Port

You can define a number of parameters for this SBI interface (print command, time-dependent autoprint, ID codes). See “Interface Port,” page 45, for details.

LEDs

For the Checkweighing application, the LEDs show whether the weight exceeds tolerance limits. For the Classification application, they show how the weight value is classified.

Saving Data

Application parameters (such as reference values) are saved when you change application programs or switch off the Combics 3. You can assign a password to prevent unauthorized users from changing settings in the “Device parameters” menu (in the Setup program under **Device parameters - Password**). See also page 16.

Configuration

You can configure the Combics 3 indicator by selecting operating parameters in the Setup menu. The parameters are divided into the following groups (highest menu level):

- Application parameters
- Fn key function
- Device parameters
- Device-specific information (Info)
- Language

When used in legal metrology, not all parameters can be accessed.

The factory-set configurations are identified by an “o” in the list starting on the next page.

Setting the Language

You can choose from five languages for the display of information :

- German
- English (factory setting)
- English with U.S. date/time format
- French
- Italian
- Spanish


Example: Selecting “U.S. Mode” for the Language



Switch on the Combics



Activate the Setup program




Soft key repeatedly,

Select “Language”

Soft key

and confirm




Soft key ,

Select “U.S. Mode”

Soft key

Save the new setting



Soft key

Exit the Setup menu

Navigating in the Operating Menu (Examples)

Example: Adapting the Combics to “Very unstable conditions” (menu item: “Extreme vibration”) for weighing platform WP1.



Switch on the Combics



Activate the Setup program

SETUP				
Application parameters				
Fn key function				
Device parameters				
Info				
Language				
<<			v	>

Soft key v,
Soft key >

Select **Device parameters**
and confirm

SETUP DEVICE				
WP 1				
COM 1				
COM 2				
UniCOM				
Control input				
Bar code				
Config. printout				
Operating parameters				
Clock				
Password				
<<	<		v	>

Soft key >,
Soft key >

Confirm weighing platform **WP-1** and then
confirm **Internal**

DEVICE WP 1 INTERNAL				
Calibration/adjustment				
Adapt filter				
Application filter				
Stability range				
Stability delay				
Taring				
Autozero				
Weight unit 1				
Display accuracy 1				
Zero range				
<<	<		v	>

Soft key v,
Soft key >

Select **Adapt filter**
and confirm

WP 1 INTERNAL ADAPT FILT				
Min. vibration				
Normal vibration				
Strong vibration				
Extreme vibration				
<<	<	^	v	↓

2x soft key v,
Soft key ↓

Select **Extreme vibration**
and save

WP 1 INTERNAL ADAPT FILT				
Min. vibration				
Normal vibration				
Strong vibration				
Extreme vibration				
<<	<	^		↓

To continue: soft key <
Soft key < <

Change other menu settings if desired, or
Exit the Setup menu

Defining password protection for the menu: entering, changing or deleting a password

Example: Entering, changing or deleting “ABC1” as password



Switch on the Combics




Activate the Setup program




2x soft key ∇ ,
Soft key \triangleright

Select **Device parameters**
and confirm




Soft key ∇ repeatedly,
Soft key \triangleright

Select **Password**
and confirm



ABC, **2** (ABC), Soft key ∇ ;
2x **2** (ABC), Soft key ∇ ;
3x **2** (ABC), Soft key ∇ ;
ABC, **1**, Soft key ∇

Enter password: “ABC1” (max. 8 characters)
Confirm input (wait 2 seconds or press ∇ soft key)
Confirm password



To delete the password:
Press **CF** and confirm with soft key ∇

To continue: soft key \triangleleft
Soft key \triangleleft

Change other menu settings if desired, or
Exit the Setup menu

Printing Parameter Settings

Example: Maximum 20 characters per line.

```
-----
12.01.200      09:46
Typ            CIS3
Ser.no        12345678
Vers.         1.0103.11.2
BVers.        01-26-02
-----
SETUP
      DEVICE
-----
WP-1
  Internal
  COM1
    Data communications
    SBI
      Baud rate
        1200 baud
      Parity
        Odd
      Number of stop b
        1 stop bi
      Handshake mode
      Hardware 1 charact
      Number of data b
        7 bit
    Data output
  Printout, printer 1

    Line format
  For other apps. (22
  characters)
  COM2
    Off
  UniCOM
    Off
  Control input
    Print key
  Bar code
    Reference val
  Printout
  Headers
    Line 1:

    Line 2:

  ID Codes
  ID1:
    123
  ID2:
    456
  ID3:
    ID3
  ID4:
    ID4
  ISO/GLP/GMP
    Off
  Date/Time
    Date with time
    Once at stability
    Off
```


etc.

Operating Menu Overview (Parameters)

o = Factory setting

√ = User-defined setting

Setup



¹⁾ = function will be made available in future

²⁾ = not available on equipment verified for use in legal metrology


Device Parameters

	WP-1	Internal	Stability Delay	<input type="checkbox"/> No delay <input type="checkbox"/> o Short delay <input type="checkbox"/> Average delay <input type="checkbox"/> Long delay
			Taring ¹⁾	<input type="checkbox"/> Without stability <input type="checkbox"/> o After stability
			Auto Zero	<input type="checkbox"/> o On <input type="checkbox"/> Off
			Weight Unit ^{1 2)}	<input type="checkbox"/> User-defined / o (factory setting: grams ¹⁾ <input type="checkbox"/> Grams / g <input type="checkbox"/> o Kilograms / kg <input type="checkbox"/> Carats / ct ¹⁾ <input type="checkbox"/> Pounds / lb ¹⁾ <input type="checkbox"/> Ounces / oz ¹⁾ <input type="checkbox"/> Troy ounces / ozt ¹⁾ <input type="checkbox"/> Hong Kong tael / tlh ¹⁾ <input type="checkbox"/> Singapore tael / tls ¹⁾ <input type="checkbox"/> Taiwanese tael / tlt ¹⁾ <input type="checkbox"/> Grains / GN ¹⁾ <input type="checkbox"/> Pennyweights / dwt ¹⁾ <input type="checkbox"/> Milligrams / mg ¹⁾ <input type="checkbox"/> Parts per pound / lb ¹⁾ <input type="checkbox"/> Chinese tael / tlc ¹⁾ <input type="checkbox"/> Mommies / mom ¹⁾ <input type="checkbox"/> Austrian carats / K ¹⁾ <input type="checkbox"/> Tola / tol ¹⁾ <input type="checkbox"/> Baht / bat ¹⁾ <input type="checkbox"/> Mesghal / MS ¹⁾ <input type="checkbox"/> Tons / t
			Display Accuracy ¹	<input type="checkbox"/> o All digits <input type="checkbox"/> Reduced by 1 decimal place for load change <input type="checkbox"/> Index +1 ¹⁾ <input type="checkbox"/> Index +2 ¹⁾ <input type="checkbox"/> Reduced by 1 decimal place ¹⁾
			Zero Range	<input type="checkbox"/> 1 percent/max. cap. <input type="checkbox"/> o 2 percent/max. cap.
			Zero at Power On	<input type="checkbox"/> 2 percent/max. cap. <input type="checkbox"/> o 5 percent/max. cap.
			Tare/Zero at Power On	<input type="checkbox"/> o On <input type="checkbox"/> Off <input type="checkbox"/> Only zero at power on

¹⁾ = not available on equipment verified for use in legal metrology

²⁾ = depends on weighing platform model

Device Parameters



1) = not available on equipment verified for use in legal metrology

2) = depends on weighing platform model

3) = not with 8 data bits

4) = not with 7 data bits

Device Parameters

COM1

Data Communications

o SBI

Number of Stop Bits

- ☐ o 1 stop bit
- ☐ 2 stop bits

Handshake Mode

- ☐ Software handshake
- ☐ o Hardware, 1 character after CTS

Number of Data Bits

- ☐ o 7 bits
- ☐ 8 bits

Data Output

- ☐ On request, without stability
- ☐ o On request, after stability
- ☐ Automatic, without stability
 - ☐ o 1 display update
 - ☐ 2 display updates
 - ☐ 10 display updates
 - ☐ 100 display updates
- ☐ Automatic, at stability
 - ☐ o 1 display update
 - ☐ 2 display updates
 - ☐ 10 display updates
 - ☐ 100 display updates

- ☐ Printout, printer 1
- ☐ Printout, printer 2

Line Format

- ☐ For raw data (16 characters)
- ☐ o For other apps. (22 characters)

Factory Settings

- ☐ Yes
- ☐ o No

xBPI-232

MP8 (binary)

Application Program

- ☐ MP8: 3-1-1
- ☐ MP8: 3-1-2
- ☐ MP8: 3-1-3
- ☐ MP8: 3-1-4
- ☐ MP8: 3-1-5
- ☐ MP8: 3-1-6
- ☐ MP8: 3-1-7
- ☐ MP8: 3-1-8
- ☐ MP8: 3-1-9
- ☐ MP8: 3-2-1
- ☐ MP8: 3-2-2
- ☐ MP8: 3-2-3
- ☐ MP8: 3-2-4
- ☐ MP8: 3-2-5
- ☐ MP8: 3-2-6
- ☐ MP8: 3-2-7
- ☐ MP8: 3-2-8
- ☐ MP8: 3-2-9

Device Parameters

COM1

Data Communications

MP8

Application Program

- ☐ MP8: 3-3-1
- ☐ MP8: 3-3-2
- ☐ MP8: 3-3-3
- ☐ MP8: 3-3-4
- ☐ MP8: 3-3-5
- ☐ MP8: 3-3-6
- ☐ MP8: 3-3-7
- ☐ MP8: 3-3-8
- ☐ MP8: 3-3-9

Program Code 2

- ☐ o Code 2.1
- ☐ Code 2.2
- ☐ Code 2.3
- ☐ Code 2.4

Baud Rate

- ☐ 150 baud
- ☐ 300 baud
- ☐ 600 baud
- ☐ o 1200 baud
- ☐ 2400 baud
- ☐ 4800 baud
- ☐ 9600 baud

Parity

- ☐ Mark
- ☐ Space
- ☐ o Odd
- ☐ Even

Print in Weigh Mode

- ☐ Manual without stability
- ☐ o Manual with stability
- ☐ Automatic without stability
- ☐ Automatic at stability

SMA

Baud Rate

- ☐ 150 baud
- ☐ 300 baud
- ☐ 600 baud
- ☐ 1200 baud
- ☐ 2400 baud
- ☐ 4800 baud
- ☐ o 9600 baud
- ☐ 19,200 baud

Parity


- ☐ Space ¹⁾
- ☐ Odd
- ☐ Even
- ☐ o None ²⁾

Number of Stop Bits

- ☐ o 1 stop bit
- ☐ 2 stop bits


¹⁾ = not with 8 data bits

²⁾ = not with 7 data bits



¹⁾ = max. 2 printers can be configured

Device Parameters









1) = not with 8 data bits

2) = not with 7 data bits

3) = function will be made available in future


4) = max. 2 printers can be configured

Device Parameters


		UniCOM (Optional Interface) <input type="checkbox"/> Off <input type="checkbox"/> Data Communications: as for COM1, plus: <div style="margin-left: 20px;"> <input type="checkbox"/> SBI: as for COM1 <input type="checkbox"/> xBPI-232: as for COM1 <input type="checkbox"/> xBPI-485: as for COM2 <input type="checkbox"/> SMA: as for COM1 <input type="checkbox"/> Profibus <input type="text"/> Valid addresses: 0 to 126 inclusive; factory setting: 126 </div> <input type="checkbox"/> Printer 1: ¹⁾ as for COM1 <input type="checkbox"/> Printer 2: ¹⁾ as for COM1 <input type="checkbox"/> Analog Output Port <div style="margin-left: 20px;"> <input type="checkbox"/> Value Output <div style="margin-left: 20px;"> <input type="checkbox"/> Net value <input type="checkbox"/> Gross value </div> <input type="checkbox"/> Analog Out: Error Indicator <div style="margin-left: 20px;"> <input type="checkbox"/> High level (20 mA) <input type="checkbox"/> Low level: 0/4 mA on this interface during calibration and configuration. </div> <input type="checkbox"/> Analog Out: Data Output Mode <div style="margin-left: 20px;"> <input type="checkbox"/> Zero to maximum capacity <input type="checkbox"/> Minimum/maximum values </div> <input type="checkbox"/> Analog Out: Data Output Min./Max. <div style="margin-left: 20px;"> <input type="checkbox"/> Min. (0/4 mA) input in kg <input type="checkbox"/> Max. (20 mA) input in kg </div> </div> <input type="checkbox"/> External Alibi Memory: as for COM1 <input type="checkbox"/> Control input 1, 2 or 3
		Control Input (for Remote Switch) <input type="checkbox"/> Print key  <input type="checkbox"/> Print key  > 2 sec <input type="checkbox"/> Tare key  <input type="checkbox"/> Tare key  > 2 secg <input type="checkbox"/> Fn key  <input type="checkbox"/> WP toggle key  <input type="checkbox"/> Comb. zero/tare function
		Bar Code <input type="checkbox"/> Reference value <input type="checkbox"/> Tare value <input type="checkbox"/> ID1 <input type="checkbox"/> Data input <input type="checkbox"/> Input without activating a function <input type="checkbox"/> External keyboard
		Printout <input type="checkbox"/> Headers <div style="margin-left: 20px;"> <input type="checkbox"/> Line 1: <input type="checkbox"/> Line 2: </div> <input type="checkbox"/> ID Codes <div style="margin-left: 20px;"> <input type="checkbox"/> ID1: <input type="checkbox"/> ID2: <input type="checkbox"/> ID3: <input type="checkbox"/> ID4: </div> <input type="checkbox"/> ISO/GLP/GMP-compliant Printout <div style="margin-left: 20px;"> <input type="checkbox"/> Off <input type="checkbox"/> For 1 application result <input type="checkbox"/> For several application results </div> <input type="checkbox"/> Date/Time <div style="margin-left: 20px;"> <input type="checkbox"/> Date with time <input type="checkbox"/> Date only </div> <input type="checkbox"/> Once at Stability <div style="margin-left: 20px;"> <input type="checkbox"/> Off <input type="checkbox"/> On </div>

¹⁾ = max. 2 printers can be configured

Device Parameters



1) = max. 2 printers can be configured



¹⁾ = Outputs either latitude and altitude or gravitational acceleration, depending on configuration prior to verification

Operation

Weighing Δ

The basic weighing function is always accessible and can be used alone or in combination with application programs, such as Counting, Checkweighing, Weighing in Percent, etc.

Features

- Press $\rightarrow 0 \leftarrow$ to zero the weighing platform
 - Press $\rightarrow T \leftarrow$ to store the weight on the platform as tare
 - Use the numeric keys to enter a tare weight (press $\rightarrow T \leftarrow$ to save)
 - Use a bar code scanner to enter tare weight
 - Tare container weight automatically
 - Delete tare values by entering 0 (press $\rightarrow T \leftarrow$ to save)
 - Press Fn to toggle between:
 - Gross and net values, or
 - 1st and 2nd weight unit, or
 - Normal and 10-fold higher resolution
- Define the Fn key function in the Setup menu, under:
Fn key function
- Weigh with two weighing platforms
 - Individual ID codes for weight values
 - Print weight values:
 - Manually, by pressing F7
 - Automatically (see “Data Output Functions”)
 - With GMP-compliant format (see “Data Output Functions”)


Restore factory settings by selecting the menu setting:
Application: Weigh:
Fty settings

Soft Key Functions

- ID** Enter up to four ID codes for identifying results on the printout
- 1st ID** Save the value entered as the first ID code

Preparation

- Activate the Setup program:
 SETUP key
- Select Application Parameters:
Press the \rightarrow soft key
- Select “Weighing Only:”
Press the \rightarrow soft key



o = factory setting

- Save settings and exit Setup:
Press the SETUP key or the $\leftarrow \leftarrow$ soft key

Automatic Taring

The first weight on the scale that exceeds the preset minimum load is stored in the tare memory at stability. The values for subsequent loads are stored as weight values. The scale returns to the initial state when the load is less than 50% of the minimum load.

Configure in Setup under:
Application: Weigh:
Autotare 1st weight

Minimum Load

To tare container weights automatically, you need to set a minimum load in the Setup menu, under:

Application: Weigh:
MinL. autotar

The minimum load is defined in display digits. There are ten levels to choose from:

1 digit (no minimum load)
2 digits
5 digits
10 digits
20 digits
50 digits
100 digits
200 digits
500 digits
1000 digits

If the scale interval is 1 g, for example, and the minimum load is set to 1000 digits (=1000 scale intervals), a load of at least 1000 g is required for autotaring.

Automatic Printing

The first weight value that exceeds the minimum load is printed. Configure in Setup under:

Device: Printout:
Once at stability

Weighing with Two Weighing Platforms

Press the F7 key to toggle the display between weighing platforms. Specify one of the two platforms as the “main scale” under

Device: Operat.:
Main scale

The display shows the readout from the main scale when you switch on the Combs. Press F7 to toggle the readout between platforms.

Device Parameters

Acoustic Signal

An acoustic signal (single beep) is emitted when you press a key. A double-beep indicates that the key is not currently active. The acoustic signal can be switched on and off under:



```
Device: Operat.:  
Acoustic signal
```

Keypad

You can block keypad functions by configuring the Setup menu under:

```
Device: Operat.:  
Keypad: Keypad: Block
```

There are three settings to choose from:

- All keys unblocked
- All keys blocked except  and 
- Alphanumeric keys blocked

Display

You can adapt the display contrast to prevailing operating conditions, under

```
Device: Operat.:  
Display: Contrast
```

You can have the display backlighting shut off automatically when not in use, under:

```
Device: Operat.:  
Display: Backlit
```

Automatic Shutoff

Configure automatic shutoff under

```
Device: Operat.:  
Auto-Off
```


You can set the timer for this function to two, four or ten minutes, under:

```
Device: Operat.: Timer
```

Example:
Weighing: Tare the scale by placing a container on the weighing platform




Switch on the Combics
The automatic self-test runs. Once a readout is shown, the Combics 3 is automatically zeroed and ready to operate. With no load on the platform, you can zero the weighing platform at any time by pressing **→0←**.




Place empty container on the platform




Tare the scale
With the automatic tare function enabled, you do not need to press **→T←** to tare the scale; the tare weight is stored automatically when you place the container on the platform.



Wait until a zero value is displayed together with the NET symbol.



Place sample on the platform




Wait until the weight unit symbol is displayed (indicating stability) and then read off the weight value

Example:


Weighing: Enter value for tare using the numeric keys; print results




Switch on the Combics
The automatic self-test runs. Once a readout is shown, the Combics 3 is automatically zeroed and ready to operate. With no load on the platform, you can zero the weighing platform at any time by pressing **→0←**.




Enter the tare weight in the current weight unit using the keypad (in this example, 0.25 kg).



Save the tare weight




Place container with sample on the platform



Read the result




Toggle the display from net to gross weight values. The display shows:



the gross weight (in this example, 0.250 kg for the container plus 2.000 kg for the sample)



Toggle to display of net value



Print the results

```
-----
24.10.2002    10:09
Typ    CW3P1-12ED-L
Vers.    1.0010.10.2
BVers.    01-26-01
-----
EISENSCHMIDT
GOETTINGEN
Batch no.    123456
Cust.        Smith
24.10.2002    10:09
-----
```

GMP header (only if GMP-compliant printout is configured)

End of GMP header
Header lines

ID codes

```
G#    +    2.250 kg
T     +    0.000 kg
PT2   +    0.250 kg
N     +    2.000 kg
-----
```

GMP footer (only if GMP-compliant printout is configured)

```
-----
24.10.2002    10:10
Name :
-----
```

End of GMP footer


Example:

Weighing: Change the tare values, print results, delete tare values



Switch on the Combics

The automatic self-test runs. Once a readout is shown, the Combics 3 is automatically zeroed and ready to operate. With no load on the platform, you can zero the weighing platform at any time by pressing $\rightarrow T \leftarrow$.



Place empty container on the platform




Tare the scale


Note: With the automatic tare function enabled, you do not need to press $\rightarrow T \leftarrow$ to tare the scale; the tare weight is stored automatically when you place the container on the platform.



Wait until a zero value is displayed together with the NET symbol.




Place packaged sample in the container



Enter the tare weight of the packaging in the current weight unit using the keypad in this example, 0.25 kg).



Save the package weight. The package tare is added to the container tare.



Read off net weight



Print the results


G#	+	6.433	kg
T	+	4.183	kg
PT2	+	0.250	kg
N	+	2.000	kg



Enter a zero ("0") using the keypad



Save the value entered. This deletes tare values; the display shows the gross value.



Print the results

G#	+	6.433	kg
T	+	0.000	kg
N	+	6.433	kg

Data ID Codes (Identifiers)

You can assign codes (such as product name, batch number, etc.) for identification of measured values on printouts.

Features

- Assign up to four ID codes.
- Assign both a name and a value for each ID code.
- The name is left-justified and the value is right-justified on the printout. If the entire code is too long for one line, additional lines are printed.
- Enter ID code names in Setup under:
Device: Printout:
ID codes
Enter up to 20 characters for the ID code name. No more than 11 characters are displayed during input; all 20 characters are printed.
- Enter up to 21 characters for the value of the ID code. Press the **ID** soft key to activate the input mode.
- Enter the first ID value directly through the numeric keypad. Press the **1st ID** soft key to save the value.
- To delete individual characters from an ID value, press **↵**; press the **Delete** soft key to delete the entire value.
- If both the name and value fields are empty, no ID code is printed.
- In the Setup program, you can configure when and whether ID codes are printed (see “Configuring Printouts”).

Factory settings for the ID code names:

ID1:	ID1
ID2:	ID2
ID3:	ID3
ID4:	ID4

Factory settings for the ID code values:

No default values set.

Soft Key Functions

ID	Toggle to ID code input
ESC	Cancel input
Delete	Delete selected ID code value
1st ID	Save the value entered as the first ID code

Example:
Entering ID code names.
Enter “Batch no.” and “Cust.” as names for ID codes 1 and 2.

SETUP

2 × soft key ↵

Activate the Setup program

SETUP
Application parameters
Fn key function
Device parameters
Info
Language

Soft key ➤
6 × soft key ↵

Select “Device parameters”

SETUP	DEVICE
WP 1	
COM 1	
COM 2	
UniCOM	
Control input	
Bar code	
Config. printout	
Operating parameters	
Clock	
Password	
<<	< ^ v >

Soft key ➤
Soft key ↵

Select “Config. printout”

SETUP	DEVICE	PRINTOUT
Headers		
ID codes		
ISO/GLP/GMP printout		
Date/time		
Once at stability		
FlexPrint		

Soft key ➤

Select “ID codes”

DEVICE	PRINTOUT	ID CODES
ID1:		ID1
ID2:		ID2
ID3:		ID3
ID4:		ID4

ABC

Activate alphabetical input

2 ×

2
ABC

Press the

2
ABC

 key twice to enter the letter “B”

DEVICE	PRINTOUT	ID CODES
ABC	ABC2abcAAE9aaaaaaz9	
ID1:		ID1
ID2:		ID2
ID3:		ID3
ID4:		ID4

5 ×

2
ABC

Press the

2
ABC

 key five times to enter the letter “a.”

DEVICE	PRINTOUT	ID CODES
ABC		
ID1:	Batch no.	ID1
ID2:		ID2
ID3:		ID3
ID4:		ID4

Use this procedure to enter all letters.

Soft key ↵

DEVICE	PRINTOUT	ID CODES
ABC		
ID1:		Batch no.
ID2:		Cust.
ID3:		ID3
ID4:		ID4

Confirm the name for the first ID code

Soft key ↵

DEVICE	PRINTOUT	ID CODES
ID1:		Batch no.
ID2:		Cust.
ID3:		
ID4:		

Enter the name for ID code 2 (in this example, "Cust.")

Confirm the name for the second ID code

Soft key ↵

Delete ID codes "ID3" and "ID4"

Soft key <<

Confirm input

Exit the Setup menu

Example:

Entering ID code values.

Enter "123456" and "Smith" as names for ID values 1 and 2.

Max	12 kg	d=	1 g
0%			100%
0	0.000		kg
ID			

Soft key I D

Activate input of ID code values

ID:	
Batch no.	
Cust.	

1	2	3
4	5	6

Enter value for ID code 1 (in this example, 123456)

ID:	
123	
Batch no.	123456
Cust.	

Soft key ↵

Confirm value for the first ID code

ID:	
ABC	
Batch no.	123456
Cust.	Smith

Enter value for ID code 2 (in this example, "Smith")

Soft key ↵

Confirm input

Soft key <<

End input of ID code values

Operation

Calibration and Adjustment

Purpose

Perform calibration to determine the difference between the value displayed and the actual weight on the platform. Calibration does not entail making any changes within the weighing instrument.


Perform adjustment to eliminate this difference, or reduce it to an amount within the applicable tolerance limits.

Configuration for Use in Legal Metrology

Configuration of the weighing instrument for use in legal metrology is set by a switch on the back of the indicator. The switch is covered by a protective cap.

Position:

- Switch on the left:
For use in legal metrology
- Switch on the right:
External calibration/adjustment accessible



Features

Which of the following features are available depends on the connected weighing platform. These features are configured in the Setup menu:

- External calibration/adjustment blocked in verified weighing instruments
- External calibration/adjustment with the default weight value or standard weight (not available on verified instruments). Configure under:
... Calibration/
adjustment: CAL key
function
- Specify the weight for external calibration/adjustment:
... Calibration/
adjustment: External
weight
- Internal adjustment for IS weighing platforms (configure under: COM1: or COM2: WP2)
- Block the $\rightarrow T \leftarrow$ key to prevent use of the two functions described above (1.9.10):
... Calibration/
adjustment: CAL key
function
- Calibrate first; then adjust automatically or manually (not on verified weighing instruments):
... Calibration/
adjustment: Cal./adj.
sequence
- Flashing WP symbol as adjustment prompt. If more than one weighing platform is connected, the platform number is also displayed:
... Calibration/
adjustment: CAL key
function
- Block external calibration/adjustment:
... Calibration/
adjustment: Activate
ext. adj.
- Elevation and latitude or gravitational acceleration displayed after Cal is shown when the Combics is switched on, if these values have been entered.
Device: Operat.:
Geograph. data
For each of these parameters, the term is displayed first (Altitud, Latitud or Gravity) for 1 second, and then the corresponding value is displayed continuously until you press $\rightarrow T \leftarrow$.

Preparation

- Activate the Setup program:
Press the $\rightarrow T \leftarrow$ key
- Select "Device Parameters:"
Press the \rightarrow soft key
- Select weighing platform 1, "WP1":
Press the \rightarrow soft key, or
- Select interface 1, "COM1" or interface 2, "COM2" (depending on the interface used): Press the \rightarrow soft key
- Select weighing platform 2, "WP2":
Press the \rightarrow soft key

Calibration/Adjustment

- CAL Key Function
 - o Ext. cal./adjust.: default weight
 - o Ext. cal./adjust.: user-def. weight
 - o Key blocked
- Cal./Adj. Sequence
 - o Cal. then auto adj.
 - o Cal. then manual adj.
- isoCAL Function
 - o Off
 - o Adjustment prompt
- Activate Ext. Adj.
 - o Activated
 - o Deactivated
- External Weight

o = factory setting

- Save settings and exit Setup:
Press $\rightarrow T \leftarrow$ or the $\leftarrow \leftarrow$ soft key

Example:

External calibration and manual adjustment with default weights (weighing parameters: factory settings)




Zero the scale




(press and hold)


Start calibration (e.g., when adjustment prompt flashes: **WP**)




"Cal" is shown for two seconds




You are prompted to place the required weight on the platform (e.g., 10,000 g)



Position the calibration weight on the weighing platform



The difference between the weight value and the true mass is displayed, with +/- sign.




External calibration
Nom. + 10000 g
Diff. + 1 g

Calibration record is printed, if adjustment was not performed and the process was stopped by pressing



Activate calibration/adjustment (press the key to cancel).




The calibration weight is displayed at the conclusion of calibration

```
-----
24.10.2002    10:15
Typ          CIS3
Vers.       1.0010.10.2
BVers.      01-26-01
-----
External calibration
Nom.  +    10000 g
Diff. +      1 g
External adjustment
Diff. +      0 g
-----
24.10.2002    10:15
Name:
-----
```

A GMP-compliant printout is generated

Data Output Functions

Data is output to the indicator display and to the interfaces. There are two standard interfaces, COM1 and COM2, and an optional multi function interface (UniCOM).



Output to the Indicator (Weights and Calculated Values)



Lines for Metrological Data (in Legal Metrology)

This line shows:

- Max 300kg** – Upper limit of the weighing capacity (in this example, 300 kg)
- Min 0.1kg** – Lower limit of the weighing capacity; weight values below this limit are not permitted in legal metrology (in this example, 0.1 kg)
- e= 0.1kg** – Verification scale interval; this value is not relevant for weighing instruments that are not used in legal metrology (in this example, 1 kg)
- d= 0.01kg** – Readability/index: The scale interval of the weighing instrument (in this example, 0.01 kg)

Plus/Minus Sign, Busy Symbol, Zero-setting Range

This section shows:

-  – “Busy” symbol: shown when the scale is processing a function activated by pressing a key
- +** **-** – the plus or minus sign of the weight or other measured value
-  – Zero-setting symbol: Identifies “zero” as a weight value (after the scale or the active weighing platform has been zeroed)

Line for Measured Value/Results

This section shows:

5.234

- The current weight value (on verified scales or platforms with e ≠ d, the last digit is bordered for identification as a legal value), or

20

- A calculated value when using an application program, such as Counting or Weighing in Percent

Unit

This section shows:

g

- The current weight unit (e.g., “g”)

PCS

- The unit of measure for other characteristics, such as “pieces” in the Counting application

Data in Tare Memory, Calculated Value, Identification of the Active Weighing Platform when More Than One Platform is Used

This section shows:

△

- Identification of calculated values (values not used in legal metrology)

B/G NET

- Identification of gross value or net value (data in tare memory)

PT

- Identification of manual tare input (using a bar code scanner)

WP1

- Display of the active weighing platform when 2 platforms are connected. The symbol flashes to prompt adjustment of the weighing platform, if the isoCAL function is active.

WP

- When the timer is active (Setup: ...: Operat.: Timer) the symbol flashes to indicate that one-half of the preset time period has elapsed.

Symbols for Printing, GMP Printout and Battery Status

This section shows:

🖨

- Printing in progress

📋

- GMP-compliant printout is configured

🔋

- Battery status: ‘Battery fully charged’ or ‘Battery empty’

Bar Graph

On the bar graph, a measured value is displayed either:

0% 100%

- as a percentage of the maximum capacity of the scale or weighing platform (gross weight), or

100%

- in relation to a target value, with tolerance limits indicated

Application Symbols

This section shows:

R1 R2

- Display of the range on multiple-range scales

▲

- Symbols for application programs:
 - Symbol for the Counting application

Σ % 1/2 1/4 1/8 1/16 1/32

- Symbols for the Totalizing, Checkweighing, Classification, Net-total Formulation, Weighing in Percent, Counting (with or without reference sample updating) and Neutral Measurement application programs. For details on the application programs, please see the “Basic Application Programs” manual for the CombiCS 3.

Interface Port

Purpose

The indicator is equipped with the following data interfaces:

- Standard COM1 and COM2 interfaces
- optional: UniCOM universal data interface (see “Accessories”).

Both interfaces can be configured in the Setup program (see “Configuring the Combics”) for different input/output functions. For example, you can connect a printer, Alibi memory, PC, remote checkweighing display, or second weighing platform to a COM port, or configure the port for control command input (e.g., for using a foot switch). The optional UniCOM interface can be used for Profibus-DP, RS-232, RS-485 or RS-422 communication, or as a voltage/current (analog) interface. A bar code scanner or an external rechargeable battery pack can be connected to the female UniCOM port.

Features

- CISL3 indicator (IP44 protection): Connect via a 25-contact D-Sub female connector. If you wish to connect a second device to an interface port, a T-connector is required (see “Accessories”).
- CIS3 indicator (IP67 protection): Route the connecting cable from the peripheral device to the indicator via a cable gland.

⚠ Warning When Using Pre-wired RS-232 Connecting Cables

RS-232 cables purchased from other manufacturers often have incorrect pin assignments for use with Sartorius weighing systems. To prevent malfunctions and defects, be sure to check the pin assignments against the chart in this manual before connecting the cable.

Specifications

Serial interface:

Operating mode:	Full duplex	
Standard:	COM1:	RS-232,
	COM2 ¹⁾ :	RS-232, RS-485
	UniCOM (optional) ¹⁾ :	RS-232 or RS-422/RS-485
Interface connector:	CISL3 indicator (IP44 protection): 25-contact D-Sub female connector CIS3 indicator (IP65/67 protection): The free ends of the cable are connected to terminal screws inside the housing; the cable is routed into the housing via a cable gland.	
Transmission rates:	150, 300, 600, 1200, 2400, 4800, 9600 and 19,200 baud (depending on the operating mode)	
Number of data bits:	7 or 8 bits	
Parity:	Space, odd, even, none (depending on the operating mode)	
Number of stop bits:	1 or 2 stop bits	
Handshake Mode	Software (XON/XOFF) or hardware (1 character after CTS)	
Communication mode:	SBI, xBPI-232 ²⁾ , xBPI-485 ²⁾³⁾ MP8-binary ⁴⁾ , SMA, Profibus (UniCOM only) Available printers: – YDP01IS – YDP02IS-Label – YDP01IS-Label – Universal – YDP02 – YDP04IS – YDP03 – YDP04IS-Label – YDP02IS – YAM01IS Alibi memory	
Network address ⁵⁾ :	0, 1, 2, (...), 31	
SBI: Manual output:	Without stability, after stability, configurable printout	
SBI: Automatic output:	Without stability, at stability, at user-defined intervals	
SBI: Output format	16 or 22 characters	
Printout of application data:	Output of a configurable printout	

Factory settings:

Depends on the device configured; for example, “Data record”, “SBI”

Transmission rate:	1200 baud
Number of data bits:	7 bits
Parity:	Odd
Stop bits:	1 stop bit
Handshake:	Hardware handshake, 1 character after CTS
Activation of data output:	Print on request after stability
Time-dependent autoprnt:	1 display update
Output format:	22 characters

Analog UniCOM interface (optional)

Standard:	4 to 20 mA, 0 to 20 mA, 0 to 5V
Power supply:	Internal or external
Factory settings:	4 to 20 mA, internal power supply
Interface connector:	CISL3 indicator (IP44 protection): 25-contact D-Sub female connector CIS3 indicator (IP67 protection): The free ends of the cable are connected to terminal screws inside the housing; the cable is routed into the housing via a cable gland.

⚠ If necessary, use an external power source to power peripheral devices.


¹⁾ The signals from both the COM2 and the UniCOM ports are transmitted over a single D-Sub female connector

²⁾ xBPI operating mode: 9600 baud, 8 data bits, parity: odd, 1 stop bit

³⁾ COM2 and optional UniCOM universal data interface

⁴⁾ Only with the standard COM1 interface

⁵⁾ Network address is valid only in the xBPI mode



* Factory setting

²⁾ Max. 2 printers can be configured

¹⁾ COM2 only

³⁾ Function will be made available in future

Preparation

- See “Pin Assignment Chart” for pin assignments and wiring diagram.

Options for Connecting Peripherals

You can connect the following printers to the COM1, COM2 or UniCOM port:

- YDP02 (user-definable interface parameters)
- YDP03 (user-definable interface parameters)
- YDP011S (strip or label printer)
- YDP021S (strip or label printer)
- YDP041S (strip or label printer)
- Universal printer (user-definable transmission parameters)
- YAM011S Alibi memory

⚠ If necessary, use an external power source to power peripheral devices.

In addition, the following devices can be connected to the standard COM1 and COM2 interfaces:

- Foot switch / hand switch
- PC (RS-232 interface)
- Second weighing platform (RS-232 interface)
- External checkweighing display (red/yellow/green) over the digital I/O (Sartorius standard)
- External rechargeable battery pack
- Bar code scanner / keyboard interface

The following devices can be connected to the optional UniCOM universal interface:

- PC (RS-232 interface)
- Second printer (external power source required)
- Remote display
- Digital I/O
- Current interface (0/4 - 20 mA)
- PLC with Profibus DP

Combiics 3 enables connection of a second weighing platform, either to the COM1 port or to the UniCOM universal port.

The standard COM1 port is operated in the RS-232 mode. The second weighing platform can be operated in any of the following modes:

- SBI
- xBPI-232 (factory setting)
- ADC-232

The standard COM2 port and the optional UniCOM universal interface can be operated in either the RS-232 or RS-485 mode. The second weighing platform can be operated in any of the following modes:

- SBI (RS-232 mode)
- xBPI-232 (RS-232 mode)
- ADC-232 (RS-232 mode)
- IS485 (RS-485 mode, xBPI mode; factory setting)
- ADC-485 (RS-485 mode)

The standard COM1 and COM2 ports or the optional universal UniCOM interface can be used as a printer interface.

For operation as a COM port, you can adapt data records to the following operating modes:

- SBI (factory setting)
- xBPI-232
- xBPI-485
- M8 binary (COM1 port only)
- SMA

In the SBI communication mode, you can control a display unit and a connected weighing platform by sending ESC commands from a PC to the communications port (COM1 or UniCOM). For details, see the section entitled “Data Input Format” in this chapter.

Generating SBI Data Output

In the Setup menu, under “Data Communications: SBI: Data output”, you can define which data is output when an output command is received:

- The displayed value, with or without stability check
- Automatic output of the displayed value, either with or without stability check, or automatically at defined intervals
- Output of a printout as configured in the Setup program, under “Device parameters: Printout: Printer 1 (or 2)” (see next page).

You can define the printout content by specifying which blocks of information are to be included. Please refer to the section entitled “Configuring Printouts” in this chapter for detailed instructions and sample printouts.

If you do not activate and configure a user-definable data record, the printout simply contains the current value displayed on the indicator (weight with unit, calculated value, numeric or alphabetic ID).


Generally, data is output only after the weighing instrument has stabilized. The settings are configured under “Data Communications: SBI: Data output”: Here you can define whether data is output on request or automatically, at stability or without stability check; and configure a user-defined printout. If you select time-dependent automatic printout, you need to define the print interval (in display updates) as well.

Line Format

Each line of a printout can contain up to 20 characters. The first 6 characters, called the “data header”, identify the subsequent value. Under “Data communications: SBI: Line format” you can disable header printing, in which case a printed line can contain up to 14 characters (factory setting: “For other apps. 22 characters”).

For more details, refer to the “Operating Menu Overview” in the chapter entitled “Configuration”.

Device Parameters




o = Factory setting

¹) = More than one can be selected



²) = When the minimum load is exceeded (configure under:
Application parameters: ... : Minimum load for autotaring)

Printing

Press the  key to output data to the printer port.

If the Setup program is active, the menu settings are printed.

- The printout is generated once the SBI command “Esc k P _” is received, (see “Data Input Format” in this chapter), or when a certain key is pressed (e.g., to save a value or start a routine) also generates a print command. In this case, a configurable printout is generated with application-specific data.

The  and  symbols are displayed when data is being output to the printer port.

Line Format

See previous page.

Configuring Printouts

To configure a printout, activate the Setup menu and navigate to the menu items shown in the diagram on the left. For details on Setup menu navigation, see “Configuration”.

You can configure a different printout for each interface. Each printout contains your choice of the following information blocks; to enable or disable a block in the printout, select it or deselect it in the Setup menu:

- Headers: Line 1, Line 2
- Date, time
- Dotted line and blank line (for the Weighing application). This block cannot be deselected.
- Initialization data (e.g., reference sample quantity, reference piece weight), followed by a blank line. This block is not included on the printout of results from the Totalizing and Net-total Formulation applications.
- Serial number of the load cell
- Results: Gross, tare, and net values; blank line and application-specific result (e.g., piece count) followed by a dotted line.

In the Setup menu, select the blocks of information that you wish to include (multiple selections possible; factory settings: all blocks included). A blocked that is not selected is omitted from the printout.

Information Blocks

The individual information blocks are shown below with detailed explanations. Samples of complete printouts are provided following the end of this section.

Headers

You can define 2 headers, each with 20 characters per line (e.g., for printing your company's name).

The following characters are available: "0" to "9", "A" to "Z", "-", and " " (space).

When this block is enabled, the printout appears as follows (example):

```
ACE HARDWARE
GOETTINGEN
```

In this example, the company name is centered on the printout. This was achieved by entering 3 blank spaces at the beginning of the first line, and 4 at the beginning of the second line.

ID Codes

ID1: Data ID code 1

ID2: Data ID code 2

ID3: Data ID code 3

ID3: Data ID code 3

The name (in this example, ID1) is left-justified and the value is right-justified on the printout. If name and value together are too long for one line, the remaining characters are printed in subsequent lines.

When this block is enabled, the printout includes up to four ID codes, which are stored in the indicator. Example:

```
ID1      Batch no.1234
ID2      Steelmeyer Co.
ID3      Screws M4x6
ID4      Mr. Smith
-----
```

Date/Time

When this block is enabled, the printout appears as follows (example):

```
21.01.2001      16:02
```

To achieve a standardized time stamp (e.g., for documentation in a fully automated system), you can disable the printout of the time in this information block, by selecting "Device parameters: Config. printout: Date/time: Date only" (factory setting: "Date with time"). With "Date only" selected, the time stamp can be inserted by a higher-level controller or central computer to maintain consistent time stamping. This setting is especially important for communication with a PC.

Separating Block: Dotted Line

This block is automatically inserted before further information blocks are printed.

```
-----
```

Application Initialization Data

Which data is included in this block depends on the active application. In the Weighing application, for example, this block is empty; in the Counting application, the reference sample quantity and the reference piece weight are printed. The block is terminated with a blank line. When this block is enabled, the printout appears as follows (example: Counting application):

```
nRef          10 pcs
wRef  +      0.035 kg
```

Scale ID (e.g., the serial number of the weighing platform)

When this block is enabled, the printout appears as follows (example):

```
Ser.no.      1234567890
```


Application Results

Which data is included in this block depends on the active application. If provided in the application, the gross, net and tare weights are usually printed, followed by a blank line. In the Counting application, the piece count is printed as the result. This block is terminated by a dotted line. When this block is enabled, the printout appears as follows (example: Counting application):



```
G#    +      1.402 kg
T      +      0.200 kg
N      +      1.202 kg
```


```
Qnt          34 pcs
-----
```

Enabling GMP-compliant Printouts

Select "ISO/GLP/GMP printout" to add a GMP header and a footer bracketing the measured result on the printout. If the GMP-compliant printout is activated (factory setting: Off), the  symbol is displayed on the indicator until the printout is generated. You can choose from the following settings:

- GMP-compliant printout off (factory setting)
- GMP-compliant printout for 1 result
- GMP-compliant printout for multiple results

The GMP header is included from the first printout generated subsequent to the activation of the "GMP" menu item. The GMP footer is printed either after each measured result ("ISO/GLP/GMP: For 1 application result"), or after the last result in a series of measurements, when you press and hold the  key for more than 2 seconds ("ISO/GLP/GMP: For several application results"). In this case, the  symbol remains displayed until the GMP footer is printed.

If you toggle to a different platform while a GMP printout of several measured results is being generated, the GMP footer for the platform used up to that point is generated when you press . The GMP header for the other platform is included on the next printout generated.

A GMP-compliant printout is generated automatically at the conclusion of calibration/adjustment routines, as well as when you set or clear a preload.

If you use a label printer for GMP-compliant printouts, you may find that a single label is not long enough for the data printed. If this is the case, activate the "Form feed" setting to advance the paper after each printout of a GMP header and application results.

The following page shows three samples of GMP headers and footers. Please refer to the following section, "Sample Printouts", for samples of complete printouts.

Sample Printouts

For details on the individual information blocks, see “Configuring Printouts”, above. For details on configuring the header lines, refer to the “Basic Application Programs” manual for the Combiics 3.

Weighing Application

There is no data for the “initialization data” block. If this block is enabled for the printout, a blank line is output.

With weighing platform serial number:

```

      HEADER LINE 1
      HEADER LINE 2
14.01.2002      09:43
-----
Ser.no.      80705337

G#    +      1.402 kg
T     +      0.200 kg
N     +      1.202 kg
-----

```

Counting Application

The “Initialization data” block contains the reference sample quantity and reference piece weight. The “Results” block contains gross, net and tare weights, as well as the calculated piece count.

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
nRef      10 pcs
wRef    +      0.035 kg

G#    +      1.402 kg
T     +      0.212 kg
N     +      1.190 kg

Qnt      34 pcs
-----

```

Neutral Measurement Application

The “Initialization data” block contains the reference sample quantity and reference weight. The “Results” block contains gross, net and tare weights, as well as the calculated piece count.

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
Ref      2 o
wRef    +      1.200 kg

G#    +      14.700 kg
T     +      0.300 kg
N     +      14.400 kg

Qnt      12 o
-----

```

Weighing in Percent Application

The “Initialization data” block contains the reference percentage and reference weight. The results block shows gross, net and tare weights, as well as the percentage, which is shown as either the loss or the residual amount.

Percentage = residue:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
pRef      100 %
Wxx%    +      2.100 kg

G#    +      1.859 kg
T     +      0.200 kg
N     +      1.659 kg

Prc      79 %
-----

```

Percentage = loss:

```

      :
      :
D      21 %
-----

```

Checkweighing Application

The “Initialization data” block contains the nominal, minimum and maximum weights. The “Results” block always contains the gross, net and tare weights. The other results can be displayed in one of two ways:

- Result = Weight:
The deviation from the nominal weight is given both as a percentage and as an absolute (weight) value, whether the result lies within the “OK” range or not.
- Result = Threshold status:
If the result lies within the “OK” range, the printout shows the deviation from the nominal weight both as a percentage and as an absolute (weight) value, just as in the “Weight” printout mode described above. If the result is outside the “OK” range, the last line of the printout indicates the status as follows:

Result in “OK” range; “Weight” or “Threshold” printout:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
Setp    +      1.300 kg
Min     +      1.235 kg
Max     +      1.365 kg

G#    +      1.312 kg
T     +      0.000 kg
N     +      1.312 kg

Lim     +      0.92 %
W.Diff+      0.012 kg
-----

```

Result outside “OK” range; “Weight” printout:

```

      :
      :
Lim     -      7.69 %
W.Diff-      0.100 kg
-----

```

Result outside (under) “OK” range; “Threshold” printout:

```

      :
      :
Stat     LL
-----

```

Result outside (over) the “OK” range; “Threshold” printout:

```

      :
      :
Stat     HH
-----

```


Classification Application

The "Initialization data" block contains the upper limits of Classes 1 through 4. The "Results" block contains gross, net and tare weights, as well as the class that the sample belongs to (1 through 5, where Class 5 means that the upper limit of Class 4 was exceeded).

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
Lim1  +   10.000 kg
Lim2  +   11.000 kg
Lim3  +   12.000 kg
Lim4  +   13.000 kg

G#    +    9.700 kg
T     +    0.000 kg
N     +    9.700 kg

Class                               11)
-----
```

- ¹⁾ Classification is based on values from 1 to 5. Any weight that exceeds the upper limit defined for Class 4 is designated as Class 5, if the application is configured for 5 classes rather than 3.

Animal Weighing Application

The "Initialization data" block contains the number of measured values that averaging is based on. The "Results" block contains the tare weight and the mean value.

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
mDef                               8

T     +    0.000 kg
x-Net +    4.202 kg
-----
```

Net-total Formulation Application

The "Initialization data" block is empty. Which data is contained in the "Results" block value depends on the program operating status at the time of printing.

The following options are available:

- Total/results printout (press **[CF]**)
- Individual/components printout (When **M+** is pressed to save a component, or when **[F]** is pressed for an individual printout)

'Total' printout:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
n                               3
Tot.cp+   3.400 kg
Cont.T+   0.200 kg
-----
```

Individual/Component Printout

If you press **[OK]** the header is printed only once. Each component is printed automatically when you press **M+** to store it. If you are using a label printer, make sure a single label is large enough for the list of all components. For printer models YDP01IS and YDP04IS, you can configure manual form feed in the operating menu. With the YDP02IS printer, form feed is automatic after each print command (fixed setting).

If an automatic printout is generated when you store a component, the component weight is equal to the current net weight. This is why components rather than net weights are printed.

Component printout

Example with 3 components (the corresponding 'Total' printout is shown above):

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
Cmp001+   1.200 kg

Cmp002+   2.000 kg
```

Printout of third component generated by pressing **[F]**

```

G#    +    4.400 kg
T     +    0.200 kg
T2    +    4.200 kg
N     +    0.000 kg
```

Individual printout when a component is saved in tare memory by pressing **[OK]**

Example: Print second component:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
Cmp002+   1.000 kg
```

Individual printout of a component by pressing **[F]**

Example for second component:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
G#    +    2.400 kg
T     +    0.200 kg
T2    +    2.200 kg
N     +    0.000 kg
```

Totalizing Application

The "Initialization data" block is empty. If this block is enabled for the printout, a blank line is output.

Which data is contained in the "Results" block value depends on the program operating status at the time of printing. The following options are available:

- 'Results' printout (press **[CF]**): Printout of values from gross totalizing memory "*G", net totalizing memory "*N" and number transactions "n".
- Standard / component printout automatic (when **M+** is pressed to save a value)
- Standard / component printout manual, by pressing **[F]**. When the components printout is configured, the header is printed only once, followed by all components.

If you are using a label printer, make sure a single label is large enough for the list of all components.

When "manual" printing is configured (press **[F]** to print) the transaction counter value is not printed.

Printout of components

Example with 3 transactions:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
G#   +   1.400 kg
T    +   0.200 kg
N    +   1.200 kg
n                1

G#   +   3.400 kg
T    +   0.200 kg
N    +   3.200 kg
n                2

G#   +   4.400 kg
T    +   0.200 kg
N    +   4.200 kg
n                3

```

'Total' printout (by pressing **[CF]**);
application data and status as above:

```

      HEADER LINE 1
      HEADER LINE 2
14.01.2002      09:43
-----
*G           9,200 kg
*N    +     8,600 kg
n                3
-----

```

Individual printout when storing a
component in totalizing memory by
pressing **[SETUP]**

Example: Print second transaction:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
G#   +   2.400 kg
T    +   0.200 kg
N    +   2.200 kg
n                2

```

Individual printout (by pressing **[F7]**)

Example: Print second transaction:

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
G#   +   2.400 kg
T    +   0.200 kg
N    +   2.200 kg

```

GMP-compliant Printout

The GMP-compliant printout consists of
3 sections (see also the section entitled
"Enabling GMP-compliant Printouts,"
above):

- GMP header
- Printout of data record (for example,
from the Weighing application)
- GMP footer

Linearization record:

```

-----
14.07.2002      13:00
Typ            CIS3
Ser.no.        12345678
Vers.          1.0010.10.2
BVers.         01-26-02
-----

```

```

Linearization
Wt.1 +         7.00 kg
Wt.2 +        15.00 kg
Wt.3 +        22.00 kg
Wt.4 +        30.00 kg
-----
completed

```

```

-----
14.07.2002      13:02
Name:
-----

```

Calibration/adjustment record:

```

-----
14.07.2002      13:50
Typ            CIS3
Ser.no.        12345678
Vers.          1.0010.10.2
BVers.         01-26-02
-----

```

```

External calibration
Targ. +        30.00 kg
Diff. -         0.03 kg
External adjustment
Diff. +         0.00 kg
-----

```

```

14.07.2002      13:52
Name:
-----

```

'Set preload' record:

```

-----
14.01.2002      13:50
Typ            CIS3
Ser.no.        12345678
Vers.          1.0010.10.2
BVers.         01-26-02
-----
Set preload
-----
completed

```

```

-----
14.07.2002      13:52
Name:
-----

```

'Clear preload' record:

```

-----
14.07.2002      13:50
Typ            CIS3
Ser.no.        12345678
Vers.          1.0010.10.2
BVers.         01-25-01
-----
Clear preload
-----
completed

```

```

-----
14.07.2002      13:52
Name:
-----

```

Weighing printout with multiple results
Example with 2 results:

```

-----
14.07.2002      09:43
Typ            CIS3
Ser.no.        12345678
Vers.          1.0010.10.2
BVers.         01-26-01
-----

```

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:43
-----
G#   +   2.40 kg
T    +   0.20 kg
N    +   2.20 kg
-----

```

```

      HEADER LINE 1
      HEADER LINE 2
14.07.2002      09:44
-----
G#   +   3.40 kg
T    +   0.30 kg
N    +   3.10 kg
-----
14.07.2002      09:45
Name:
-----

```

Data Output Format (Line Format)

You can output the value displayed in the measured value line and the weight unit, with or without a data ID code. Whether the data ID code is included in the output depends on your settings under “Line Format”.

Examples:

Q n t + 235 p c s Without data ID code
 + 235 p c s With data ID code

Line Format settings:

For raw data (16 characters): no “data header“

For other apps. 22 characters): with “data header”
(factory setting).

Data Output Format with 16 Characters

Display segments that are not activated are output as spaces. Characters without a decimal point are output without a decimal point.

The type of character that can be output depends on the character’s position:

Normal Operation

Pos.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	+	*	D	D	D	D	D	D	D	*	U	U	U	CR	LF	
or	-	*	D	D	D	D	D	D	D	*	U	U	U	CR	LF	
or	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	CR LF

+ -: Plus or minus sign

*: Space

D: Digit or letter (max. 7 characters plus decimal point)

U: Character for unit of measurement¹⁾
(1 to 3 letters followed by 0 to 2 spaces)

CR: Carriage return

LF: Line feed

¹⁾ depends on scale type; for example, not all units are available on scales verified for use in legal metrology.

Special Codes

Pos.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	*	*	*	*	*	*	-	-	*	*	*	*	*	*	*	CR LF
or	*	*	*	*	*	*	H	*	*	*	*	*	*	*	*	CR LF
or	*	*	*	*	*	*	H	H	*	*	*	*	*	*	*	CR LF
or	*	*	*	*	*	*	L	*	*	*	*	*	*	*	*	CR LF
or	*	*	*	*	*	*	L	L	*	*	*	*	*	*	*	CR LF
or	*	*	*	*	*	*	C	*	*	*	*	*	*	*	*	CR LF

*: Space

- -: Final readout mode

H: Overload

HH: Overload in Checkweighing

L: Underload

LL: Underload in Checkweighing

C: Calibration/adjustment

Error Codes

Pos.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	*	*	*	E	r	r	*	*	#	#	*	*	*	*	*	CR LF
or	*	*	*	E	r	r	*	*	#	#	#	*	*	*	*	CR LF

#: Space

#: Error code number (2 or 3 digits)

Example: Output of the weight value +1255.7 g

Pos.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	+	*	*	*	1	2	5	5	.	7	*	g	*	*	CR	LF

Position 1: Plus or minus sign or space

Position 2: Space

Positions 3-10: Weight value with decimal point; leading zeros are output as spaces.

Position 11: Space

Positions 12-14: Unit symbol or space

Position 15: Carriage return

Position 16: Line feed

Data Output Format with 22 Characters

When data is output with an ID code, the 6-character code precedes the 16-character string described above. The code identifies the subsequent value.

Normal Operation

Pos.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
	1	1	1	1	1	1	+	*	D	D	D	D	D	D	D	*	U	U	U	CR	LF	
or	1	1	1	1	1	1	-	*	D	D	D	D	D	D	D	*	U	U	U	CR	LF	
or	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	CR LF

I: ID code character¹⁾, right-justified with spaces

+ -: Plus or minus sign

*: Space

D: Digit or letter (max. 7 characters plus decimal point)

U: Character for unit of measurement¹⁾
(1 to 3 letters followed by 0 to 2 spaces)

CR: Carriage return

LF: Line feed

Special Codes

Pos.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
	S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	-	-	*	*	*	*	CR LF
or	S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	H	*	*	*	*	*	CR LF
or	S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	H	H	*	*	*	*	CR LF
or	S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	L	*	*	*	*	*	CR LF
or	S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	L	L	*	*	*	*	CR LF
or	S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	C	*	*	*	*	*	CR LF

*: Space

H: Overload

L: Underload

C: Calibration/adjustment

- -: Final readout mode

HH: Overload in Checkweighing

LL: Underload in Checkweighing

Error Codes

Pos. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22
 S t a t * * * * * E r r * * # # * * * * CRLF
 or S t a t * * * * * E r r * # # # * * * * CRLF

*: Space

#: Error code number (2 or 3 digits)

Characters for ID code 1 ¹⁾	Meaning
G#	Gross value
N	Net value
T	Application tare memory 1
T2	Application tare memory 2
D i f f	Difference from calibration value
N o m .	Exact calibration weight
n R e f	Reference sample quantity
p R e f	Reference percentage
w R e f	Reference sample weight
Q n t	Result from Counting (piece count) and Neutral Measurement applications
m D e f	Target value for Animal weighing
x - N e t	Result from Animal Weighing
S e t p	Target value for Checkweighing
W . D i f f	Absolute difference (e.g., in kg) in Checkweighing
L i m	Deviation in % in Checkweighing
M a x	Upper limit for Checkweighing
M i n	Lower limit for Checkweighing
S t a t	Status
C l a s s	Classification
L i m x	Class limit
D	Percentage (as loss)
P r c	Percentage (as residue)
W x x %	Reference percentage weight
C m p x x x	Component xxx
C o n t . T	Contents of the tare memory in Net-total Formulation
T o t . c p	Total weight in Net-total Formulation
P T 2	Preset tare
n	Transaction counter
* G	Sum of gross weights in Totalizing
* N	Sum of net weights in Totalizing
S e r . n o	Serial number of the platform or indicator

Automatic Data Output (SBI)

You can have results of measurement printed automatically¹⁾. You can configure the autoprint function to print at certain intervals (measured in display updates²⁾) and define whether printing is dependent on stability of the weighing instrument³⁾. How often the display is updated depends on the operating status and model of the equipment.

Examples:

N + 153.00 g Net weight
S t a t Display blank
S t a t L Display underload
S t a t H Display overload

Setting:

1) 3) Automatic output without stability

or

Automatic output with stability

Factory setting: Manual after stability;
 i.e., automatic data output function off.

2) Time-dependent automatic data output:

Intervals: 1, 2, 10 or 100 display updates

Factory setting: 1 display update

External Keyboard Functions (PC Keyboard)

Configure under:

Setup: Device parameters: Bar code: External keyboard

The key codes implemented here are specific to the German keyboard layout. The following alphanumeric characters are implemented (some require "Shift" key):

a - z, A - Z, 0 - 9, <space>, ", \ + ' <> / " \$ % & / (); = : _ ? *

Function key:

PC keyboard	Combiics 3
F1	→I← key
F2	→O← key
F3	→A← key
F4	F5 soft key (far left)
F5	F4 soft key (second from left)
F6	F3 soft key (middle)
F7	F2 soft key (second from right)
F8	F1 soft key (far right)
F9	→D← key
F10	→D← key, long (> 2 sec) ('Info' function)
F11	SETUP key
F12	Fn key
Print	→E← key
Return ↵	F1 soft key (far right)
Up arrow	F3 soft key (middle)
Left arrow	F4 soft key (second from left)
Down arrow	F2 soft key (second from right)
Right arrow	F1 soft key (far right)
Home	CF key
Backspace	CF soft key
ESC	CF soft key


¹⁾ depends on scale type; for example, not all units or characters are available on scales verified for use in legal metrology.




Data Input Format

You can connect a computer to your indicator to send commands controlling scale functions and applications via the interface port. All commands use the same format, starting with the ESC character (ASCII 27) and ending with a carriage return (CR; ASCII 13) and a line feed (LF; ASCII 10). The total length of a command is anywhere from 4 characters (1 command character between the start and end described above) to 7 characters (4 command characters).

The table below shows the available command characters; each command must be flanked by the start and end characters as described above.

Example: The command character for output is "P" ("output to Port"). To trigger this command, send the string: "ESC P CR LF".

Command	Meaning
K	Weighing mode 1
L	Weighing mode 2
M	Weighing mode 3
N	Weighing mode 4
O	Block all keys
P	Output readout to data interface
Q	Output acoustic signal
	Unblock keys
T	Tare and zero (combination tare function)
13_	Zero (see also the "kZE_" command)
14_	Tare without zeroing (see also the "kT_" command)
1_	Information about the indicator Example of output: "C13/012502/1" Meaning: Indicator: Combics 3, Software version: 012502, Active weighing platform: 1
kF1_	Trigger soft key F1 function
kF2_	Trigger soft key F2 function
kF3_	Trigger soft key F3 function
kF4_	Trigger soft key F4 function
kF5_	Trigger soft key F5 function
kP_	Trigger  key function Output to printer port

Command	Meaning
kT_	Trigger  key function (tare)
kNW_	Trigger  key function (Toggle the weighing platform)
kZE_	Trigger  key function (zero)
x1_	Output model designation of active weighing platform. Example: "LP6200S-OCE"
x2_	Output serial number of active weighing platform. Example: "0012345678"
x3_	Output software version of active weighing platform. Example: "00-20-05"
x4_	Output software version of indicator. Example: "01-26-01"
x9_	Output serial number of indicator. Example: "0012345678"
x10_	Output model of indicator. Example: "CIS3"
z1_	Activate input for printout header 1
z2_	Activate input for printout header 2

The ASCII code for the "underline" character ("_") is 95.

Format for entering printout header lines: ESC z x a ... a _ CR LF where x = (header line) 1 or 2; a...a = up to 20 characters of text, followed by the "underline" character, carriage return and line feed.

Synchronization

Data is communicated between the indicator and a computer in the form of messages ("telegrams") made up of ASCII code. For error-free data communication, the settings for baud rate, parity, handshake mode and character format must be the same at both ends.

You can configure the interface settings in the Setup menu so that they match those of the computer. You can also define parameters in the indicator to make data output dependent on various conditions. Details on conditional data output are provided in the "Basic Application Programs" manual for the Combics 3.

If you do not connect a peripheral device to the indicator's interface port, this will not generate an error message.

Handshake

The scale interface (Sartorius Balance Interface = SBI) has transmit and receive buffers. You can define the handshake parameter in the Setup menu:

- Hardware handshake (CTS/DTR)
- Software handshake (XON, XOFF)

Hardware Handshake

With a 4-wire interface, 1 more character can be transmitted after CTS ("clear to send").

Software Handshake

The software handshake is controlled via XON and XOFF. When a device switched on, XON must be transmitted to enable a connected device to communicate.

When the software handshake is configured in the Setup menu, the hardware handshake becomes active after the software handshake.

The data transmission sequence is as follows:

```

Scale    --- byte --->  Computer
(trans-  --- byte --->  (receiving
mitting  --- byte --->  device)
device)  --- byte --->
          <--- XOFF ---
          --- byte --->
          --- byte --->
          ...
          (Pause)
          ..
          <--- XON ---
          --- byte --->
          --- byte --->
          --- byte --->
          --- byte --->
  
```

Transmitting Device

Once XOFF has been received, it prevents further transmission of characters. When XON is received, it re-enables the transmitting device to send data.

Receiving Device


To prevent too many control commands from being received at one time, XON is not transmitted until the buffer is almost empty.

Pin Assignment Charts

Model CISL3 (IP44 Protection)

COM1 and COM2 female connectors:

25-contact D-Submini female connector (DB25S) with screw lock hardware



Front view


Male interface connector used (please use connectors with the same specifications):
25-pin D-Submini (DB25) with integrated shielded cable clamp assembly (Amp type 826 985-1C) and fastening screws (Amp type 164868-1)

Pin assignments COM1 (RS-232)

- Pin 1: Shield
- Pin 2: Data output (TxD)
- Pin 3: Data input (RxD)
- Pin 4: Not connected
- Pin 5: Clear to send (CTS)
- Pin 6: Internally connected
- Pin 7: Internal ground (GND)
- Pin 8: Internal ground (GND)
- Pin 9: Not connected
- Pin 10: Not connected
- Pin 11: +12 V for printer
- Pin 12: RES_OUT\
- Pin 13: +5 V
- Pin 14: Internal ground (GND)
- Pin 15: Universal switch
- Pin 16: Control output “lighter”
- Pin 17: Control output “equal”
- Pin 18: Control output “heavier”
- Pin 19: Control output “set”
- Pin 20: Data terminal ready (DTR)
- Pin 21: Supply ground (GND)
- Pin 22: Not connected
- Pin 23: Not connected
- Pin 24: Power supply +15...25 V (peripherals)
- Pin 25: +5 V

Model CIS3:

Terminals on the PCB




- Pin assignments, COM2: RS-232, RS-422 or RS-485 (optional UniCOM interface not installed)
Option A11: RS-232 factory set,
Option A12: RS-485 factory set,
RS-422: see “Setting the Interface Operating Mode for COM2” below for details on solder bridge coding.
- Pin 1: Shield
 - Pin 2: RS-232: Data output (TxD)
RS-422: Data output (TxD)
RS-485: Data + (TxD-RxD+)
 - Pin 3: RS-232: Data input (RxD),
RS-422: Data input + (RxD),
RS-485: Not connected
 - Pin 4: Internal ground (GND)
 - Pin 5: RS-232: Clear to send (CTS),
RS-422: Data input - (RxD-),
RS-485: Not connected
 - Pin 6: Internally connected
 - Pin 7: Internal ground (GND)
 - Pin 8: Not connected
 - Pin 9: Not connected
 - Pin 10: Not connected
 - Pin 11: +12 V for printer
 - Pin 12: RES_OUT\
 - Pin 13: +5 V switch
 - Pin 14: Internal ground (GND)
 - Pin 15: Keyboard data
 - Pin 16: Not connected
 - Pin 17: Not connected
 - Pin 18: Not connected
 - Pin 19: Keyboard clock
 - Pin 20: RS-232: Data terminal ready (DTR),
RS-422: Data output - (TxD-),
RS-485: Data - (TxD-RxD-)
 - Pin 21: LINE_1 _GND
 - Pin 22: LOW_BATT
 - Pin 23: BATT_ON_OFF
 - Pin 24: LINE_1_B
 - Pin 25: +5 V

Model CIS3 (IP67 Protection)

Connecting open cable ends to terminal screws inside the indicator


Com1 interface connection:



Top view

Terminal assignments

- No. 1: Universal switch
- No. 2: Control output “set”
- No. 3: Control output “heavier”
- No. 4: Control output “equal”
- No. 5: Control output “lighter”
- No. 6: Clear to send (CTS)
- No. 7: Data output (TxD)
- No. 8: Data input (RxD)
- No. 9: Data terminal ready (DTR)
- No. 10: Internal ground (GND)
- No. 11: LINE_A
- No. 12: LINE_A
- No. 13: GND_LINE_A
- No. 14: GND_LINE_A
- No. 15: +12 V for printer
- No. 16: Reset output
- No. 17: +5 V
- No. 18: +5 V
- No. 19: Ground (GND)
- No. 20: Ground (GND)



Connections in the CIS3

Diagram (on the left): top view

Terminal assignments in the 10-contact COM2 terminal strip:

	RS-232	RS-422	RS-485
No. 1:	Not connected	Not connected	Not connected
No. 2:	GND	GND	GND
No. 3:	GND	GND	GND
No. 4:	+5 V switch	+5 V switch	+5 V switch
No. 5:	Data terminal ready (DTR)	Data output - (TxD-)	Data - (TxD-RxD-)
No. 6:	Keyboard clock	Keyboard clock	Keyboard clock
No. 7:	Keyboard data	Keyboard data	Keyboard data
No. 8:	Clear to send (CTS)	Data input - RxD-	Not connected
No. 9:	Data input (RxD)	Data input + (RxD+)	Not connected
No. 10:	Data output (TxD)	Data output + (TxD+)	Data + (TxD-RxD+)

Terminal assignments in the 4-contact terminal strip on the left-hand side
(for rechargeable battery)

No. 1:	GND_LINE_B
No. 2:	LINE_B
No. 3:	LOW_BATT ¹⁾
No. 4:	BATT_ON_OFF ²⁾

Terminal assignments in the 4-contact terminal strip on the right-hand side
(for UniCOM interface)


	RS-232	RS-422	RS-485
No. 1:	Clear to send (CTS)	Data input - (RxD-)	Not connected
No. 2:	Data input (RxD)	Data input + (RxD+)	Not connected
No. 3:	Data output (TxD)	Data output + (TxD+)	Data + (TxD-RxD+)
No. 4:	Data terminal ready (DTR)	Data output - (TxD-)	Data - (TxD-RxD-)

	Profibus
No. 1:	Not connected
No. 2:	Not connected
No. 3:	Not connected
No. 4:	Not connected

¹⁾ The signal from the battery pack indicates that the battery is completely drained.


²⁾ Switches off the battery pack when the scale is switched off.

Setting the Interface Operating Mode for COM2



Coding for COM2 in Model CISL3

	RS-232	RS-422	RS-485
Solder bridge J2:	open	closed	closed
Solder bridge J9:	open	open	closed
Solder bridge J10:	open	open	closed



Coding for COM2 in Model CIS3

	RS-232	RS-422	RS-485
Solder bridge J2:	open	closed	closed
Terminals 5 and 8 on the 10-terminal COM2 strip:	open	open	closed
Terminals 9 and 10 on the 10-terminal COM2 strip:	open	open	closed

120-ohm terminal resistor for RS-422 and RS-485

	RS-422	RS-485
Solder bridge J4:	closed	closed


Bias resistors (for RS-485 only)

	RS-485
Solder bridge J5:	closed
Solder bridge J6:	closed

Connecting Cables to Interfaces


Cables should be connected by a certified technician who has received specialized training from Sartorius.

- Make sure to use the connecting cable with screw-lock hardware (see “Accessories”).
- △ Make sure to disconnect the equipment from power before connecting cables.
- △ Installation work that affects the IP67 protection rating must be performed with extreme care.
- △ Any installation work that does not conform to the instructions in this manual results in forfeiture of all claims under the manufacturer’s warranty.
- △ Always make sure the equipment is disconnected from power before performing any installation, maintenance or repair work.
- △ An IP67-protected cable gland for connecting a weighing platform is installed on the indicator at the factory. The other openings in the housing are sealed with protective caps. Please use extreme caution when performing any work on the equipment that affects this cable gland.





- Remove the four screws as indicated in the illustration and then remove the front panel from the indicator.

- Use the cable gland to connect the peripheral device to the indicator.
- △ The connecting cable is prepared at the factory for installation in the Combics indicator. The cable gland is already attached to the cable.
- △ Please use extreme caution when performing any work on the equipment that affects this cable gland. Use a torque wrench and tighten the cable gland to 5 Nm.




- Connecting the wires inside the indicator:
 - Remove the protective cap from the bore hole on the indicator. If the terminal screws for both COM1 and COM2 are already in use (terminals LV1, LV2 and LV3), use the bore hole in the middle of the rear indicator panel.
 - Guide the cable with the pre-installed cable gland through the bore hole.
 - Close and tighten the cable gland in accordance with the applicable regulations.
 - Make sure the shield is in contact with the clamps, because the cable is grounded by the shield.



- Connect the cable as follows:
 - Route the cable through the cable gland.
 - Close and tighten the cable gland in accordance with the applicable regulations.
 - Strip the casing from a section of the cable end (see illustration). The shielding (1) must have contact with the clamps (2).

- Expose approx. 15 cm (6 inches) of the individually isolated wires (3) for installation.
- Route the cable through the cable gland.
- Make sure the shield is in contact with the clamps, because the cable is grounded by the shield.



- Connecting the wires inside the indicator:
 - Expose approximately 5 cm (2 inches) of the isolated wires for installation.
 - Remove approximately 1 cm (1/2 inch) of the isolation from the wires and affix ferrules to the wire ends.
 - Connect the wires securely in accordance with the terminal assignments.
- After you close the housing again, use a pressure gauge to check the integrity of the IP67-protection. For details, contact the Sartorius Service Center.

Cabling Diagram (Adapter Cable for PC)


(CISL3 indicator: Adapter cable 7357312; CIS3 indicator: Adapter cable YCC02-D9F6).
Diagram for connecting a computer or other peripheral device to the indicator using the RS-232C/V24 standard and cables up to 15 m (50 ft.) long:

Cabling Diagrams

Connection assignments for the cable from the indicator to an RS-232 PC interface.


25-pin D-Sub male connector
(Model CISL3)

9-contact D-Sub female connector





Open cable end
(Model CIS3)

9-contact D-Sub female connector



Cabling Diagram (Adapter Cable for PC)



Cable type: AWG 24 specification

Service


Activating the Service Mode

Purpose

The Service mode allows access to an extended menu. This mode must be activated before you can perform calibration and adjustment work on the Combics and on any connected weighing platform.

When the Service mode is active, an “S” is shown on the right-hand side of the header line in the Setup menu. To deactivate the Service mode, restart the indicator (turn the indicator off and back on again).

Activating the Service Mode



Turn on the Combics

The weighing instrument is currently in an application mode (such as Weighing or, as in this example, Counting).

Enter the service password (see Appendix) and press **SETUP** to confirm.

Note:
The number shown in the illustration on the left is not the service password.




The device in now is Service mode. On the right-hand side of the Setup menu header line, an **S** is displayed.


In the Service mode, the Setup menu contains additional menu items that are not available in the user Setup mode; for example, the highest menu level now includes the option **Factory settings: all parameters**.

To view or change device parameters in Setup mode:
Select **Device parameters**

2x soft key ↵



Soft key ➤



Open the menu.

The **Device** submenu is opened.

Select the desired menu item from the next level and open the next submenu. Repeat this procedure until the desired menu item in the lowest menu level can be opened. Check the setting and change if necessary (press **↵** to confirm) and then press the **<** soft key (repeatedly, as needed) until the highest level of the Setup menu is reached.



Exiting the Service mode

Turn the Combics off and then on again. The scale is now in the normal application mode. If you exit the Setup menu without confirming changes by pressing the **SETUP** or **<<** soft key, the Service mode remains active. Press the **SETUP** key to open the Setup menu in Service mode again.

Service Menu

When the Service mode is activated, the service technician can access additional menu items that are not visible when the Service mode is deactivated.

The following advanced functions are available:

In the highest menu level, the last item is now:

- **Factory settings: all parameters**

In the **Device parameters** menu, the following items are added to the menu, below **Code**:

- **Service** (service date)
- **Memory number** (for a connected Alibi memory)
- **Terminal data** (serial number and model of the indicator)

The first item of the Device Parameters menu for "WP1 - Internal" is now:

- **ADC configuration.**

The **Calibration/adjustment** menu in the Device Parameters menu for "WP1 - Internal" now contains the following additional submenus:

- **Adjust without weights**
- **Geographical data.**

The **CAL key function** and **Activate ext. adj.** sub-menus of the "Calibration/Adjustment" menu also contain additional menu items.

If the COM1 or COM2 interface is configured for a second weighing platform, "WP2", the additions to the "Calibration/Adjustment" menu listed above for "WP1" apply to the "WP2" menu as well. Under certain conditions, the "ADC Configuration" menu is also available for WP2 (if a weighing platform suitable for this purpose is connected and a suitable transfer protocol is used).

In general, the software detects the parameters of the connected load cell(s). If the parameters of a given load cell cannot be detected or cannot be changed, the parameters in question might not be displayed. For example, in the "Calibration/Adjustment" menu, the "External calibration" item is not displayed if the connected weighing cell is not configured for use in legal metrology; in other words, if it does not have a "Legal metrology" data record.

A diagram of the menu tree for the Setup menu in Service mode is shown on the following pages. As mentioned above, which menu items are shown depends on the weighing platform(s) connected.

Note:

To configure the A/D converter and to enter or change parameters in the "Calibration/Adjustment" menu, set the menu access switch to the "Accessible" position. To do this, move the switch to the right (towards the interface connectors). For details, see "Configuring the Analog/Digital Converter" and "Calibration, Adjustment and Linearization" in this chapter, as well as the section entitled "Calibration and Adjustment" under "Operating the Combics."

Configuring the Analog/Digital Converter

Purpose

To adapt the Combics for use with any commercially available strain-gauge load cell or analog Sartorius CAPP, CAPS, IU or IF weighing platform by selecting or entering parameters in the Setup program. Access is restricted by a special password (service password).

Features

With the menu access switch open, you can configure most of the parameters affecting the following specifications:

- Toggle between "Standard" and "Verifiable" ("Legal for trade") mode (configuration for use in legal metrology)
- Verification scale interval e
- Scale interval d
- Minimum load
- Maximum load
- Maximum load for a given range
- Verification scale interval e for a given range
- Available weight units
- Weight unit for calibration/adjustment

These parameters are not affected when you restore the factory settings (menu item: **Factory settings: all parameters** on the highest level of the Setup menu.

Parameters not listed above are not affected by your choice of Standard or Trade configuration; the same restrictions apply as for Sartorius weighing instruments that do not offer a choice between the two configurations.

Note on Settings

The **ADC configuration** menu is opened from the Setup menu, under **Device parameters** (weighing platform 1: **WP1**; weighing platform 2: **COM1** or **COM2**, with suitable transfer protocol). The menu is shown on page 66. For details on opening the Setup menu, see "Configuring the Combics". The A/D converter can be configured only in the Service mode and only with the menu access switch open.

When you return to the highest level of the Setup menu by pressing the \leftarrow soft key repeatedly, you are prompted to save the configuration data. To save new or modified data, press the \rightarrow soft key; otherwise, press \leftarrow . press the $\leftarrow\leftarrow$ soft key to close the Setup menu in Service mode without saving changes.

Following A/D converter configuration and after saving data (menu item: **Save configuration data**), make sure you close the menu access switch and press ON to turn the Combiics off and then on again; otherwise, the display will not indicate the “overload” (H) or “underload” (L) states.

Select the weight unit for the maximum load in each weighing range of the weighing platform under **Weight unit 1**. Select a weight unit that allows configuration without decimal places, as these are truncated by the weighing platform’s rounding function. The maximum load for each range must be a value that can be displayed in any available weight unit with no more than 4 digits other than “0”.

If the weight unit required for configuration is not available, select the **Available units** item from the “ADC Configuration” menu. The “Weight unit 1” and “Weight unit 2” menus show only the weight units activated in the “Available Units” menu. The weight unit used during configuration cannot be blocked.

Checking and Configuring the Equipment for Use in Legal Metrology

The metrological data of the active weighing platform is shown in the two uppermost lines of the display (see also “Display Modes” in the chapter entitled “Operating Design”).

After completing the configuration and calibration/adjustment, close the menu access switch (move to the “blocked” position).

Open the “Weight unit 1” menu to make sure only the permitted weight units are accessible.

Descriptions of the Individual Menu Items

Standard/Verifiable: Select and load a configuration data record.

Before selecting the menu item for A/D converter configuration, check whether the weighing platform is used in the standard operating mode (“Standard” configuration) or in legal metrology (“Verifiable” configuration):

- Standard configuration, **Standard** or
- Verifiable configuration, **Verifiable**.

If the desired configuration is not already set (marked by \square) press the \wedge or \vee soft key to select the setting. Press the \rightarrow soft key to confirm the setting and open the “ADC Configuration” menu.

Accuracy Class

This menu item is not shown when the “Standard” configuration is active.

When the “Verifiable” configuration is active (for weighing platforms verified or verifiable for use in legal metrology), only **Class III/IIII** (accuracy class III/IIII) can be selected.

Activate the **Class** menu item (to select accuracy class III/IIII).

If the menu item is not already active (marked by an \square), press the \downarrow soft key to confirm. Press the \leftarrow soft key to exit the menu item.

Weighing Ranges

The capacity of the weighing platform can be divided into multiple ranges:

- **Single range mode**
The entire weighing range is divided into scale intervals on the basis of the lowest interval d and the maximum load. In this case, the readability over the entire weighing range is always the lowest scale interval d.
- **Multi-interval mode**
The “Multi-interval mode” function divides the weighing capacity into as many as four ranges, each with a different readability. When using the “Verifiable” configuration, this function is permitted only in accuracy classes III and IIII . The scale switches from one range to the next automatically, in accordance with the range limits specified. When the scale switches from a higher to a lower range, the higher resolution is set automatically. Once the scale has been tared, the highest possible resolution is available even if the weighing platform is loaded.

- Multiple range mode

A multiple-range scale has two or three weighing ranges. When the maximum capacity of a lower range is exceeded, the scale switches to a higher range (lower resolution) and remains in that range. The scale can be returned to the lower weighing range (higher resolution) only by pressing the ON key and then unloading the scale.

If the desired configuration is not already set (marked by \square), press the \wedge or \vee soft key to select the setting. Press the \rightarrow soft key to confirm the setting and open the next lower menu items, for scale interval d or verification scale interval e, minimum load (“Verifiable” configuration only) weighing range limits (multi-interval or multiple-range mode only) and maximum capacity. Use the numeric keys to change these settings as needed; press the \downarrow soft key to confirm each change or the **Eso** soft key to cancel. Press the \leftarrow soft key to return to the “Ranges” menu. Press the \leftarrow soft key to go from “Ranges” back to the “ADC Configuration” menu.

Scale Interval d (“Standard” Configuration Only)

The lowest scale interval d indicates the resolution of the weighing instrument. The scale interval d can be entered only in increments of 1, 2, 5, 10, 20, 50, etc.

Verification Scale Interval e (“Verifiable” Configuration Only)

The verification scale interval e indicates the resolution of the weighing instrument in legal metrology. The verification scale interval e can be entered only in increments of 1, 2, 5, 10, 20, 50, etc. For weighing instruments of accuracy class III or IIII , $e = d$. This is why the scale interval d does not need to be entered separately.

Minimum Load (Min. Load) (“Verifiable” Configuration Only)

The minimum load for weighing instruments of class III is 20 e; for class IIII it is 10 e.

Note: The function of the minimum load setting is to warn operators that below this limit, the summation of tolerances might lead to significant measurement errors. In Germany, for example, initial weights below the minimum load are not allowed.

Range 1, Range 2, Range 3

Here you can enter the limits for each of the weighing ranges. When a limit is exceeded, the accuracy changes. The following applies when entering range limits:

Range 1 ≤ range 2 ≤ range 3 ≤ maximum capacity.

Thus, you can divide the weighing capacity into four ranges.

The resolution changes in intervals of 1, 2, 5, 10, 20, 50, etc. The lowest resolution is equal to the specified lowest scale interval d. Set unused ranges to 0.

Maximum Capacity (Max. Cap.)

The maximum capacity is the maximum load that may be placed on the weighing instrument. If a heavier load is placed on the platform, the display shows H.

The scale intervals are calculated from the maximum capacity and the lowest scale interval d. In legal metrology, the number of intervals must not exceed 3000 e; for multi-interval scales, the limits is 3000 e per range. In Standard operation, as opposed to legal metrology, you can define a "SuperRange" weighing instrument with more intervals. For example, a maximum capacity of 30,000 kg with a lowest scale interval d of 0.001 yields 30,000 scale intervals. These parameters, however, may be influenced by physical restrictions.

Available Units

With this function, you can make particular weight units (Weight unit x; x=1, 2) inaccessible during weighing. Available units are indicated by a circle (○) on the display (more than one can be selected). To enable or disable a unit, select the unit by pressing the \rightarrow or \leftarrow soft key, and then press the \downarrow soft key (toggle function).

Calibration/Adjustment Unit

This setting defines the weight unit with which calibration must be performed. The calibration unit remains the same, even when a different weight unit is used during normal weighing operation. The selected weight unit is marked by a circle (○). To change the weight unit, select the desired unit by pressing the \rightarrow or \leftarrow soft key and press the \downarrow soft key to confirm.

Save Parameters

Select "Yes" by pressing the \rightarrow soft key and press \downarrow to confirm; the A/D converter configuration settings are stored. The device software is reset, and the scale returns to the normal weighing mode. The Service mode is deactivated. To exit the menu without saving configuration changes, press the \leftarrow soft key.

Once these parameters have been configured, the A/D converter in conjunction with the load cell(s) is defined as a weighing instrument. The A/D converter, in conjunction with the weighing platform, can now be used like any standard weighing platform.

In addition, the weight unit must be defined and the weighing platform adjusted (calibration, adjustment and linearization must be performed). For a detailed description of these procedures, see the chapter entitled "Calibration and Adjustment."

Adjust without Weights

Open this submenu from the "Calibration/Adjustment" menu (refer to the menu tree diagram on the previous pages).

Open the "Input parameters" submenu to enter the parameters for "Nominal load" (in kg; specification of the strain-gauge beam), "Resolution" (in kg) and "Sensitivity" (in mV/V; under "Sensitivity 1"). These values are converted to internal quantities. Once the A/D converter configuration data has been stored (by selecting the "Save parameters" menu item), these parameters can no longer be read. For weighing platforms with multiple load cells, you can either enter sensitivity of the other load cells individually ("Sensitivity 2" through "Sensitivity 4" for load cells 2 through 4), or enter the mean value of all sensitivities under "Sensitivity 1" (and enter "0" for "Sensitivity 2" through "Sensitivity 4"). Save the values entered for these parameters by selecting the "Save parameters" menu item.

Geographical Data

This is a submenu of the "Calibration/Adjustment" menu (see the menu tree diagram on the previous pages) and is described in detail in a separate section, starting on page 79.

⚠ Note:


After configuring the A/D converter and adjusting the weighing instrument (calibration, adjustment and linearization), return the menu access switch (17) to the "closed" position.

Once the A/D converter configuration has been locked (menu access switch closed), the indicator can no longer be used to influence weighing results. The scope of functions available in the weighing instrument is defined by the A/D converter. Weighing functions that can be activated include:

- Read weight values
- Tare the scale
- Calibration/adjustment
- Read tare value
- Save/delete tare input
- Zero the scale

Overview of the Setup Menu in Service Mode


o = Factory setting
x = User-defined setting



1) function will be made available in future

2) availability of menu items depends on the software and on the functionality of the connected weighing platform

3) menu item not available on scales verified for use in legal metrology



¹⁾ function will be made available in future


²⁾ availability of menu items depends on the software and on the functionality of the connected weighing platform

³⁾ menu item not available on scales verified for use in legal metrology

Setup Menu for A/D Converter Configuration

Access Setup in
Service mode

WP1 - WP1 - Internal -
ADC configuration



A/D Converter Configuration (Examples)

Example 1: Configuring the A/D Converter with a Weighing Platform Connected

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		
Config. printout		
Operating parameters		
Clock		
Password		
<<	<	>

Soft key ➤

if necessary: Soft key ⬆ | ⬇ soft key ➤

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt. filter			
Application filter			
Stability range			
Stability delay			
Autozero			
Weight unit 1			
Display accuracy 1			
Zero range			
<<	<	>	

Soft key ➤

WP 1	INTERNAL	ADC CONF.	S
Standard			
Verifiable			

Soft key ➤

INTERNAL	ADC CONF.	LEGAL	S
Accuracy class			
Ranges			
Available units			
Calibration/adjustment unit			
Save configuration data			

Soft key ➤

Preparation

(see also “Calibration and Adjustment” in the chapter entitled “Operating the CombiCS”)

- Remove the cap that covers the menu access switch on the left-hand side of the back of the indicator
- Move the menu access switch to the right (towards the interface connectors), (“Accessible”).
- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select weighing platform **WP 1**.

If the **Internal** setting is not already active (marked by ☒) , press the ⬆ or ⬇ soft key to select the setting and press ➤ to confirm. The message **Function active** is shown briefly in the first line of the display, after which the Setup menu for “WP1” - “Internal” is opened.

The Setup menu for the “WP1 - Internal” device parameters is displayed.

Open the **ADC configuration** menu.

Press the ⬆ or ⬇ soft key to select the desired data record; either **Standard** (for using the weighing platform in standard mode) or **Verifiable** (for using the weighing platform in legal metrology). In the example shown here, the data record for “Verifiable” configuration is selected. This setting is already active (marked by ☒). To change to the “Standard” configuration, press the ⬆ soft key to move the highlight bar upwards.

For details on menu navigation, see the chapter entitled “Operating Design” at the beginning of this manual.

Open the menu for configuring A/D converter parameters.

In this example, the menu for ADC configuration of a weighing platform for use in legal metrology is opened.

If the “Standard configuration” mode was selected in the previous step, the “Accuracy class” menu item is not shown.

Open the first menu item. In the “Standard configuration”, this is the **Ranges** item; in the “Verifiable” configuration, the first item is **Accuracy class**.

Note:

When the “Verifiable” configuration is active, always select the **Accuracy class** menu item first.

Select accuracy class ☒/III. If the **Class III/III** setting is not marked by the ☒ symbol, press the ⬇ soft key to activate it. The setting is now marked by the ☒ symbol.

Press the ⬅ soft key to exit the “Accuracy class” menu item.

If necessary: soft key ∇ , soft key \triangleright

ADC CONF.	LEGAL	RANGES	S
oSingle range mode			
Multi-interval mode			
Multiple range mode			

Soft key \triangleright

LEGAL	RANGES	SINGLE RG	S
E:		0.001 kg	
Min. cap:		0.010 kg	
Max. cap:		6.000 kg	

Select the **Ranges** menu item.

In the example shown here, **Single range mode** has been selected (marked by o).

To select a different weighing range configuration, proceed as follows:
Press the ∇ soft key to move the highlight bar downward (or, if necessary, press the \wedge soft key to move it upward) and open this submenu by pressing the \triangleright key (see below). The selected weighing range configuration is now active. When you return from the input menu for entering the weighing range parameters, the new range configuration is marked by a circle (o).

For details on configuring weighing ranges, see the section entitled “Descriptions of the Individual Menu Items” at the beginning of this chapter.

Open the menu for setting the parameters of the weighing range (“Single range mode”) or weighing ranges (“Multi-interval mode” or “Multiple range mode”).

In the example shown here, the A/D configuration is set with a “Verifiable” data record as a single-range scale.

You can enter or change the values for scale interval d (“Standard” configuration) or verification scale interval e (“Verifiable” configuration) minimum load (“Verifiable” configuration only), range limits (“Multi-interval” or “Multiple range” mode only) and maximum capacity here. The default values displayed depend on the data record loaded and might have to be changed.

Navigating in the Menu: Entering / Changing Parameters

(For details, see “Operating Design”)

- Move the highlight bar to the input field: press the ∇ or \wedge soft key. The selected input field is active.
- For numeric input: use the $\boxed{0}$... $\boxed{9}$ keys and the $\boxed{.}$ key (decimal point). For correction: press the \boxed{CF} key.
- Confirm numeric input: press the \downarrow soft key. If other parameters follow the one just entered, the highlight bar is automatically positioned on the next input field.
- Cancel numeric input: press the \boxed{ESC} soft key.
- To save the parameters as currently displayed and return to the next higher menu level, press the \triangleleft soft key.
- To exit the Setup menu and the Service mode, press the $\triangleleft\triangleleft$ soft key.

$\boxed{0}$ $\boxed{.}$ $\boxed{0}$ $\boxed{0}$ $\boxed{2}$

LEGAL	RANGES	SINGLE RG	S
E:		0.002 kg	
Min. cap:		0.020 kg	
Max. cap:		6.000 kg	

In the example shown here, a single-range scale in “Verifiable” configuration with a maximum capacity of 6.000 kg is modified; the verification scale interval e is changed from 0.001 kg to 0.002 kg, in accordance with the maximum permitted value of 3000 verification scale intervals. Press the \downarrow soft key to confirm the changed value. The highlight bar is automatically positioned on the field for minimum load (“Min. cap.”).

The following values apply for the minimum load (see also “Descriptions of the Individual Menu Items” at the beginning of this chapter):

- for class $\boxed{\text{III}}$: Min. cap. = 20 e
- for class $\boxed{\text{III}}$: Min. cap. = 10 e

When you change the verification scale interval e, the value for “Min. cap.” is automatically re-calculated (in this example, from 0.02 kg to 0.04 kg). In the example shown here, the minimum load for class $\boxed{\text{III}}$ would have to be changed to 0.040. To change this value manually, press $\boxed{0}$ $\boxed{.}$ $\boxed{0}$ $\boxed{4}$ $\boxed{0}$ and then press the \downarrow soft key to confirm. The highlight bar is automatically positioned on the “Max. cap.” field.

The value for the maximum capacity (= 6.000 kg) is not changed.

For this example, the input of parameters for a single-range scale in “Verifiable” configuration is now concluded. Press the \triangleleft soft key to return to the next higher menu level (see the next page, following the configuration example for “Multi-interval mode”).

LEGAL	RANGES	MULTI-INT.	S
E:		0.001 kg	
Min cap:	0.010 kg		
Range 1:	3.000 kg		
Range 2:	0.000 kg		
Range 3:	0.000 kg		
Max. cap:	6.000 kg		
<<	<	v	

The illustration on the left shows an example of the input menu opened when the range configuration defines a **Multi-interval scale**. The same is shown for a **Multiple range scale**.

This example shows the parameters for a scale in “Verifiable” configuration, with 2 weighing ranges and a maximum capacity of 6.000 kg:

- Range 1: 0 to 3.000 kg with $e_1 = 0.001$ kg
- Range 2: 3.002 kg to 6.000 kg with $e_2 = 0.002$ kg

Enter the verification scale interval for Range 1 in the **E** field. The minimum load for a class **(III)** scale must be set to 0.02 kg.

Return to the next higher menu level, **Ranges**.

If the original configuration has been changed (for example, from “Single range mode” to “Multi-interval mode” or “Multiple range mode”), the new setting is marked by a circle (○).

Return to the next higher menu level, **ADC configuration**.

Soft key <

Soft key <

INTERNAL	ADC CONF.	LEGAL	S
Accuracy class			
Ranges			
Available units			
Calibration/adjustment unit			
Save configuration data			

Soft key v; if necessary, soft key >

Select the **Available units** menu item.

ADC CONF.	LEGAL	UNITS	S
User-definable /o			
Grams /g		*	
Kilograms /kg		*	
Carats /ct			
Pounds /lb			
Ounces /oz			
Troy ounces /ozt			
Hong Kong taels /tlh			
Singapore taels /tls			
Taiwanese taels /tlt			
<<	<	^	v

This menu lets you enable or disable the weight units that can be selected for “Weight unit x” (x = 1, 2). For details, see “Descriptions of the Individual Menu Items” at the beginning of this chapter. In most cases, you will not need to change the default values stored in the configuration data record.

To disable (block) or enable a weight unit: press the **v** or **^** soft key to select the unit and press **↓** to confirm. If a weight unit had been available (marked by *), it is now blocked (the marking is removed); if it had been blocked (no marking), it is now available and marked by * (toggle function). The weight unit used for configuration of weighing ranges cannot be blocked.

Soft key <

Return to the next higher menu level, **ADC configuration**.

Soft key v; if necessary, soft key >

Select the **Calibration/adjustment unit** menu item.

This menu lets you set the weight unit for calibration and adjustment.

ADC CONF.	LEGAL	CAL UNIT	S
Grams /g			
Kilograms /kg			
Tons /t			

The current setting is marked by a circle (○). For details, see “Descriptions of the Individual Menu Items” at the beginning of this chapter. In most cases, you will not need to change the default values stored in the configuration data record.

The menu shows all weight units activated in the “Available units” menu. The currently active calibration weight unit is always displayed, regardless of whether it is activated in the “Available units” menu.







To change the calibration weight unit, press the **v** or **^** soft key to select the new unit and press the **↓** soft key to activate it. The activated weight unit is marked by a circle (○).

Soft key <

Return to the next higher menu level, **ADC configuration**.

Soft key v, soft key >

Select the **Save parameters** menu item.



The menu for saving the A/D converter configuration is displayed.

- To save the configuration data, press the \wedge soft key to move the highlight bar to "Yes" and press the \downarrow soft key to confirm. In the first line of the display, the message **Data stored** is shown briefly. The program then returns to the normal weighing mode. To return to the Service mode, you need to enter the Service password again.
- To exit without saving changes, press the \leftarrow soft key. The program returns to the next higher menu level.

If A/D converter configuration data was changed before you pressed the key to exit without saving, you are prompted to confirm when the menu returns to the "WP1 - Internal" menu level.

- Press the \rightarrow soft key if you wish to save changes at this point.
- Press the \leftarrow soft key to exit without saving changes.

If you save changes, the program continues as described above. Otherwise, the program returns to the "WP1 - Internal" level of the "Device Parameters" menu.

For details on calibration and adjustment, see "Calibration and Adjustment" in the chapter entitled "Operation," or refer to the service manual.

At the conclusion of A/D converter configuration, return the menu access switch from the "accessible" to the "blocked" position:

- If necessary, remove the cap that covers the menu access switch on the left-hand side of the back of the indicator.
- Move the menu access switch to the left ("blocked" position). See also "Calibration and Adjustment" in the chapter entitled "Operation," or refer to the service manual.
- Replace the protective cap over the menu access switch.

Restart the weighing instrument: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

The displays depicted in the next two illustrations on the left show data from a multi-interval configured as described above, or a similarly configured multiple-range scale.

If the A/D converter was configured with a "Verifiable" data record, the lines for display of metrological data (lines 1 and 2) show the data valid for use in legal metrology, if the menu access switch is closed. For details, see the section entitled "Checking and Configuring the Equipment for Use in Legal Metrology" in this chapter.

Example 2: A/D Converter Configuration with Load Cell(s) Connected: Calibration/Adjustment without Weights

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
Unicom		

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			

Soft key ➤

WP 1	INTERNAL	ADC CONF.	S
Standard			
oVerifiable			

Soft key ➤

INTERNAL	ADC CONF.	STANDARD	S
Ranges			
Available units			
Calibration/adjustment unit			
Save configuration data			

Soft key

ADC CONF.	STANDARD	RANGES	S
oSingle range mode			
Multi-interval mode			
Multiple range mode			

Soft key ➤

STANDARD	RANGES	SINGLE RG	S
D:		0.0005 kg	
Max. cap:		6.0000 kg	

0 . 0 0 2

Preparation

(see also “Calibration and Adjustment” in the chapter entitled “Operating the CombiCS”)

- Remove the cap that covers the menu access switch on the left-hand side of the back of the indicator
- Move the menu access switch to the right (towards the interface connectors); “accessible” position.
- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select weighing platform **WP 1**.

If the **Internal** setting is not already activated (marked by **o**), press the **▲** or **▼** soft key to select the setting and press **➤** to confirm. The message **Function active** is shown briefly in the first line of the display, after which the Setup menu for “WP1” – “Internal” is opened.

The Setup menu for the “WP1 – Internal” device parameters is displayed.

Open the **ADC configuration** menu.

This example illustrates the procedure for entering and saving the load cell parameters for a weighing platform. This is necessary only for a weighing platform that is used for Standard weighing (as opposed to legal metrology). If “standard” is not already marked by the highlight bar, press the **▲** soft key to select the **Standard** configuration data record. The illustration on the left shows the data from a weighing platform configured for use in legal metrology (“Verifiable” configuration, marked by **o**). When you press the **➤** soft key to open the “Standard” menu, the standard configuration is loaded. When you return to the WP1 – Internal level of the “Device Parameters” menu, The “Standard” configuration is already marked as active (**o**).

Open the menu for configuring A/D converter parameters with the “Standard” configuration.

Select the **Ranges** menu item.

In the example shown here, **Single range mode** has been selected (marked with **o**).

The “Multi-interval mode” and “Multiple range mode” are described in Example 1 and under “Descriptions of the Individual Menu Items” at the beginning of this chapter.

Open the menu for setting the parameters of the weighing range (“Single range mode”) or weighing ranges (“Multi-interval mode” or “Multiple range mode”).

In the example shown here, the A/D configuration is set with a “Standard” data record as a single-range scale.

Entering the scale interval, range limits (multiple-range or multi-interval scales only) and maximum capacity:

The default values displayed depend on the data record loaded and might have to be changed.

Navigating in the Menu: Entering / Changing Parameters

For details, see Example 1 above and the chapter entitled “Operating Design”.

In the example shown here, a single-range scale in “Standard” configuration with a maximum capacity of 6.000 kg is modified; the scale interval d is changed from 0.0005 kg (= 12,000 intervals) to 0.002 kg (= 3000 intervals). Press the **↓** soft key to confirm the new value. The highlight bar is automatically positioned on the field for “Max. cap.”

STANDARD	RANGES	SINGLE RG	S
D:	0.002	kg	
Max. cap:	6.000	kg	

“Max. cap.” field:

If necessary, change the default value and confirm the new value. The maximum capacity is usually less than the value to be entered in the “Adjust without weights” menu for the nominal capacity of the load cell(s), as load cells carry additional weight (e.g., a weighing platform). Further details are given at the end of this example, on the page after next.

In the example shown here the default value for the maximum capacity (= 6.000 kg) is not changed.

Soft key \leftarrow

Return to the next higher menu level, **Ranges**.

If the original configuration has been changed (for example, from “Single-range mode” to “Multi-interval mode” or “Multiple-range mode”), the new setting is marked by a circle (○).

Soft key \leftarrow

Return to the next higher menu level, **ADC configuration**.

INTERNAL	ADC CONF.	STANDARD	S
Ranges			
Available units			
Calibration/adjustment unit			
Save configuration data			

Soft key ∇ ; if necessary, soft key \rightarrow

Select the **Available units** menu item.

This menu lets you enable or disable the weight units that can be selected for “Weight unit x” (x = 1, 2). For details, see Example 1 above and “Descriptions of the Individual Menu Items” at the beginning of this chapter. In most cases, you will not need to change the default values stored in the configuration data record. Return to the next higher menu level, **ADC configuration**, by pressing the \leftarrow soft key.

Soft key ∇ ; if necessary, soft key \rightarrow

Select the **Calibration/adjustment unit** menu item.

This menu lets you set the weight unit for calibration and adjustment. For details, see Example 1 above and the “Descriptions of the Individual Menu Items” at the beginning of this chapter. In most cases, you will not need to change the data record default values stored in the configuration data record. Return to the next higher menu level, **ADC configuration**, by pressing the \leftarrow soft key.

Soft key ∇ , soft key \rightarrow

Select the **Save parameters** menu item.

ADC CONF.	STANDARD	SAVE	S
Yes			
No			

The menu for saving the A/D converter configuration is displayed.

- To save the configuration data, press the ∇ soft key to move the highlight bar to “Yes” and press the \rightarrow soft key to confirm. In the first line of the display, the message **Data stored** is shown briefly. The program then returns to the normal weighing mode. To return to the Service mode, you need to enter the Service password again.
- To exit without saving changes, press the \leftarrow soft key. The program returns to the next higher menu level.

If A/D converter configuration data was changed before you pressed the key to exit without saving, you are prompted to confirm when the menu returns to the “WP1 - Internal” level of the “Device Parameters” menu.

Data stored	S

- Press the \rightarrow soft key if you wish to save changes at this point.
- Press the \leftarrow soft key to exit without saving changes.

If you save changes, the program continues as described above. Otherwise, the program returns to the “WP1 - Internal” level of the “Device Parameters” menu.



WP1: Max	6 kg	d=	2 g	
0%				100%
◆				
○				
	0.000		kg	
ID				

Restart the weighing instrument: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			

Soft key ∇ , soft key \triangleright
5x soft key ∇

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
isoCAL function			
Activate ext. adj.			
Parameter for external weight			
Adjust without weights			
Geographical data			
<<	<	^	v
			>

Soft key \triangleright

INTERNAL	CAL./ADJ.	ADJ.W/O WT	S
Input parameters			
Save parameters			

Soft key \triangleright

CAL./ADJ.	ADJ.W/O WT	PARAMETERS	S
Nominal load:			
Resolution:			
Sensitivity 1:			
Sensitivity 2:			
Sensitivity 3:			
Sensitivity 4:			

1 0 . 0 0

Soft key ∇

0 . 0 0 2

Soft key ∇

Setup menu for the “WP1 - Internal” level of the “Device Parameters” menu (for details, see the first segments of Examples 1 and 2).

Open the Calibration/adjustment menu.
Select the Adjust without weights menu.

Open the Adjust without weights menu.

Open the menu for setting the parameters of the load cell(s).

Enter the nominal capacity and resolution of the load cells in kg and the sensitivity of the load cell(s) in mV/V in the corresponding input fields.

Navigating in the Menu: Entering / Changing Parameters

For details, see Example 1 above and the chapter entitled “Operating Design”.

- Enter the nominal capacity of the load cell(s) in kg (usually listed in the specification sheets). The nominal capacity is generally greater than the value entered in the A/D converter configuration menu under “Max. cap.”, because the weighing platform in some cases carries additional equipment. If the weighing platform has multiple load cells, multiply the nominal capacity accordingly.
Example: The weighing platform consists of 4 load cells, each of which has a capacity of 50 kg. In this case, the nominal capacity is $4 \times 50 = 200$ kg.

In the example shown here, the weighing platform consists of one load cell with a maximum capacity of 10 kg.

Confirm the value entered. The highlight bar is automatically positioned on the field for “Resolution.”

- Enter the resolution (lowest scale interval d) in the weight unit “kg”. This value must be the same as that entered in the A/D converter configuration menu under “D:”.

Enter the resolution of the weighing platform in kg (in this example, 0.002 kg).

Confirm the value entered. The highlight bar is automatically positioned on the field for “Sensitivity 1”.

- Enter the sensitivity of the load cell in mV/V (usually listed in the load cell specification sheets). If a weighing platform consists of more than one load cell, enter the sensitivity of load cell 1 or the mean value of the sensitivities of all load cells. Range of permitted values: $0.0100000 \leq \text{sensitivity} \leq 5.0000000$ mV/V.

If a weighing platform consists of more than one load cell, enter the sensitivity of the other load cells (up to 4 load cells) in the fields “Sensitivity 2” (for load cell 2) through “Sensitivity 4” (for load cell 4), unless you entered the mean value for all load cells under “Sensitivity 1” (see above). In the latter case, or if fewer than 4 load cells are present, enter “0.000” in the corresponding fields.

1 . 9 4 4

Soft key ↵

CAL./ADJ. ADJ.W/O WT PARAMETERS S	
Nominal load:	10.00 kg
Resolution:	0.002 kg
Sensitivity 1:	1.9440000
Sensitivity 2:	0.0000000
Sensitivity 3:	0.0000000
Sensitivity 4:	0.0000000

Soft key <

Soft key ↵, soft key >

CAL./ADJ. ADJ.W/O WT SAVE S	
Yes	
No	


Soft key <

Soft key <

Soft key <

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			

<< or SETUP



I/O I/O

WP1: Max		6 kg	d=	2 g
0%		100%		
0.000		kg		
ID				

Enter the sensitivity of the load cell (in this example, 1.9440 mV/V).

Confirm the value entered. The highlight bar is automatically positioned on the field for "Sensitivity 2".

- If the weighing platform consists of multiple load cells and the mean value was not entered under "Sensitivity 1": Enter the sensitivity of the other load cells under "Sensitivity 2" through "Sensitivity 4".
- Input fields with no sensitivity values must contain "0.0000000".

Return to the **Adjust without weights** menu level.

Select the **Save parameters** menu item.

The menu for saving the load cell parameters is displayed.

- To save the configuration data, press the < soft key to move the highlight bar to "Yes" and press the ↵ soft key to confirm. In the first line of the display, the message **Data stored** is shown briefly. Afterwards, the program returns to the "o No" (Do not save data) display.

Return to the **Adjust without weights** menu level.

Return to the **Calibration/adjustment** menu level.

Return to the "WP1 - Internal" level of the Setup menu.

Set/clear preload: see the corresponding section in the following pages. See also "Calibration and Adjustment" in the chapter entitled "Operation," or refer to the service manual.

Return to the normal weighing mode.

At the conclusion of A/D converter configuration, return the menu access switch from the "accessible" to the "blocked" position:

- If necessary, remove the cap that covers the menu access switch on the left-hand side of the back of the indicator.
- Move the menu access switch to the left ("blocked" position). See also "Calibration and Adjustment" in the chapter entitled "Operation" or refer to the service manual.
- Replace the protective cap over the menu access switch.

Restart the weighing instrument: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Entering Geographical Latitude, Elevation and Gravitational Acceleration

Purpose

To perform external calibration/adjustment on the weighing instrument at a location other than the place of installation.

The sensitivity of a weighing instrument is directly affected by gravitational acceleration, which in turn is dependent on geographical latitude and elevation. Thus when a weighing instrument is moved from its place of installation and used in another location, its sensitivity is altered. In general, gravitational acceleration increases in the direction of the poles (i.e., with increasing degree of latitude) and decreases with increasing distance from the center of the earth (i.e., with increasing elevation).

If precise data concerning the place of installation of the weighing instrument is known; i.e., the geographical latitude in degrees (north or south) and elevation in meters above sea level, then the instrument can be adjusted at the factory for its intended place of installation, provided that the same data for the place of adjustment (i.e., at the factory) is known. Rather than geographical latitude and local elevation, it is sufficient to know the gravitational acceleration at the places of adjustment and installation.

The following data, describing the place of manufacture (Sartorius in Goettingen, Weender Landstrasse 94-108) is used as reference data:

- Geographical latitude:
51° 32' = 51.53 degrees
- Elevation: 151 m
- Gravitational acceleration:
9.811590 m/s²

If this reference data is stored in the indicator, the adjustment factor does not need to be corrected for the place of installation.

After the menu access switch is closed, the geographical data is stored in the A/D converter.

The adjustment applies for the place of location including a specific tolerance zone. For example, the tolerance zones for a scale with 3000 e are ± 100 km for the latitude and ± 200 m for the elevation above sea level.

The following exception applies in Germany for scales with 3000 e:

The scale can be used in legal metrology anywhere in Germany ("Zone D") if the geographical data is as follows:

- Geographical latitude:
51.00 degrees
- Elevation: 513 m
This data corresponds to the following value:
- Gravitational acceleration: 9.810 m/s²

These values are calculated for Germany based on a mean value for the Earth's acceleration. The greater the precision of the geographical data entered, the greater the precision achieved with the weighing instrument; the tolerance range, however, is restricted accordingly (see above.)

Procedure

The geographical data stored in the indicator at the factory applies to Germany ("Zone D") (see above).

Before adjusting the complete weighing system, make sure the geographical reference data stored in the indicator matches the values for the place of adjustment (whether at the factory or at the place of installation). If the values do not match, enter the latitude and elevation (or the gravitational acceleration) in the corresponding input fields of the "Geographical Data" menu, which is a submenu of the "Calibration/Adjustment" menu, under "Device Parameters." Then adjust the scale. If the place of adjustment is not the same as the place of use, enter the data that defines the place of use. Following adjustment, close the menu access switch. The scale can now be used at the place of installation, or anywhere within a tolerance zone (see above) around the place of installation. If the scale is installed in Germany, you can enter the data for "Zone D" (51.00 degrees, 513 m above sea level). In this case, the scale can be used anywhere within Germany. This setting is recommended for weighing equipment dealers, who thus do not need to know the exact geographical data when delivering to customers in Germany.

If a service technician performs a span adjustment (for example, after one or more load cells have been replaced), it is conducted without changing the values stored in the "Geographical Data" menu. For this adjustment, either the geographical latitude ("Latitude") and elevation ("Altitude") or the gravitational acceleration ("Gravit. acc.") for the place of installation must be entered. This data can be obtained from the relevant land registry or Ordnance Survey.

The geographical data cannot be edited unless the menu access switch is open. If the indicator is part of a verified weighing system, the verification seal must be broken to change this data. Afterwards, the scale must be re-verified.

If the gravitational acceleration has been entered, then this value takes precedence over the geographical latitude and the elevation. In this case, the input fields for latitude and elevation show the values "99999.99" and "9999999," respectively, when you open the input menu. In the converse case; i.e., if the values for geographical latitude and local elevation were entered, these values are shown when you open this menu. In both cases, the value for gravitational acceleration is displayed as "0.000000."

To display geographical data during the adjustment procedure, select "Display geogr. data: Yes" in the "Device Parameters" menu. The factory default setting for this item is "No." When the setting is "Yes," the indicator shows which data (geographical latitude and elevation, or gravitational acceleration) is used. Press $\rightarrow \text{I} \leftarrow$ to confirm the data. If necessary (for example, if the geographical data does not apply for the current place of adjustment), press $\rightarrow 0 \leftarrow$ to cancel the calibration procedure.

When the display of geographical data is active, the calibration procedure is as follows:

When the calibration procedure is started (CAL), the display shows **Altitude** for 2 seconds (if latitude and elevation are used), followed by the configured value (indicating meters above sea level).

Press **→T←** to confirm the data, or **→0←** to cancel the adjustment routine. Next, the display shows **Latitude** for 2 seconds, followed by the value set for the geographical

latitude (in degrees).

Again, press **→T←** to confirm the data or **→0←** to cancel the adjustment routine.

The calibration weight is now prompted. If the gravitational acceleration is given rather than the latitude and elevation, the display shows **CAL** and then **Gravity** (for 2 seconds), followed by the value entered for the local gravitational acceleration. Press **→T←** to confirm or **→0←** to cancel.

Example: Entering Geographical Data and Performing External Calibration

Preparation

(see also “Calibration and Adjustment” in the chapter entitled “Operation”)

- Remove the cap that covers the menu access switch on the left-hand side of the back of the indicator
- Move the menu access switch to the right (towards the interface connectors); “accessible” position.
- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select weighing platform **WP 1**.

If the **Internal** setting is not already activated (marked by **○**), press the **∧** or **∨** soft key to select the setting and press **→** to confirm. The message **Function active** is shown briefly in the first line of the display, after which the Setup menu for “WP1” - “Internal” is opened.

The Setup menu for the “WP1 - Internal” device parameters is displayed.

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		
Config. printout		
Operating parameters		
Clock		
Password		
<<	<	>

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			
Autozero			
Weight unit 1			
Display accuracy 1			
Zero range			
<<	<	>	

Soft key **∨**, soft key **→**

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
isoCAL function			
Activate ext. adj.			
Parameter for external weight			
Adjust without weights			
Geographical data			
<<	<	>	

5× soft key **∨**, soft key **→**

INTERNAL	CAL./ADJ.	GEOGR. DATA	S
Input parameters			
Save parameters			
<<	<	>	

Soft key **→**

Open the **Calibration/adjustment** menu.

Open the **Geographical data** menu.

Open the **Input parameters** menu.

CAL./ADJ. GEOGR. DATA PARAMETERS S				
Latitude:		51.53		
Altitude:		151		
Gravit. acc.:		0.000000		
<div> <div><<</div> <div><</div> <div></div> <div>></div> <div>>></div> </div>				

CAL./ADJ. GEOGR. DATA PARAMETERS S				
Latitude:		99999.99		
Altitude:		9999999		
Gravit. acc.:		0.000000		
<div> <div><<</div> <div><</div> <div></div> <div>></div> <div>>></div> </div>				

The illustration on the left shows an example in which the currently valid parameters for the weighing platform have been entered under "Latitude" and "Altitude." After this data was saved and the scale returned to weighing mode, this pair of values is displayed again the next time the input menu is opened. The input field for gravitational acceleration is empty (display shows "0.000000").

The next illustration shows an example in which the currently valid geographical parameters for the weighing platform have been entered as the gravitational acceleration at the place of installation. The input fields for "Latitude" and "Altitude" are empty (display shows "99999.99" and "9999999"). After the value for gravitational acceleration has been saved and the scale has returned to normal weighing mode, the value for gravitational acceleration is not shown the next time the input menu is opened. The input field for this value is empty (display shows "0.000000"). To view the configured value, open the "Info" menu for the weighing platform in question.

Changing geographical parameters:

Press the Δ or ∇ soft key to select the desired input field, enter the value using the numeric keys and press the \downarrow soft key to confirm. The highlight bar is automatically positioned on the next input field. Enter the latitude at the place of installation as a positive decimal number (convert angular minutes to decimal places).

Navigating in the Menu: Entering / Changing Parameters: for details, see Example 1 above and the chapter entitled "Operating Design."

- Entering or changing values for latitude / altitude: Enter the new values in the corresponding input fields. Observe the ranges for permissible parameters:
Latitude in degrees (north or south): $0.00 \leq \text{latitude} \leq 90.00$
Altitude in meters above sea level: $-10000 \leq \text{altitude} \leq +10000$.

CAL./ADJ. GEOGR. DATA PARAMETERS S				
Latitude:		51.00		
Altitude:		513		
Gravit. acc.:		0.000000		
<div> <div><<</div> <div><</div> <div></div> <div>></div> <div>>></div> </div>				

The illustration on the left shows the "Latitude" and "Altitude" for the setting "Germany (Zone D)." With this setting, the weighing instrument can be used anywhere in Germany.

Entering or changing the gravitational acceleration: Enter the new value in the "Gravit. acc." input field.

Range of permitted values: $9.700000 \leq \text{gravitational acceleration in m/s}^2 \leq 9.900000$

If all three input fields contain valid data, the value for gravitational acceleration at the place of installation takes precedence over the values for "Latitude" and "Altitude."

CAL./ADJ. GEOGR. DATA PARAMETERS S				
Latitude:		99999.99		
Altitude:		9999999		
Gravit. acc.:		9.810000		
<div> <div><<</div> <div><</div> <div></div> <div>></div> <div>>></div> </div>				

In the example shown here, the value for gravitational acceleration has been changed. The new value, 9.810000 m/s^2 applies for the setting "Germany (Zone D)." With this setting, the weighing instrument can be used anywhere in Germany.

Soft key Δ

Soft key ∇ , soft key \rightarrow

CAL./ADJ. GEOGR. DATA SAVE S				
Yes				
oNo				
<div> <div><<</div> <div><</div> <div></div> <div>></div> <div>>></div> </div>				

Return to the next higher menu level.





Select the **Save parameters** menu item.

- Save the geographical data: press the Δ soft key to move the highlight bar to "Yes" and press the \downarrow soft key to confirm. In the first line of the display, the message **Data stored** is shown briefly. Afterwards, the program returns to the display showing "o No" (Do not save data).

Soft key <

Soft key <

Soft key <



Return to the **Geographical Data** menu level.

Return to the **Calibration/adjustment** menu level.

Return to the “WP1 - Internal” level of the Setup menu.

Return to the normal weighing mode.

Restart the weighing instrument: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Calibration and Adjustment

(for more details, see “Calibration and Adjustment” in the chapter entitled “Operation”)

Settings:


- Open the “Device Parameters” menu for the weighing platform (e.g., “WP1 - Internal”), and open the “Calibration/Adjustment” submenu.
 - Menu item “CAL key function”: setting “Ext. cal./adjust.: factory-defined weight” (factory setting).
 - Menu item “Cal./adj. sequence”: setting: “Cal. then manual adj.” (factory setting).
 - Menu item “Activate ext. adj.” (not for “Verifiable” configuration): setting: “Activated” (factory setting).
 - For display of geographical data:
In the “Device Parameters” menu, open the “Operating Parameters” submenu.
Menu item: “Display geogr. data”: setting: “Yes”.

Unload and zero the scale.

Start external calibration/adjustment.

CAL is shown for two seconds.

Example: The “Elevation” and “Latitude” parameters have been entered (menu: “Calibration/Adjustment” - “Geographical Data” - “Input Parameters”).




The display shows **Altitud** for 2 seconds.




The elevation at the place of installation is displayed in meters above sea level. In the example shown here, the elevation setting for “Germany (Zone D)” is displayed.



Confirm the displayed value or press **→←** to cancel the calibration procedure.




The display shows **Latitud** for 2 seconds.




The geographical latitude of the place of installation is shown in degrees north or degrees south. In the example shown here, the latitude setting for “Germany (Zone D)” is displayed.








Confirm the displayed value or press **→←** to cancel the calibration procedure.



You are prompted to place the required weight on the platform (e.g., 5.0 kg). The subsequent steps for completing the calibration/adjustment are described in the chapter entitled “Operation,” under “Calibration and Adjustment.”



In place of **Altitud** and **Latitud**, **Gravity** is displayed for 2 seconds if the gravitational acceleration was entered rather than the elevation and geographical latitude (menu: “Calibration/Adjustment” - “Geographical Data” - “Input Parameters”).



The value entered for the gravitational acceleration at the place of installation is displayed in m/s^2 .

In the example shown here, the gravitational acceleration for the setting “Germany (Zone D)” is displayed.

Confirm the value displayed for gravitational acceleration, or cancel the calibration procedure. Press $\rightarrow 0 \leftarrow$ to cancel.

You are prompted to place the required weight on the platform (e.g., 5.0 kg). The subsequent steps for completing the calibration/adjustment are described in the chapter entitled “Operation,” under “Calibration and Adjustment.”

At the conclusion of A/D converter configuration, return the menu access switch from the “accessible” to the “blocked” position:

- If necessary, remove the cap that covers the menu access switch on the left-hand side of the back of the indicator.
- Move the menu access switch to the left (“blocked” position). See also “Calibration and Adjustment” in the chapter entitled “Operation,” or refer to the service manual.
- Replace the protective cap over the menu access switch.

Restart the weighing instrument: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

If the A/D converter was configured with a “Verifiable” data record, the lines for display of metrological data (lines 1 and 2) show the data valid for use in legal metrology, if the menu access switch is closed. For details, see the section entitled “Checking and Configuring the Equipment for Use in Legal Metrology” in this chapter.

Calibration/Adjustment, Linearization, Setting and Clearing the Preload

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		

Soft key \rightarrow

If nec.: soft key \wedge | \vee , soft key \rightarrow

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			

Soft key \vee , soft key \rightarrow

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
isoCAL function			
Parameter for external weight			
Adjust without weights			
Geographical data			

3 x soft key \vee , soft key \rightarrow

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt.:	5.000 kg		
Lin. wt.1:	2.000 kg		
Lin. wt.2:	4.000 kg		
Lin. wt.3:	0.000 kg		
Lin. wt.4:	6.000 kg		

6	.	0	0	0
---	---	---	---	---

Soft key \downarrow

Entering Calibration and Linearization Weights

Preparation

(See also “Calibration and Adjustment” in the chapter entitled “Operation.”)

- Remove the cap that covers the menu access switch on the left-hand side of the back of the indicator housing.
- Move the menu access switch to the right (towards the interface connectors); into the “Accessible” position.
- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select the desired weighing platform (in this example: **WP 1**).

If the **Internal** setting is not already activated (marked by \square), press the \wedge or \vee soft key to select the setting and press \rightarrow to confirm. The message **Function active** is shown briefly in the first line of the display, after which the Setup menu for “WP 1 - Internal” is opened.

The Setup menu for the “WP 1 - Internal” device parameters is displayed.

Open the **Calibration/adjustment** menu.

Open the **External weight** menu.

The first menu item, “Cal/Adjust-Wt.” (for selecting the user-defined calibration weight), is also accessible without activating the Service mode. The menu items for selecting linearization weights “Lin. wt.1” through “Lin. wt.4”, however, can be selected only after the Service mode has been activated.

The current values for the user-defined calibration weight and the 4 linearization weights are displayed. You can confirm or change these values.

Navigation and Input

For details, see Example 1 under “Configuring the Analog/Digital Converter” above, and the chapter entitled “Operating Design.”

In the example shown here, the value for the external user-defined calibration weight has been changed to 6.000 kg. Press the \downarrow soft key to confirm the new value. The highlight bar is automatically positioned in the field for entering the first linearization weight (“Lin. wt.1”).

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt.:	6.000	kg	
Lin. wt.1:	2.000	kg	
Lin. wt.2:	4.000	kg	
Lin. wt.3:	0.000	kg	
Lin. wt.4:	6.000	kg	

Changing linearization weight 1:

1 . 5 0 0

Soft key \downarrow

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt.:	6.000	kg	
Lin. wt.1:	1.500	kg	
Lin. wt.2:	0.000	kg	
Lin. wt.3:	6.000	kg	
Lin. wt.4:	2.000	kg	

Enter or change up to four linearization weights in sequence as needed.

If you do not require all four linearization positions, enter "0.000" in the unused fields to blank these lines in the display. The highlight bar is automatically positioned in the next input field after you enter each value. When you close the menu by pressing \leftarrow , the new or changed values are stored.

INTERNAL	CAL./ADJ.	EXT.WEIGHT	S
Cal/adj. wt.:	6.000	kg	
Lin. wt.1:	1.500	kg	
Lin. wt.2:	3.000	kg	
Lin. wt.3:	4.500	kg	
Lin. wt.4:	6.000	kg	

In the example shown here, four linearization weights have been entered (1.5 kg, 3.0 kg, 4.5 kg and 6.0 kg).

Soft key \leftarrow

Return to the next higher menu level and store values entered.

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
isoCAL function			
Parameter for external weight			
Adjust without weights			
Geographical data			

Calibration/Adjustment and Linearization Functions

Settings

- Open the "Device Parameters" menu for the weighing platform (e.g., "WP 1 - Internal") and open the "Calibration/Adjustment" submenu.
 - Menu item "Cal./adj. sequence": setting "Cal. then manual adj." (factory setting).
 - Menu item "Activate ext. adj." (not for "Verifiable" configuration): setting "Activated" (factory setting).
 - Geographical data is not displayed during calibration/adjustment (factory setting).

To activate display of geographical data: Menu path "Device Parameters > Operating parameters > Display geogr. data": setting "On" (factory setting: "Off"). For details on performing calibration/adjustment procedure with the geographical data displayed, please see "Entering Geographical Data" above.

Preparation

(See also "Calibration and Adjustment" in the chapter entitled "Operation" and refer to the service manual for CombiCS Complete Scales and Indicators.)

- Remove the cap that covers the menu access switch on the left-hand side of the back of the indicator housing.
- Move the menu access switch to the right (towards the interface connectors); into the "Accessible" position.
- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select the desired weighing platform (in this example: **WP 1**).

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		

If the **Internal** setting is not already activated (marked by \square), press the \uparrow or \downarrow soft key to select the setting and press \rightarrow to confirm. The message **Function active** is shown briefly in the first line of the display, after which the Setup menu for "WP 1 - Internal" is opened.

Soft key \rightarrow

If nec.: soft key \wedge | \vee , soft key \rightarrow

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			



Soft key \vee , soft key \rightarrow

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
isoCAL function			
Parameter for external weight			
Adjust without weights			
Geographical data			

Soft key \rightarrow

INTERNAL	CAL./ADJ.	CAL KEY	S
Ext. cal./adj.: factory-def. wt.			
Ext. cal./adj.: user-defined wt.			
Ext. lineariz.: user-def. wts			
Set preload			
Delete preload			
Key blocked			

If nec.: Soft key \wedge , soft key \downarrow

					
WP1: Max 6 kg d= 2 g					
0% 100%					
0.000 kg					
ID					

The Setup menu for the “WP 1 - Internal” device parameters is displayed.

Open the **Calibration/adjustment** menu.

The “Calibration/adjustment” submenu for the selected weighing platform (in this example, “WP 1 - Internal”) is displayed.

Open the **CAL key function** submenu.

The “CAL Key Function” submenu is displayed.

Important Note:

Which functions can be configured in the “CAL Key Function” submenu depends on the selected weighing platform and its configuration data. Functions that cannot be activated are not displayed in the selection list (in this example, the “Ext. lineariz.; factory-def. wt.” function).

Important Note:

When you press the CAL key to perform the calibration/adjustment function you have defined here, the function will be carried out in the normal weighing mode (the display shows **CAL**), because the Service mode is deactivated when you exit the Setup menu. To perform the function on a digital weighing platform (such as an IS platform), however, it must be carried out in Service mode. The procedure for this is as follows: after selecting the desired function in the “CAL Key Function” menu and exiting the Setup menu, reactivate the Service mode again and then exit the Setup menu immediately by pressing **SETUP** or the $\leftarrow \leftarrow$ soft key.

The weighing instrument is now in Service mode, even though this is not indicated on the display. Press and hold the $\rightarrow \rightarrow$ key at least 2 seconds to activate the selected calibration/adjustment function. The display shows **S-CAL**, indicating that the scale is in Service mode. If you cancel the function by pressing $\rightarrow 0 \rightarrow$, or restart the scale by pressing $\rightarrow 0 \rightarrow$, the Service mode is deactivated.

External Calibration/Adjustment with Factory-Defined Weight (Default Weight)

If not already selected (factory setting, marked by \odot when active), select menu item **Ext. cal./adjust.: factory-defined cal weight** (external calibration/adjustment with the weight value configured at the factory). To do this, press the \wedge soft key (repeatedly if necessary) to highlight this menu item and press the \downarrow soft key to confirm. The menu item is marked by a circle (\odot).


Important Note:

The menu items “Ext. cal./adjust.: factory-defined cal wt.” (external calibration/adjustment using the weight value defined at the factory – default weight), “Ext. cal./adjust.: user-defined weight” (external calibration/adjustment with a user-defined weight) and “Cal key blocked” are also accessible without activating the Service mode.




Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.


If nec.: →0←



→T← (> 2 sec)



→T←



Unload and zero the scale.

Start external calibration/adjustment.

This display is shown for 2 seconds.

Important Note:

If the display of geographical data (elevation and latitude or gravitational acceleration) is activated (see “Settings” at the beginning of this section), this data is displayed; press →T← to confirm each value (to cancel the calibration/adjustment procedure, press →0←). For details, see “Entering Geographical Data” above.

The nominal value of the required calibration weight (in this example, 5.000 kg) is shown as a negative value on the display.

- Place the required weight on the scale.

Important Note:

If the calibration/adjustment sequence is set to “Cal then auto adjust,” (menu path “Calibration/adjustment > Cal./adj. sequence > Cal. then auto adj.”; see “Settings” at the beginning of this section) and the calibration weight consists of more than one weight, apply the weights to the scale in series at short intervals. **When the weighing instrument has stabilized, the weight on the scale is accepted as the calibration weight after a predefined interval, and the weighing instrument is calibrated/adjusted with this weight.** The difference since the most recent span adjustment is not displayed; this value is output only on GMP-compliant printouts (see next page).

After a brief pause, the difference since the last span adjustment is displayed (calibration).

Important Note:

This value is displayed only if the setting “Cal. then manual adj.” is active (see previous “Note”). If “Cal. then auto adj.” is active, the calibration/adjustment procedure cannot be cancelled.

- To stop the procedure after calibration and before adjustment takes place, press →0← (only if “Cal. then manual adj.” is active).

Perform adjustment (only if “Cal. then manual adj.” is active).

At the conclusion of the calibration procedure, the calibration weight is displayed as a positive value.

```

-----
14.01.2003      13:50
Typ      CW3P1-6DC-LCE
Ser.no.   12345678
Vers.    1.0103.11.2
BVers.   01-26-02
-----
External calibration
Nom.    +   5.000 kg
Diff.   +   0.010 kg
External adjustment
Diff.   +   0.000 kg
-----
14.01.2003      13:52
Name:
-----

```



When calibration/adjustment has been completed, the GMP-compliant printout shown here on the left is generated. If the adjustment procedure is canceled (only calibration is performed), the last two lines, “External calibration” and “Diff. + 0.000 kg” are not printed.

- Unload the scale.

Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Note:



If a serious operator error should occur during calibration (for example, if the menu setting “Cal. then auto adj.” is active and the wrong calibration weight is placed on the scale), the scale might completely fail to stabilize, which means it cannot show a zero point. In this case, select the “Adjust without weights” menu item and set the mean sensitivity of the strain-gauge weighing beam to 2.0 mV/V. Then perform calibration/adjustment. Also refer to “Example 2: Adjust without weights” in the section entitled “Configuring the Analog/Digital Converter.”

External Calibration/Adjustment with a User-Defined Weight

Preparation

As described above for “Ext. cal./adjust.; factory defined cal wt.” (external calibration with the weight value configured at the factory), with the exception that the menu item **“Ext. cal./adj.; user-defined weight”** (external calibration/adjustment with a user-defined weight) is selected in this case.

- Additional setting:
Enter the value for the calibration weight in the “Calibration/adjustment” menu, under “External weight” in the “Cal/adj. wt.” input field.




Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Unload and zero the scale.


Start the calibration/adjustment procedure.

This display is shown for 2 seconds.



Important Note:


If the display of geographical data (altitude and latitude or gravitational acceleration) is activated (see “Settings” at the beginning of this section), this data is displayed; press **→T←** to confirm each value (to cancel the calibration/adjustment procedure, press **→0←**). For details, see “Entering Geographical Data” above.



The nominal value of the required calibration weight (in this example, 6.000 kg) is shown as a negative value on the display.

- Place the required weight on the scale.

If the calibration/adjustment sequence is set to “Cal then auto adjust”, refer to the note under “External Calibration/Adjustment with Factory-Defined Weight (Default Weight).”




After a brief pause, the difference since the last span adjustment is displayed (calibration).

- To stop the procedure after calibration and before adjustment takes place, press $\rightarrow 0 \leftarrow$.



Perform calibration/adjustment.



At the conclusion of the calibration procedure, the calibration weight is displayed as a positive value.

```

-----
14.01.2003    13:50
Type      CW3P1-6DC-LCE
Serrano.    12345678
Veers.     1.0103.11.2
Boers.      01-26-02
-----
External calibration
Targ. +    6.000 kg
Diff. +    0.010 kg
External adjustment
Diff. +    0.000 kg
-----
14.01.2003    13:52
Name:
-----
  
```

When calibration/adjustment has been completed, the GMP-compliant printout shown here on the left is generated. If the adjustment procedure is canceled (only calibration is performed), the last two lines, “External calibration” and “Diff. + 0.000 kg” are not printed.



- Unload the scale.

Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Note:
 If a serious operator error should occur during calibration, refer to the “Note” above for details on corrective measures.

Internal Calibration/Adjustment

This function is available only if a digital weighing platform (for example, an IS platform) is connected as WP 2, either as a second weighing platform or as the only weighing platform without using the built-in A/D converter. The WP 2 device must be connected to the COM1 or COM2 port, and this interface must be configured accordingly. This function is also accessible without activating the Service mode.

External Linearization with the Factory-Set Weights (Default Weights)

This function is accessible only if the software and the functionality of the connected weighing platform permit this operation.

Preparation

As described above for “Ext. cal./adjust.; factory-defined cal wt.” (external calibration/adjustment using the weight value defined at the factory - default weight) and “Ext. lineariz.; user-defined weight.” Activating the display of geographical data has no effect on this function.

- Select “CAL Key Function” from the “Calibration/Adjustment” menu and activate the menu setting for **Ext. lineariz.; factory-def. wt.2)** (external linearization with default weights).

Restart the scale: Turn the indicator off and then on again.






The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Unload and zero the scale.

Start linearization.

This display is shown for 2 seconds.

The subsequent linearization procedure is described below, under “Ext. lineariz.; user-defined weights” (external linearization with user - defined weights).



External Linearization with User-Defined Weights

Preparation

As described above for “Ext. cal./adjust.; factory-defined cal wt.” (external calibration/adjustment using the weight value defined at the factory - default weight) and “Ext. lineariz.; factory-def. wt.”). Activating the display of geographical data has no effect on this function.

- Select “CAL Key Function” from the “Calibration/Adjustment” menu and activate the menu setting for **Ext. lineariz.; user-defined weight** (external linearization with user-defined weights).
- Additional setting:
Enter the values for the linearization weights in the “Calibration/adjustment” menu, under “Parameter for external weights” (“Ext. weight”), in the “Lin. wt.1” to “Lin. wt.4” input fields as described at the beginning of this section.


Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Unload and zero the scale.

Start linearization.

This display is shown for 2 seconds.




After approx. 2 seconds, the target value for linearization weight 1 is shown as a negative value on the display (in example shown here, 1.500 kg) .

- Place the prompted weight on the scale.


After a brief pause, the difference since the most recent calibration is displayed.

- Press $\rightarrow 0 \leftarrow$ if you wish to cancel linearization at this point.



Adjust the scale; to do this, store linearization weight 1.


After linearization weight 1 has been stored, the target value for linearization weight 2 is shown as a negative value on the display (in this example: 3.000 kg).



- Place the prompted weight on the scale.


After a brief pause, the difference since the most recent calibration is displayed.

- Press $\rightarrow 0 \leftarrow$ if you wish to cancel linearization at this point.



Adjust the scale; to do this, store linearization weight 2.


After linearization weight 2 has been stored, the target value for linearization weight 3 is shown as a negative value on the display (in this example: 4.500 kg).





- Place the prompted weight on the scale.

After a brief pause, the difference since the most recent calibration is displayed.

- Press $\rightarrow 0 \leftarrow$ if you wish to cancel linearization at this point.





Adjust the scale; to do this, store linearization weight 3.

After linearization weight 3 has been stored, the target value for linearization weight 4 is shown as a negative value on the display (in this example: 6.000 kg).

- Place the prompted weight on the scale.

After a brief pause, the difference since the most recent calibration is displayed.

- Press if you wish to cancel linearization at this point.

Adjust the scale; to do this, store linearization weight 4.

After linearization weight 4 has been stored, a zero point is prompted.

- Remove all linearization weights from the weighing platform.

The zero point is stored automatically, after which the scale returns to the normal weighing mode.

When linearization has been completed, the GMP-compliant printout shown here on the left is generated.

```

-----
14.01.2003    13:00
Typ    CW3P1-6DC-LCE
Ser.no.    12345678
Vers.    1.0103.11.2
BVers.    01-26-02
-----
Linearization
Wt.1 +    1.500 kg
Wt.2 +    3.000 kg
Wt.3 +    4.000 kg
Wt.4 +    6.000 kg
          completed
-----
14.01.2003    13:02
Name:
-----

```

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		

Soft key \rightarrow

If nec.: soft key \uparrow | \downarrow , soft key \rightarrow

DEVICE	WP 1	INTERNAL	S
ADC configuration			
Calibration/adjustment			
Adapt filter			
Application filter			
Stability range			
Stability delay			

Soft key \downarrow , soft key \rightarrow

WP 1	INTERNAL	CAL./ADJ.	S
CAL key function			
Cal/adj. sequence			
isoCAL function			
Parameter for external weight			
Adjust without weights			
Geographical data			


Soft key \rightarrow

INTERNAL	CAL./ADJ.	CAL KEY	S
Ext. cal./adj.: factory-def. wt.			
Ext. cal./adj.: user-defined wt.			
Ext. lineariz.: user-def. wts			
Set preload			
Delete preload			
Key blocked			

Soft key \uparrow (repeatedly, if nec.) | \downarrow

Soft key \downarrow

INTERNAL	CAL./ADJ.	CAL KEY	S
Ext. cal./adj.: factory-def. wt.			
Ext. cal./adj.: user-defined wt.			
Ext. lineariz.: user-def. wts			
Set preload			
Delete preload			
Key blocked			



Setting and Clearing the Preload

Preparation

(See also “Calibration and Adjustment” in the chapter entitled “Operation” and refer to the service manual for Combics Complete Scales and Indicators.)

- Remove the cap that covers the menu access switch on the left-hand side of the back of the indicator housing.
- Move the menu access switch to the right (towards the interface connectors); into the “Accessible” position.
- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select the desired weighing platform (in this example: **WP 1**).

If the **Internal** setting is not already activated (marked by \odot), press the \uparrow or \downarrow soft key to select the setting and press \rightarrow to confirm. The message **Function active** is shown briefly in the first line of the display, after which the Setup menu for “WP 1 - Internal” is opened.

The Setup menu for the “WP 1 - Internal” device parameters is displayed.

Open the **Calibration/adjustment** menu.

Open the **CAL key function** submenu.

The function currently set for the CAL key (in this example, “Ext. cal./adjust.; factory-defined cal weight” (external calibration/adjustment using the weight defined at the factory - default weight) is marked by a circle (\odot).

Setting the Preload

If not already selected (marked by \odot), activate the **Set preload** setting. To do this, press the \downarrow or \uparrow soft key (repeatedly if necessary)


to highlight this menu item and press the \downarrow soft key to confirm.

The “Set Preload” item is marked by a circle (\odot).

Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

Unload and then tare or zero the scale.
After a tare command, the indicator may show **NET**.




Display after the scale has been zeroed.



- Place the preload weight on the weighing platform.

→T← (> 2 sec)



Activate the "Set preload" function.

This display is shown for 2 seconds. The weight on the scale is stored as the preload.


```

-----
14.01.2003    13:50
Typ    CW3P1-6ED-LCE
Ser.no.    12345678
Vers.     1.0103.11.2
BVers.     01-26-02
-----
Set preload
      completed
-----
14.01.2003    13:52
Name:
-----

```

After the "Set Preload" operation has been completed, the scale is zeroed. The scale then returns to the normal weighing mode.

At the conclusion of the "Set preload" operation, the GMP-compliant printout shown here on the left is generated.



Clearing the Preload

Open the CAL key function submenu.

The function currently set for the CAL key (in this example, "Ext. cal./adjust.; factory-defined cal weight" (external calibration/adjustment using the weight defined at the factory - default weight) is marked by a circle (○).

Soft key ^ (repeatedly, if nec.) I ∨

Soft key ↓

If not already selected (marked by ○), activate the Clear preload setting.

To do this, press the ∨ or ^ soft key (repeatedly if necessary) to highlight this menu item and press the ↓ soft key to confirm.




The "Clear Preload" item is marked by a circle (○).




Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.




- Remove the preload from the weighing platform.
The display shows the preload weight as a negative value.



Activate the “Clear preload” function.

This display is shown for 2 seconds. The preload is cleared.



After the “Clear Preload” operation has been completed, the scale is zeroed. The scale then returns to the normal weighing mode.


At the conclusion of the “Clear Preload” operation, the GMP-compliant printout shown here on the left is generated.

```
-----
14.01.2003      13:50
Typ    CW3P1-6DC-LCE
Ser.no.   12345678
Vers.    1.0103.11.2
BVers.   01-26-02
-----
Clear preload
        completed
-----
14.01.2003      13:52
Name:
-----
```


After performing calibration/adjustment, linearization and setting/clearing the preload:

- Activate the “Device Parameters” menu for the active weighing platform (for example, WP 1) and highlight the “Calibration/adjustment” menu item.

Open the “Calibration/Adjustment” menu.




Soft key ➤




- Open the “CAL Key Function” submenu and select the “Ext. cal./adjust.; factory-defined cal weight” (external calibration/adjustment using the weight defined at the factory - default weight) menu item. This is the factory default setting for this submenu, and is also accessible without activating the Service mode.
- Before performing service work, return any changed settings in the “Cal./adj. sequence” (sequence of the calibration/adjustment procedure) and Activate ext. adj.” (activate external calibration/adjustment, not for use in legal metrology) submenus to the original settings (generally, these will correspond to the factory defaults).
The factory settings are:
 - Menu item “Cal./adj. sequence”: setting “Cal. then manual adj.”
 - Menu item “Activate ext. adj.” (not for “Verifiable” configuration): setting “Activated”





3x soft key <



Soft key > repeatedly







6x soft key >, soft key >



Return to the “Device Parameters” menu..

Select the **Operating parameters** menu.

Select and open the **Display geogr. data** submenu.

If not already deactivated (“Off” marked by ) , deactivate the display of geographical (“Off”; factory setting). To do this, press the  soft key to move the highlight bar to and press the  soft key to confirm. The circle () now marks the “Off” setting.

Important Note:

When you activate the “Factory Settings for All Parameters” menu item at the highest menu level, all operating parameters are returned to the factory default settings. This also applies to any customer-specific menu settings that have been configured. For details, see “Restoring All Operating Parameters to Factory Settings” in this chapter.

- Move the menu access switch from the “Accessible” to the “Closed” position:
- If necessary, remove the cap that covers the menu access switch on the left-hand side of the back of the indicator.
- Move the menu access switch to the left (“Closed” position). See also “Calibration and Adjustment” in the chapter entitled “Operation,” or refer to the service manual.
- Replace the protective cap over the menu access switch.

Restart the scale: Turn the indicator off and then on again.

The Sartorius logo is displayed briefly, after which the device is in normal weighing mode.

If the A/D converter was configured with a “Verifiable” data record, the lines for display of metrological data (lines 1 and 2) show the data valid for use in legal metrology when the menu access switch is closed. For details, see the section entitled “Use in Legal Metrology” in this chapter.

Connecting a Weighing Platform to WP 2 COM1 (Recommended) or COM2 Port):

When you connect a digital weighing platform configured for use in legal metrology to WP 2 (xBPI-232 protocol; initiated automatically), the metrological data is transferred automatically when communication is established between the indicator and the weighing platform. This data is

displayed after you close the menu access switch (see also the notes on this topic at the beginning and end of this chapter, as well as the “Calibration and Adjustment” section in the chapter entitled “Operation”). Thus no further steps are necessary to protect communication between indicator and weighing platform (for example, by entering the serial number of the weighing platform).


Restoring All Operating Parameters to Factory Settings

When you activate the menu item “Factory settings for all parameters” at the highest level of the Setup menu, all operating parameters (i.e., all settings stored in the indicator’s EEPROM and RAM modules) are restored to the factory settings. The user language is also returned to the default language (English) and any user password configured is deactivated. This “Reset” function also applies to all interface configuration data (for example, “SBI” on COM1, or “WP 2” on COM2) and any menu settings that have been configured. The internal transaction counter for Alibi memory is also reset. This is why the error code “Err 343” is displayed. The settings for weighing platforms WP 1 and WP 2 are not affected.


Preparation

(See also “Operating Menu (Overview)” in the chapter entitled “Configuration.”)

- Activate the Service mode (see the corresponding section at the beginning of this chap-



5 x soft key ↵, soft key ➤



Soft key ↵



Select and open the **Factory settings for all parameters** menu item.

- To restore all parameters to the factory settings, press the **↵** soft key to move the highlightbar to the “Yes” setting and press the **➤** soft key to confirm. The first line of the display briefly shows the message “**Parameters reset.**” Afterwards, the program returns to the display status “o No” (“Do not reset parameters”).

Return to the Setup menu in Service mode.

The device is now set to the “English” language version.

If desired, select “Language” in the Setup menu to set the language to “U.S. Mode.”

SETUP	DEVICE	S
MP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		

Soft key ∇ repeatedly

SETUP	DEVICE	S
UniCOM		
Control input		
Bar code		
Config. printout		
Operating parameters		
Clock		
Password		
Service		
Memory number		
Terminal data		
<<	<	>

Soft key \rightarrow

SETUP	DEVICE	SERVICE	S
Service date:		01.02.03	

Entering the Service Date

Preparation

(See also “Operating Menu (Overview)” in the chapter entitled “Configuration” and refer to the service manual for Combics Complete Scales and Indicators.)

- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select the **Service** menu item.

Open the **Service** menu item.

The input field for the service date is displayed.

Navigation and Input

For details, see Example 1 under “Configuring the Analog/Digital Converter” and refer to the chapter entitled “Operating Design.”

Enter the date of the next scheduled service procedure and press the ∇ soft key to confirm.

Important Note:

The service date is displayed in the Setup menu under “Setup > Info > Service.” It is not necessary to activate the Service mode to view the service date.

Soft key \leftarrow

Return to the “Device Parameters” menu.

Entering the Transaction Number for Data Stored in Alibi Memory

The Combics indicator assigns a unique number to each transaction for unambiguous identification of data records stored in Alibi memory. The transaction number can have up to 8 digits, and is increased by one each time a data record is transferred to Alibi memory. The beginning number is defined either by the indicator (start value: 1) or by the user. If a defective weighing platform is replaced by a service representative, for example, the user can enter an explicit start value for the transaction number so that the existing transaction series is continued without interruption.

Preparation

(See also “Operating Menu (Overview)” in the chapter entitled “Configuration” and refer to the service manual for Combics Complete Scales and Indicators.)

- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

SETUP	DEVICE	S
MP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		

Soft key ∇ repeatedly

SETUP	DEVICE	S
UniCOM		
Control input		
Bar code		
Config. printout		
Operating parameters		
Clock		
Password		
Service		
Memory number		
Terminal data		
<<	<	>

Soft key \triangleright

SETUP	DEVICE	MEM. NO.	S
Memory no.:		1	

Soft key \triangleleft

SETUP	DEVICE	S
WP 1		
COM 1		
COM 2		
UniCOM		
Control input		
Bar code		

Soft key ∇ repeatedly

SETUP	DEVICE	S
UniCOM		
Control input		
Bar code		
Config. printout		
Operating parameters		
Clock		
Password		
Service		
Memory number		
Terminal data		
<<	<	>

Soft key \triangleright

SETUP	DEVICE	TERMINAL	S
Serial no.:		12345678	
Model:		CW3P1-6ED-LCE	

Soft key \triangleleft

Soft key \triangleleft

$\triangleleft \triangleleft$ or **SETUP**

Select the **Memory number** menu item.

Open the **Memory number** menu item.

Navigation and Input

For details, see Example 1 under “Configuring the Analog/Digital Converter” and refer to the chapter entitled “Operating Design.”

Enter the new start value for the transaction number and press the \downarrow soft key to confirm.

Return to the “Device Parameters” menu.

Entering the Serial Number and Model Designation

Following replacement of the digital PCB, the serial number and model designation of the indicator or complete scale must be entered in the indicator.

Preparation

(See also “Operating Menu (Overview)” in the chapter entitled “Configuration” and refer to the service manual for Combics Complete Scales and Indicators.)

- Activate the Service mode and open the **Device parameters** menu (see the corresponding section at the beginning of this chapter).

Select the **Terminal data** menu item.

Open the **Terminal data** menu item.

Navigation and Input

For details, see Example 1 under “Configuring the Analog/Digital Converter” and refer to the chapter entitled “Operating Design.”

Enter the serial number in the “Serial no.” field and press the \downarrow soft key to confirm. The highlight bar is automatically positioned on the “Model” field.

Enter the model designation in the “Model” field and press \downarrow to confirm.

Return to the “Device Parameters” menu.

Return to the Setup menu in Service mode.

Return to the normal weighing mode.

Error Codes

Error codes are shown on the main display. **ERR** codes are shown continuously; **INF** messages are displayed for 2 seconds, after which the program returns automatically to the weighing mode.

Error Code	Cause	Solution
ERR 101 - 104	Key is stuck Key pressed at power on	Release key or Contact your local Sartorius Service Center
ERR 320	Program memory defective	Contact your local Sartorius Service Center
ERR 335	Verified weighing platform not compatible with the connected terminal	Connect a compatible weighing platform
ERR 340	Operating parameter memory (EEPROM) defective.	Turn the scale off and then on again If the error code is still displayed, please contact your local Sartorius Service Center
ERR 341	Data lost from RAM; battery needs to be recharged	Leave the scale connected to power for at least 10 hrs.
ERR 343	Loss of data in the memory area for transaction numbers in external Alibi memory	Contact your local Sartorius Service Center
INF 01	Data output not compatible with output format	Change the menu settings
INF 02	Calibration/adjustment condition not met; e.g., - the scale was not tared - the scale is loaded	Calibrate only when zero is displayed Press $\rightarrow T \leftarrow$ to tare Unload the scale
INF 03	Calibration/adjustment could not be completed within a certain time	Allow the scale to warm up and then repeat the adjustment process
INF 06	Built-in calibration weight defective	Contact your local Sartorius Service Center
INF 07	Function not allowed in scales verified for use in legal metrology	Contact your local Sartorius Service Center for information on changing settings
INF 08	The load on the scale is too heavy to zero the readout	Check whether "Tare/zero at power on" is set
INF 09	Taring is not possible when the gross weight is \leq zero	Zero the scale
INF 10	Tare key is blocked when there is data in the tare memory	The data stored for the application program must be deleted before taring
INF 22	Error in storing reference value, load is too light	Put a heavier sample on the scale
INF 23	Error in initializing an application	Contact your local Sartorius Service Center
INF 29	Minimum load not reached	Define a lower value for the minimum load (in the "Application parameters," under "Minimum load for initialization")
INF 71	Cannot store the current weight value (e.g., control limits too low or too high)	None
INF 72	Cannot store the current weight value (e.g., the transaction counter has reached its limit)	None
INF 73	Data not found or unreadable	Contact your local Sartorius Service Center
INF 74	Function is blocked (e.g., menu is locked)	None
INF 98	No weighing platform connected	Connect a weighing platform
INF 99	No weighing platform connected	Connect a weighing platform
NO WP	No weighing platform connected	Connect a weighing platform

Service

Regular servicing by a Sartorius technician will ensure the continued accuracy of your indicator. Sartorius offers service contracts with regular maintenance intervals ranging from 1 month to 2 years. The maintenance interval depends on operating conditions and tolerance requirements.

Repairs

- ⚠ Disconnect defective equipment from power immediately. Repair work must be performed by authorized Sartorius service technicians using original spare parts. Repairs performed by untrained persons may result in considerable hazards for the user. If the equipment is still under the warranty, send the entire indicator to the factory for repairs.

- ⚠ If a cable or cable gland is damaged or defective, replace the cable as a complete unit with all its connectors.

- ⚠ Do not open the equipment while it is carrying current. Wait at least 10 seconds after disconnecting it from power before beginning to open the equipment. Proper fitting of all surfaces is essential for the IP rating of the housing; for this reason the device must be opened and closed by a certified technician.

Cleaning

The indicator is designed in compliance with European Hygienic Equipment Design Group (EHEDG) directives for contamination prevention, so that it is particularly easy to clean and disinfect.

- ⚠ Unplug the equipment from the wall outlet (mains supply) and disconnect any data cables.
- ⚠ Make sure no liquid enters the indicator housing.
- ⚠ Do not use aggressive cleaning agents (solvents or similar agents).
- Clean the indicator using a piece of cloth which has been wet with a mild detergent (soap).
- If used in the food industry, use a cleaning agent suitable for the particular working environment.
- After cleaning, wipe down the indicator with a soft, dry cloth.
- ⚠ Do not wash down the equipment with water or dry it with compressed air; this is not permitted.

Cleaning Stainless Steel Surfaces

Clean all stainless steel parts regularly. Remove the stainless steel load plate and thoroughly clean it separately. Use a damp cloth or sponge to clean stainless steel parts on the weighing instrument. You can use any household cleaning agent that is suitable for use on stainless steel. Clean stainless steel surfaces by wiping them down. Then rinse the equipment thoroughly, making sure to remove all residues. Afterwards, allow the equipment to dry. If desired, you can apply oil to the cleaned surfaces as additional protection. Solvents are permitted for use only on stainless steel parts.

Replacing the Dust Cover

- Replace damaged dust covers.
- Place the new dust cover on the indicator and press down on the front and back along the edges until the cover is firmly seated.

Safety Inspection

Safe operation of the equipment is no longer ensured when:

- there is visible damage to the device or power cord,
- the built-in power supply no longer functions properly,
- the device has been stored for a relatively long period under unfavorable conditions (e.g., excessive humidity), or
- the equipment has been subjected to rough handling during shipment.

If there is any indication that safe operation of the device is no longer warranted:

- Disconnect the equipment from power,
- Lock it in a secure place to ensure that it cannot be used for the time being, and
- Notify your nearest Sartorius Service Center or the International Technical Support Unit based in Goettingen, Germany.

Maintenance and repair work may be performed only by authorized Sartorius service technicians who have access to the required maintenance manuals and have attended the relevant service training courses.

- ⚠ The seals on the equipment indicate that only authorized service technicians may open the equipment and perform maintenance work; this ensures that operation of the equipment is safe and trouble-free and the warranty remains in effect.

Sartorius products are packaged for safe shipment using environmentally friendly materials. If you do not need the packaging after successful installation of the equipment, you should return it for recycling. For information on recycling options, including recycling of old weighing equipment, contact your municipal waste disposal center or local recycling depot.

If the equipment contains batteries, make sure to remove them before disposal. Batteries are hazardous waste and must be disposed of separately.


Please contact your municipal waste disposal center for details.

Overview

Specifications

When used in standard applications (as opposed to legal metrology):	
- Display resolution	≤31,250 d
In legal metrology:	
Accuracy class	III, IIII
Verification scale intervals when used as	
- Single-range scale	≤3,125 e
- Multi-interval scale	≤3,125 e
Maximum e1	6,250e
- Multiple-range scale	≤3,125 e
Load cell connection:	
- Supply voltage	9 V (± 4.5 V)
- Bridge impedance	83 Ω to 2,000 Ω
- Available sensor technology	4-conductor or 6-conductor technology
When used in legal metrology:	
- Available sensor technology	6-conductor technology
- Max. cable length per gauge	150 m/mm ²
- Lowest permissible input signal	
for p _{ind} = 0.5	≥0.720 μV/e
for p _{ind} = 0.3	≥1.200 μV/e
Fraction of tolerance for this module:	
for delta V _{min} ≥0.720 μV/e	0.5
for delta V _{min} ≥1.200 μV/e	0.3
Performance specifications of the integrated A/D converter, weighing capacity	
	up to 32 t
Measuring signal	0.45 mV to 36 mV
Measuring signal for preload (dead load)	0.45 mV to 6.3 mV
Measuring signal variation	4.5 mV to 29.7 mV
Sensitivity	4 million digits max. (internal)
Digital protective interface	acc. to EN45501
Data interface	Bi-directional RS-232 COM1 interface with control outputs (5V, TTL standard) (standard equipment)
	Bi-directional COM2 interface as RS-232, RS-422 or RS-485 (standard equipment)
Additional data interface	optional
Display	108 × 58 mm graphic display, backlit, 248 × 128 pixels
Housing:	
- Material	AISI 304 stainless steel
- Dust and water protection acc. to EN60529	CISL3: IP44 (optional IP65) CIS3: IP67
Operating temperature range	-10°C to +40°C (+14°F to +104°F)
Power supply	100-240 VAC (-15/+10%), 50-60Hz, max. 17W / 23 VA optional 15.5-24 VDC (±10%), max. 12 W optional 13-17 VAC (±10%), 50-60 Hz, max. 12 W Optional battery pack: YBR10Z
Emissions	Acc. to EN61326+A1 Class B (IEC 61326+A1)
Immunity to interference	Acc. to EN61326+A1, industrial areas (IEC 61326+A1)
Electrical safety	Acc. to EN61010-1 (EC 1010-1), EN60950 (IEC 950)

Dimensions (Scale Drawings)



Accessories

Product

Order No.

Dust covers (2 pcs)

YDC01CI

Interface module (RS-232) for UniCOM

YD001C-232

Interface module (RS-485/RS-422) for UniCOM

YD001C-485

Profibus-DP module for UniCOM interface

YD001C-DP

Analog current output, 0-20 mA, 4-20 mA, 0-10 V, 16-bit*

YDA01C-20MA



Verifiable strip and label printer with thermal print head, paper width 60 mm, with adapter cable (12-contact round male connector) and external power supply.

YDP04IS-OCE-UV

Adapter cable YCC01-01CISLM3 required for

Combics model CISL indicator.

Adapter cable YCC02-R12F6 required for

Combics model CIS indicator.

- Printer paper (3 rolls) for YDP04/12IS, 60 mm x 75 mm, thermo paper

69Y03090

- Labels for YDP04/12IS, small, 58 x 30 mm; 1000 labels

69Y03092

- Labels for YDP04/12IS, medium, 58 mm x 76 mm; 500 labels


69Y03093

- Labels for YDP04/12IS, large, 58 x 100 mm; 350 labels

69Y03094

Cable for direct connection of YDP04/12IS printer to Combics model CISL indicator

YCC01-01CISLM3



Verifiable printer with functions for date, time and statistical evaluations; LC display.

YDP03-OCE.

- Printer paper (5 rolls; length per roll: 50 m)
- Replacement ink ribbon cartridge for printer

6906937

6906918



Verifiable strip and label printer with thermal print head, paper width 101 mm, with adapter cable (12-contact round male connector) and external power supply.

YDP12IS-OCE-UV

Sartorius "NICE Label Express" software required for putting the printer into operation.

Adapter cable YCC01-01CISLM3 required for Combics model CISL indicator.

Adapter cable YCC02-R12F6 required for Combics model CIS indicator.

- Printer paper (1 roll) for YDP12IS printer, 101 mm x 75 m, thermo paper

69Y03196

- Labels for YDP12IS printer, extra large, 101 x 75 mm; 305 labels

69Y03195

* data output cannot be used in legal metrology

Product	Order No.
External rechargeable battery pack, up to 40 h operation, incl. charger	YRB10Z
External red/green/red display for Combics model CISL indicators	YRD11Z
Second display for Combics model CISL indicators *	YRD02Z
Remote display, 7-segment, up to 45 mm character size *	Information on request
Bar code scanner, 120 mm scanning width, with cable for connection to Combics 2	
– for Combics model CISL indicators	YRB02CISL
– with adapter cable YCC02-R12F6 for Combics model CIS indicators	YBR02FC
Foot switch, incl. D-Sub 25-pin T-connector	YFS01
Hand switch, incl. D-Sub 25-pin T-connector	YHS02
External Alibi memory for electronic storage of weighing data	YAM01IS
Scanner for loading weighing data in a PC from YAM13IS card	YAM02IS
Power supply for YAM01IS or YAM02IS	YAM11IS
Memory card for YAM01IS	YAM13IS
Cable for connecting Combics indicator to YAM01IS Alibi memory	YCC01-10CIM3
Cable (D-Sub 9-pin) for connecting YAM01IS Alibi memory to a PC	69EM0012
Flow control for pumps with analog or pulse interface	YFC02Z-V2
Flexible formatting options for printouts (e.g., for bar codes with variable font size, graphics, etc.)	Information on request
Sartorius WinScale driver software for Windows 95/98/2000/NT. Displays the scale readout on your PC monitor and provides secure memory for storing data that is subject to legal control. YCC01-09ISM5 RS-232 connecting cable required (RS-485 cable available on request).	YSW03
SartoConnect data transfer software for connecting your Sartorius scale to a computer running Windows 95/98/NT. Load weighing data in an application such as MS Excel or Access. Includes a cable (1.5 m) for connecting the scale to a PC (12-pin to 9-pin)	YSC011
Installation kit for installing the Combics in a pit (with separable connection to indicator)	YAS991
Combics Configuration Tool for operating menu settings*	YAD03CW
IP65 Upgrade Kit for IP44-protected Combics model CISL indicators	YAS01CISL
Retainer for wall mounting; stainless steel	YDH02CIS
Floor-mounted column	YDH03CIP
Floor-mounted column; stainless steel	YDH03CIS
Base for installing the floor-mounted column	YBP03CIP
Base for installing the floor-mounted column; stainless steel	YBP03CIS

* not for use in legal metrology

Product	Order No.
Retainer for a bar code scanner, for attachment to floor-mounted column, bench stand or complete scale retainer	YBH01CWS
Plate for attaching a printer to the floor-mounted column or bench stand	YPP01CWS
Castor set (2 guide castors, 2 lockable castors) for YBP03CIP/S floor-column base	YR003CI
Anti-theft locking device	YTP01CI
24V industrial power supply module*	YAS02CI
Connecting cable (25-pin D-Sub) for YRB10Z battery pack (2 m)	YCC02-RB01
Connecting cable with cable gland, for YRB10Z battery pack (2 m) (Combics CIS models only)	YCC02-RB02
Connecting cable with cable gland for car battery (2 m) (Combics CIS models only)	YCC02-CB02
Connecting cable with cable gland for YBR02FC bar code scanner (Combics CIS models only)	YCC02-BR02
Connecting cable with cable gland, to 9-pin D-Sub male connector, 6 m (Combics CIS models only)	YCC02-D09M6
Connecting cable with cable gland, to 9-pin D-Sub female connector, 6 m (Combics CIS models only)	YCC02-D09F6
Connecting cable with cable gland, to 25-pin D-Sub female connector, 1.5 m (Combics CIS models only)	YCC02-D25F6
Connecting cable with cable gland, to 12-pin round male connector, 6 m (Combics CIS models only)	YCC02-R12M6
Connecting cable with cable gland, to 12-pin round female connector, 1.5 m (Combics CIS models only)	YCC02-R12F6
Cable for YDA01C-20MA current interface, with open cable ends (e.g., order 5 x for a 5 m cable)*	6906926
Cable gland for Combics model CIS, IP65/67 (Combics CIS models only)	YAS04CIS

Connecting an IS Weighing Platform to a Combics 3 Indicator

You can connect an IS weighing platform to the COM1 or COM2 port for use as 'WP2'.

Features:

- IS weighing platforms process weighing data independently of the indicator.
- IS weighing platforms can be internally calibrated/adjusted.
- IS...-OCE models have a separate approval number, printed on a tag that is affixed to the cable.
- Please observe the conditions described in the manual for the weighing platform you connect.

* not for use in legal metrology

Declaration of Conformity

In 1985, the Council of the European Community approved a resolution concerning a new approach to the technical harmonization and standardization of national regulations. Monitoring compliance with the directives and standards concerning the C marking is governed in the individual EU Member States through the implementation of the EC Directives adopted by the respective national laws. As of December 1993, the scope of validity for all EC Directives has been extended to the Member States of the European Union and the Signatories of the Agreement on the European Economic Area.

Sartorius complies with the EC Directives and European Standards in order to supply its customers with weighing instruments and related equipment that feature the latest technology and provide many years of trouble-free service.

The **CE** marking may be affixed only to weighing instruments and associated equipment that comply with the following Directives:

Council Directive 89/336/EEC
"Electromagnetic compatibility (EMC)"
Applicable European Standards:

- 1. Electromagnetic compatibility:
 - 1.1 Reference to 89/336/EEC:
 - Official Journal of the European Communities, No. 2001/C105/03
 - EN 61326-1 Electrical equipment for measurement control and laboratory use EMC requirements
 - Part 1: General requirements
Defined immunity to interference:
Industrial areas, continuous, un-monitored operation
Limitation of emissions: Residential areas, Class B

Important Note:
The operator shall be responsible for any modifications to Sartorius equipment and for any connections of cables or equipment not supplied by Sartorius and must check and, if necessary, correct these modifications and connections. On request, Sartorius will provide information on the minimum operating specifications (in accordance with the Standards listed above for defined immunity to interference).

73/23/EEC "Electrical equipment designed for use within certain voltage limits"
Applicable European Standards:

- EN 60950 Safety of information technology equipment including electrical business equipment
- EN 61010 Safety requirements for electrical equipment for measurement, control and laboratory use
- Part 1: General requirements

If you use electrical equipment in installations and under ambient conditions requiring higher safety standards, you must comply with the provisions as specified in the applicable regulations for installation in your country.

Weighing Instruments for Use in Legal Metrology: Council Directive 90/384/EEC
"Non-automatic weighing instruments"

This Directive regulates the determination of mass in legal metrology .
For the respective Declaration of Type Conformity for Sartorius weighing instruments verified for use as legal measuring instruments that have an EC Type-Approval Certificate, see the instruction manual for the weighing platform in question or the enclosed "Guide to Verification" (on CD-ROM). This Directive also regulates EC verification by the manufacturer, provided that an EC Type-Approval Certificate has been issued and the manufacturer has been accredited by an officer of a Notified Body registered at the Commission of the European Community for performing such verification. The legal basis for EC verification is EC Directive No. 90/384/EEC for non-automatic weighing instruments, which has been in effect since January 1, 1993, within the Single European Market, and the accreditation of the Quality Management System of Sartorius AG by Lower Saxony's Regional Administrative Department of Legal Metrology (Niedersächsische Landesverwaltungsamt – Eichwesen) from February 15, 1993. For additional information on the **CE** mark on Sartorius equipment, see Sartorius Publication No. W- -0052-e93081.

"EC Verification" –
A Service Offered by Sartorius

Our service technicians authorized to perform the verification of your weighing instruments that are acceptable for legal metrological verification can inspect and verify the metrological specifications at the place of installation within the Member States of the European Union and the Signatories of the Agreement on the European Economic Area.

Subsequent Verifications within the European Countries

The validity of the verification will become void in accordance with the national regulations of the country in which the weighing instrument is used.
For information on verification and legal regulations currently applicable in your country, and to obtain names of the persons to contact, please contact your local Sartorius office, dealer or service center.



Konformitätserklärung zur Richtlinie 90/384/EWG *Declaration of Conformity of Type to Council Directive 90/384/EEC*

nichtselbsttätige elektromechanische Waagen
nonautomatic electromechanical weighing instruments

(Alle Daten sind in den Prüfberichten, Bauartzulassungen oder den betroffenen Geräten selbst zu entnehmen)
(All data to be taken from test certificates, type-approval certificates, or instruments in question)

Auswerte- gerät <i>Indicator</i>	Typ Auswertegerät <i>Indicator type</i>	Typ Waage Weighing instrument <i>type</i>	Genauigkeits- klasse <i>Accuracy class</i>	EG-Bauart- zulassung Nr. <i>EC type approval no.</i>	Prüfschein Nr. Auswertegerät <i>Indicator test certificate no.</i>
Cl...	TN	SARTICS	III IIII	D04-09-015	D09-03.13
CIX...	TN-X	SARTICS	III IIII	D04-09-015	D09-03.13

Elektromechanische Waage

Die Konformitätserklärung gilt, wenn:

- das Auswertegerät als unverändertes Originalmodul verwendet wird.
- die Kompatibilität der Module über das mitgelieferte Programm "KOMPMOD.xls" bestätigt und vom Waagenbauer unterschrieben wurde.
- eine Benannte Stelle der EU geprüft und in einer Konformitätsbescheinigung bestätigt hat:
 - * die Übereinstimmung der im Formular (Programm) gemachten Angaben mit Waage und EG-Bauartzulassung.
 - * die Richtigkeit der Aufschriften auf dem Kennzeichnungsschild
 - * die Prüfung der Waage nach EN 45501 Punkt 8.2
- die Benannte Stelle das Kennzeichnungsschild mit der grünen Klebmarke mit dem Messtechnik-M und ihrer Nummer ausgerüstet und die in der EG-Bauartzulassung geforderten Stellen mit ihren Sicherungsmarken verschlossen hat.

Sartorius AG
37070 Göttingen, Deutschland / Germany
Göttingen, 01.11.2004

Dr. G. Maaz
(Spartenleitung Mechatronik)
(President of the Mechatronics Division)

Electromechanical weighing instrument

The Declaration of EC Conformity of Type applies if:

- The indicator is used as an unchanged original module
- The Compatibility of Modules is confirmed by the delivered program "COMPMOD.xls" and signed by the scale assembler
- A Notified Body of the EU has tested and confirmed the following in its own Certificate of Conformity:
 - * the information and specifications on the form (program) conform to those of the weighing instrument and on the EC type-approval certificate
 - * the marking on the descriptive plate is correct
 - * the weighing instrument was tested in conformance to EN 45501, section 8.2
- The Notified Body has affixed the green sticker with the metrology mark "M" and its number to the descriptive plate, and sealed the positions in accordance with the EC type-approval certificate using the Notified Body's protective marks.

J. Rehwald
(Leitung Produktion Mechatronik / Wägetechnik)
(Head of the Production Department
Mechatronics / Weighing Technology Division)

Physikalisch-Technische Bundesanstalt

Braunschweig und Berlin

PTB



EG-Bauartzulassung

EC type-approval certificate

Zulassungsinhaber: Sartorius AG

Issued to:

Weender Landstr. 94-108
37075 Göttingen

Rechtsbezug:
In accordance with:

§ 13 des Gesetzes über das Mess- und Eichwesen (*verification act*)
vom/dated 23. März 1992 (BGBl. I S. 711), zuletzt geändert am (*last*
amended on) 25.11.2003 (BGBl. I S. 2304), in Verbindung mit Richtlinie
(*in connection with council directive*) 90/384/EWG, geändert durch (*amended*
by) 93/68/EWG

Bauart:
In respect of:

Nichtselbsttätige elektromechanische Waage mit oder ohne Hebelwerk
Nonautomatic electromechanical weighing instrument with or without
lever system

Typ / Type:

SARTICS

Max 0,5 kg ... 300 t

(III) $n \leq 6250$

(III) $n \leq 1000$

Option: Mehrbereichs- und Mehrteilungswaage
multi-interval and multiple range instrument

Zulassungsnummer:

D04-09-015 1. Revision

Approval number:

Gültig bis:

07.04.2014

Valid until:

Anzahl der Seiten:

12

Number of pages:

Geschäftszeichen:

PTB-1.12-4014622

Reference No.:

Benannte Stelle:

0102

Notified Body:

Im Auftrag
By order


Marcus Link



Braunschweig, 18.10.2004

Siegel
Seal

Die Hauptmerkmale, Zulassungsbedingungen und Auflagen sind in der Anlage enthalten, die Bestandteil der Revision der EG-Bauartzulassung ist. Hinweise und eine Rechtsbehelfsbelehrung befinden sich auf der ersten Seite der Anlage

The principal characteristics, approval conditions and special conditions, if any, are set out in the Annex which forms an integral part of this Revision of the EC type-approval certificate. For notes and information on legal remedies, see first page of the Annex.

Physikalisch-Technische Bundesanstalt

Braunschweig und Berlin

PTB



Prüfschein

Test certificate

Ausgestellt für:

Sartorius AG

Issued to:

Weender Landstr. 94-108
37075 Göttingen

Prüfgrundlage:

EN 45501 (1992), Nr. 8.1, WELMEC-Dokument 2.1 (1997) EWG
Richtlinie 90/384/EWG, OIML R 76-1

In accordance with:

Gegenstand:

Auswertegerät *Indicator*
und Terminal *and Terminal*
Typ: TN und / and TN-X

Object:

Typ:

Kennnummer:

Serial number:

Prüfscheinnummer:

D09-03.13 1. Revision

Test certificate number:

D09-03.13 Revision 1

Datum der Prüfung:

Date of Test:

Anzahl der Seiten:

9

Number of pages:

Geschäftszeichen:

PTB-1.12-4009190

Reference No.:

Benannte Stelle:

0102

Notified Body:

Im Auftrag

By order

Marcus Link



Braunschweig, 31.10.2003

Siegel


Seal

R3-39200



Hinweise siehe erste Seite der Anlage, die Bestandteil des Prüfscheines ist.
For notes, see first page of the Annex which forms an integral part of the test certificate.

Plates and Markings

CIS3 / CISL3 (Type TN)



Alternative: Disconnectable connection between indicator and load receptors with strain-gauge load cells:



If there is a junction box between load receptor and electronic evaluation unit the junction has to be secured against inadmissible manipulation.


Alternative place for the Descriptive Plate of the weighing instrument
Handling in this case:
Affix the ID label of the weighing instrument to the delivered tag plate. Affix the ID tag plate to the data cable of the weighing module near the indicator. The verification officer or an authorized Sartorius representative must then seal the ID tag plate to the fastener.

- M** Mark for EC verification (green metrology sticker)
- K** Descriptive plate with CE-conformity

- S** Protective mark
- MD** Metrological data: Max, Min, e, (d)


Example of descriptive plate on a weighing instrument already verified

K



Example of plate with model designation

T



Appendix: General Password

SETUP

**2× soft key ∇ ,
soft key \triangleright**

Activate the Setup program

Select **Device parameters**
(or Application parameters)
and confirm

You are prompted to enter the
password

SETUP	PASSW.CHECK
Enter password: XXXXXXXXXX	
<<	<

Enter numbers

Soft key \uparrow

Enter the General Password
(see below)
Confirm the password

The parameter menu is displayed

DEVICE	WP 1	INTERNAL
Calibration/adjustment		
Adapt filter		
Application filter		
Stability range		
Stability delay		
Taring		
Autozero		
Weight unit 1		
Display accuracy 1		
Zero range		
<<	<	>

Soft key ∇ (repeatedly, if necessary)

Read the old password, or
enter a new password
(max. 8 characters)

Soft key \uparrow

To delete the password:
Press \square or **CF** and then
confirm by pressing the \uparrow soft key

SETUP	DEVICE	PASSWORD
Password:		ABCD
<<	<	>

Soft key $\triangleleft \triangleleft$

Exit the Setup menu

Restart the application

General Password:
40414243

Service Password:
202122

Appendix: "Guide to Verification of Weighing Instruments"

Proof of Compatibility for Modules used with Non-Automatic Weighing Instruments

The Excel file on this CD makes it possible to create the documents required for verification of a scale for legal metrology. This file can be saved and archived (for example, on the PC) under a name of the user's choosing.

The printout of the completed forms is valid as a model for verification of the weighing instrument produced by the scale manufacturer. Once the forms have been properly completed and signed by the scale manufacturer, they are submitted to the weights and measures officer and serve as proof of compatibility for the weighing instrument.

Information important to the weights and measures officer may include the type approval certificate, the test certificate, or a test report. Manufacturer information about the load cell or the indicator may be useful as supplementary information.

System Requirements

Minimum System Requirements:

- PC 486DX / 33 MHz
- Mouse
- 8 MB RAM
- Windows® 95/NT
- MS Internet Explorer®
- Double-speed CD-ROM drive
- Software: MS Excel® version 8 (included with MS Office 97) or later
- VGA graphics adapter, 800x600 pixels, 256 colors

® Windows-95, MS Internet Explorer and MS Excel are registered trademarks of Microsoft Inc. Please observe the legal notices (see end of page).

Installation

- Insert the CD in the CD-ROM drive.
- If the program does not start automatically, double-click on the "Start.pdf" file stored on the CD to run the program. To locate this file, run the Microsoft Explorer (e.g., by double-clicking on the "My Computer" symbol) and select the drive letter of your CD-ROM drive. To exit the program, use the "Alt+F4" keyboard shortcut (i.e., hold down the "Alt" key and press the "F4" key). Click on the corresponding flag to select the desired language. On the next page, click on "ReadMe" to open this file or on "Indicators" to begin using the program.

Using the Program

ReadMe File

Make sure you have read the entire ReadMe file before using the program, as it contains important information about how to use the Excel file and offers useful tips on how to fill out the documents.

After reading this file, click on "Indicators" to begin using the program. On the next page, select the desired indicator model or series. This opens a list of options for use of the program.

Documents

Click on "Documents" to open a list of all documents that are relevant for the declaration of compatibility.

Start

- Click on "Start the Excel Program" to run the dedicated Excel program. The required Excel file is opened automatically. Depending on the settings in your system, a dialog box for selecting the macro may appear. Otherwise, you may need to reset the security level for Excel macros, and/or select the "Activate macros" option before you continue. Fill out all fields on the "Data-input" page (highlighted in yellow).
- > For an example of a completed form, go back to the page with the "Start the Excel Program" option and select "Sample File" instead. Another option, "Explanation of the Excel Program" presents details on the fields that are marked in yellow.

- Each of these information files has "Back" buttons for returning to the program.
- Once the technical specifications have been entered correctly (according to the information provided by the manufacturer), the program calculates all values automatically. Under "Weighing instrument (WI)" there is a list box in the second column; click on the down arrow to select the appropriate type of weighing instrument; e.g., single-range weighing instrument, etc.
- > The fields should be filled out by an expert. On page two, the fields marked in green or red show whether the components (load cell and indicator) are compatible: red = incompatible; green = compatible.
- > Note: The scale manufacturer who configures a weighing instrument from individual components (indicator and load cell(s)) is responsible for the technical information in the document. Once all of the data has been entered correctly (all fields on page 2 are marked green), print out both pages. Check the information and sign the data sheet.

Legal Notice

Copyright

This documentation may not be duplicated or transmitted for any purpose whatsoever, whether in whole or in part, without the express written permission of Sartorius AG. All rights defined under copyright law are reserved by Sartorius AG.

Persons or organizations acquiring this program may use it only for their own purposes and shall not make it available to third parties whether in consideration for remuneration or free of charge. The software may not be changed, reverse engineered, or modified through assimilation.

The Excel program used was developed by the "German Association of Metrology and Verification" (Arbeitsgemeinschaft für Mess und Eichwesen (AGME)). It is also available as freeware on the Internet. The program is copyright and may not be modified. Users are liable for misuse.

Sartorius AG
Weender Landstrasse 94–108
37075 Goettingen, Germany

Phone +49.551.308.0
Fax +49.551.308.3289
www.sartorius.com

Copyright by Sartorius AG,
Goettingen, Germany.
All rights reserved. No part
of this publication may
be reprinted or translated in
any form or by any means
without the prior written
permission of Sartorius AG.
The status of the information,
specifications and illustrations
in this manual is indicated
by the date given below.
Sartorius AG reserves the
right to make changes to
the technology, features,
specifications and design of
the equipment without notice.

Status:
December 2004, Sartorius AG,
Goettingen, Germany