

XK3190-C601
WEIGHING INDICATOR
(BATCHING VERSION)

MANUAL

PLEASE READ THIS MANUAL VERY CAREFULLY
BEFORE OPERATING

Dec 2006

Specifications subject to change without prior notice

CONTENTS

- 1. GETTING STARTED
- 2. TECHNICAL PARAMETERS AND SPECIFICATIONS
- 3. LAYOUT AT FRONT AND DESCRIPTION
- 4. Parameter Setting and Calibration
- 5. INSTRUCTION FOR OPERATION
- 6. OPERATION ERROR CODES
- 7. APPENDIX

1. GETTING STARTED

CAUTION

- *This is not a toy. Keep out of reach of children;*
- *This indicator is not an explosion proof device;*
- *This indicator is not a water proof device;*
- *Do not open this indicator, no user serviceable parts inside. Always contact supplier for service.*

1.1 Introduction

XK3190-C601 weighing indicator (batching version) adopts MCS-51 SCM and high speed $\Sigma - \Delta$ A/D conversion method with max.100 times/s conversion speed. It can make up batching scale with load cell and other mechanical parts, applied in high speed and high precision weighing control occasion.

1.2 Features


- Calibration and operation all by panel keys;
- With parallel printing interface connected to stylus printer;
- Able to print out weighing records, accumulation value and formula;
- Able to save/check/delete weighing records, data protection at sudden power failure;
- With real clock, calendar;
- Able to set zero tracking range and auto/manual zero range;
- Able to set A/D conversion speed and digital

- filter intensity;
- With self-checking for input/output hardware configuration and error code display function;
- With RS232 output (standard) or RS422 output (optional), communicating with PC by continuously send mode or command mode;
- With 20mA current loop output for connection of scoreboard;
- With 4~20mA analog output (optional);
- With 6 inputs and 7 relay outputs to control max. 2 materials;

1.3 Connecting to Other Devices¹

1.3.1 Connection to load cell

Connect this indicator to load cell through the 9-pin load cell connector located at the back. Refer to the below table for load cell pin assignment.



| PIN # | ASSIGNMENT |
|-------|------------|
| 1 | E- |
| 2 | S- |
| 5 | SHIELD |
| 6 | E+ |
| 7 | S+ |
| 8 | IN- |
| 9 | IN+ |

¹ Turn scale off and cut off power before making any connections or disconnections.

Short connect PIN 1 AND PIN 2, PIN 6 and PIN 7 when connected to load cell with a 4-wire cable;

CAUTION


- Connection between load cell and indicator must be reliable; shield-wire must be connected to ground reliably;
- Load cell and indicator are all static-electricity-sensitive devices, measures must be taken to ensure safety.

1.3.2 Connection to PC or SCOREBOARD or current display (optional)

From the 15-pin interface located at the back, you could

- Connect indicator to computer via RS232 output or RS422 output (optional);
- Connect indicator to scoreboard via 20mA current loop output;
- Connect indicator to current display with 4~20mA analog output.

15-pin connector



| PIN # | ASSIGNMENT | PIN # | ASSIGNMENT |
|-------|---------------|-------|-----------------|
| 1 | RS422 OUTPUT+ | 9 | SCOREBOARD OUT+ |
| 2 | RS422 OUTPUT- | 10 | SCOREBOARD OUT- |
| 3 | RS422 IN- | 12 | 4~20mA I- |
| 4 | RS422 IN+ | 13 | 4~20mA I+ |
| 6 | RS232 RXD | 14 | CALIBRATION+ |
| 7 | RS232 TXD | 15 | CALIBRATION- |
| 8 | GND | | |

Note1: RS422 output is optional;
 Note2: Function of short-connect pin 14 and pin 15 is as what the calibration head performs.
 Calibration head is a 15-pin connector with pin 14 and pin 15 short connected which is usually packed together with the manual.

- Connect indicator to computer via RS232 output or RS422 output (optional);

Data format for RS232 or RS422 is the same. Data is transmitted in ASCII code. Data format is as listed below(one group):

| | | | | | | | | | |
|-------|------|---|---|---|---|---|---|---|------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| START | DATA | | | | | | | | STOP |

There are two modes to communicate with PC:

- Continuously send, and
- Command mode.

A. Continuously send

Data transmitted is tare weight or net weight from the display of the indicator. Each time it sends one frame data to pc, one frame consists of 9 groups while the data format of one group is as listed above. Below is the content for one frame:

| GROUP NO. | CONTENT | NOTES |
|-----------|---------------|---|
| 1 | = | START SIGNAL |
| 2 | + OR - | SIGN SINAL |
| 3 | WEIGHING DATA | High digit |
| 4 | | : |
| 5 | | : |
| 6 | | If decimal point is 3, then this group is "." |
| 7 | | If decimal point is 2, then this group is "." |
| 8 | | If decimal point is 1, then this group is "." |
| 9 | | Low digit |

For example,

Now the indicator displays 50.00KG, then the frame indicator sends to PC is : =+0050.00;

If the indicator displays -0.040KG, then the frame indicator sends to PC is : =-000.040;

B. Command mode

Indicator will act according to instruction from computer, please refer to following notes and table:

AD: address of indicator (example A in ASCII code 41);

NN: address of memory pc wants to read/write;

C1: Content pc wants to read/write (000 digit);

C2: Content pc wants to read/write (00 digit);

C3: Content pc wants to read/writ (0 digit);

XH: Verify result for high 4 digits;

XL: Verify result for low 4 digits;

Notes:

- Address indicator could set is from 1~26, while communication address is corresponding from A~Z;
- Instruction from A~Z is transferred in ASCII code; but the example listed in table is in Hex. code. When communicating with PC via the hyper terminal software (This software is with windows operating system), you should choose "transmit in hex format", or else you must convert the example to ASCII code;
- Instruction Q,R,S,T U is read/write operation for data memory. There are many strings in data memory, but one instruction from pc only triggers one operation, hence several instructions should be sent from pc one by one to do these operations

Instruction table is listed in appendix

- Connect indictor to scoreboard via 20mA current loop output;

Data is transmitted serially in binary code with baud rate 600.

Data format is as listed below (one group):

| | | | | | | | | | | |
|-------|-----------------------------|---|---|---|---|---|---|---|------|------|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| START | DATA (Low is prior to high) | | | | | | | | SIGN | STOP |

Indicator sends one frame data to scoreboard per 100ms, one frame consists of 3 groups while the data format of one group is as listed above. Below is the content for one frame:

| | | | | | | | | | | | |
|---------|-------|----|----|-----|-----|-----|-----|-----|-----|------|------|
| Group 1 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| | Start | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | SIGN | STOP |
| | | X | | | Y | | | G16 | G17 | 0 | 1 |
| Group 2 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| | Start | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | SIGN | STOP |
| | | G8 | G9 | G10 | G11 | G12 | G13 | G14 | G15 | 0 | 1 |
| Group 3 | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| | Start | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 | SIGN | STOP |
| | | G0 | G1 | G2 | G3 | G4 | G5 | G6 | G7 | 1 | 1 |

For group one, Sign bit is 0; X(D0,D1,D2) means decimal point (0~3); Y (D3) means sign(1 for negative while 0 for positive); Y (D4) means display weight type(1 for net weight while 0 for tare weight); G17 and G16 is binary code;

For group two, Sign bit is 0; G15~G8 is binary code;

For group three, Sign bit is 1; G7~G0 is binary code;


From G0~G17 consists of 18 bit binary code, low prior to high.
with content of weighing data

- Connect indicator to current display via 4~20mA analog output (optional)

When indicator is at zero, then current display will show 0;
when indicator is at the weight corresponding to 20mA, then current display will show 20mA. (Refer to parameter setting for how to set the weight corresponding to 20mA).

1.3.3 Connection with printer


25-pin interface



| PIN # | ASSIGNMENT | PIN # | ASSIGNMENT |
|-------|------------|-------|------------|
| 1 | ST | 7 | D5 |
| 2 | D0 | 8 | D6 |
| 3 | D1 | 9 | D7 |
| 4 | D2 | 11 | BUSY |
| 5 | D3 | 25 | GND |
| 6 | D4 | | |

Description for each pin is as listed in above table. After connect to stylus printer, indicator could print out weighing records, accumulation value and formula.

1.4 Layout at the back of various interfaces



2. TECHNICAL PARAMETERS AND SPECIFICATIONS

- Accuracy: Class III, N=3000
- A/D Conversion Method: $\Sigma - \Delta$
- Input Signal Range: 0mV ~ 15mV
- Net input signal range: 3mV ~ 15mV
- Nonlinearity: $\leq 0.01\%FS$
- Temperature rate at FS: $\leq 8PPM/^{\circ}C$
- Load Cell Excitation: DC5V, I = 350mA

- Load cell connection mode: 6-wire mode, auto compensation at long distance
- Display Digits: 6 x numeric bits and 1 sign bit with 0.5 inch character height plus 18 status indicators
- Division: 1/2/5/10/20/50
- Clock display: time and date display
- Key: 8 press keys with soft-touching PVC material
- Built-in 20mA current loop output for connection of scoreboard
- Built-in RS232C output(standard) or RS422 output(optional) for connection of pc with selectable baud rate and communication mode
- Built-in parallel printing interface for connection of stylus printer
- Relay output: touching capacity at AC 220V,0.5A
- Input: Switch touching point (close effective)
- Operation Environment: 0°~40°C Non-condensed. R.H. ≦90%
- Power Source: AC220V(-15%~+10%);50HZ (-2%~+2%)

3. LAYOUT AT FRONT AND DESCRIPTION

Key board:



[START] key

Press this key, then indicator start working in automatic control status;

[STOP] key

Press this key, then indicator stop working in automatic control status;

[ESC] key

Press this key to return to weighing status from parameter setting status;



key

Press this key to

- enter into date/time setting mode or
- printing setting mode or
- accumulation value check mode or
- accumulation value clear mode or

shift to left digit when setting parameter value



key

Press this key to

- enter into calibration mode;
- shift to right digit when setting parameter value



key

Press this key to

- tare off the weight of a container when weighing display is positive and stable;
- increase value at a digit when setting parameter value



key


Press this key to

- set weight displayed to zero;
- decrease value at a digit when setting parameter value

[ENTER] key

Press this key to confirm the current input by key;

INDICATORS AND PANEL



I1 INDICATOR

This is an input indicator. It will be on when [START] key is pressed or when there is a short connect between pin 1 and pin 2 of control socket as listed in below table;

I2 INDICATOR

This is an input indicator. It will be on when [STOP] key is pressed or when there is a short connect between pin 1 and pin 3 of control socket as listed in below table;

I3 INDICATOR

This is an input indicator. It will be on when there is a short connect between pin 1 and pin 4 of control socket as listed in below table. This input is usually given when weighing indicator works in manual control mode to start the charge control process.

I4 INDICATOR

This is an input indicator. It will be on when there is a short connect between pin 1 and pin 5 of control socket as listed in below table. This input is usually given when weighing indicator works in manual control mode to start the discharge control process.

I5 INDICATOR

This is an input indicator. It will be on when there is a short connect between pin 1 and pin 6 of control socket as listed in below table. This input is usually given when weighing indicator works in manual control mode and after I3 input has been given. Or it is usually given when weighing indicator works in automatic control mode and after I1 input has been given,

be sure to keep this input always when working in automatic mode and there is no required condition for charge material.

I6 INDICATOR

This is an input indicator. It will be on when there is a short connect between pin 1 and pin 7 of control socket as listed in below table. This input is usually given when weighing indicator works in manual control mode and after I4 input has been given. Or it is usually given when weighing indicator works in automatic control mode and after o6 output has been given, be sure to keep this input always when working in automatic mode and there is no required condition for discharge material.

O1 INDICATOR

This is an output indicator. It will be on when weighing indicator is at the process of fast feeding for the first material.

O2 INDICATOR

This is an output indicator. It will be on when weighing indicator is at the process of slow feeding for the first material.

O3 INDICATOR

This is an output indicator. It will be on when weighing indicator is at the process of fast feeding for the second material.

O4 INDICATOR

This is an output indicator. It will be on when weighing indicator is at the process of slow feeding for the second material.

O5 INDICATOR

This is an output indicator. It will be on when weighing indicator is at the process of discharging material.

O6 INDICATOR

This is an output indicator. It will be on when the weighed material just reaches the OK range.²

O7 INDICATOR

This is an output indicator. It will be on when the weighed material reaches out of the OK range. Usually under this condition, customers should do something until it gives O6 output.

AUTO INDICATOR

² OK range is a weight range that customers could accept. Suppose the set point for one material is A, minus or plus for this material customers could accept is Q, then weight from A-Q to A+Q is OK range.

This is an indicator to indicate which working mode the weighing indicator is at, if it's auto mode, then auto indicator will be on.

STABLE INDICATOR

This is an indicator to indicate a stable weight is being displayed.

TARE INDICATOR

This is an indicator to indicate tare function is in operation and net weight value being displayed;

ZERO INDICATOR

This is an indicator to indicate a net zero weight status.

TIME INDICATOR

This is an indicator to indicate current time is being displayed.

Note: at back of the indicator, there is a 15-pin control socket for input or output control

Pin 1 to Pin 7 is for input description:

| Pin 7 | Pin 6 | Pin 5 | Pin 4 | Pin 3 | Pin 2 | Pin 1 |
|---------------------|------------------|-----------|--------|-------|-------|--------|
| Discharge Permitted | Charge Permitted | Discharge | Charge | Stop | Start | Public |

| I6 | I5 | I4 | I3 | I2 | I1 | |
|----|----|----|----|----|----|--|
|----|----|----|----|----|----|--|

When any of the pin from 2 to 7 is short connected to pin 1, it just gives indicator one kind of input, corresponding input I indicator will be on;

Pin 8 to Pin 15 is for output description:

| Pin 15 | Pin 14 | Pin 13 | Pin 12 | Pin 11 | Pin 10 | Pin 9 | Pin 8 |
|--------|--------|--------|-----------|--------|--------|--------|--------|
| 12V | NOT OK | OK | Discharge | Slow 2 | Fast 2 | Slow 1 | Fast 1 |
| | O7 | O6 | O5 | O4 | O3 | O2 | O1 |

When indicator is at the process of one of the statement, corresponding output O indicator will be on.

There is a connection between this 15-pin control socket and relay box with a cable offered by the supplier, when O indicator is on, corresponding relay will work.

4.Parameter Setting and Calibration

4.1 Parameter setting³

There are three types of parameter to be set, they are:

[SET-0]: Parameter for check

[SET-1]: Parameter for configuration and function

³ Calibration head must be put on to set parameter for [set-1] and [set-2], or else, parameter value can't be saved;

[SET-2]: Parameter for control

Key function description at parameter setting status as followed:

- [↑][↓][←][→]: Shift between digits or increase value at digit
- [STOP]: Return to last parameter setting
- [ESC]: Return to weighing status

[SET-0]:

Press [SET] key, it will display [set-0], then press [ENTER] key, operate step by step refer to following table:

| Item | Display | Parameter description | Remark |
|------|-------------|--|----------------------|
| 1 | [d**.**.]** | Current date set | Could set |
| 2 | [t**.**.]** | Current time set | Could set |
| 3 | [n ****] | Accumulation time | Check only |
| 4 | [A *****] | Accumulation value | Check only |
| 5 | [Del 0] | Clear accumulation value or not ⁴ | Press[ENTER], finish |

[SET-1]:

Press [SET] key, it will display [set-0], press [↑] key until it shows [set-1], then press [ENTER] key, operate step by step refer to following table:

⁴ 0-not clear; 1-clear

| Item | Display | Parameter description | Remark |
|------|----------|--|--------------------------|
| 1 | [H ABCD] | Hardware configuration ⁵ A- PC connection B- Scoreboard connection C- Printer connection D- Analog output | For example: [H 1111] |
| 2 | [n ABCD] | Zero parameter ⁶ A- Outside code or inner code display B- Zero tracking range C- Manual zero range D- Auto zero range | For example: [n 0222] |

⁵ 0-No need for these connection; 1-need for these connection

⁶ Parameter A:0-outside code display; 1-inner code display

Parameter B: 1~8

| | | | | | | | | |
|-----|-----|---|-----|---|-----|---|-----|---|
| B | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
| (e) | 0.5 | 1 | 1.5 | 2 | 2.5 | 3 | 3.5 | 4 |

Parameter C,D:0~5

| | | | | | | |
|------|---|---|---|----|----|-----|
| C,D | 0 | 1 | 2 | 3 | 4 | 5 |
| F.S% | 0 | 2 | 4 | 10 | 20 | 100 |

| | | | |
|---|----------|---|--------------------------|
| 3 | [FLt EF] | E-AD parameter setting ⁷ E- AD sampling speed F- AD filter intensity | For example: [FLt 22] |
| 4 | [Adr **] | Address for indicator ⁸ (1~26) | |
| 5 | [bt *] | Baud rate(0~4) 0-600;1-1200;2-2400;3-4800;4-9600 | |
| 6 | [tod *] | Communication mode 0- Continuously send 1- Command mode | |
| 7 | | [Pt *] | |

| | | | |
|----|----------|---|-----------------|
| 8 | [PL *] | Printing language: 0- English 1- Chinese | |
| 9 | [AtP *] | Auto printing: 0- No auto printing 1- Auto printing | |
| 10 | [A*****] | 20mA analog output weight value set ⁹ | |
| 11 | [Prt *] | To print above parameter set value or not | 0- No 1- Yes |

⁷ E:

| | | | | |
|---------|------|----|----|-----|
| E | 0 | 1 | 2 | 3 |
| Times/s | 12.5 | 25 | 50 | 100 |

The higher E is, the faster speed and less stability it will be

F:

| | | | | | |
|-----------|--------|------|--------|--------|----------|
| F | 0 | 1 | 2 | 3 | 4 |
| Intensity | Weaker | weak | Middle | Strong | Stronger |

The higher F is, the more stability and more delay it will be

⁸ When A of parameter H set as 0, parameter Adr,bt,tod is disabled;

[SET-2]:

Press [SET] key, it will display [set-0], press [↑] key until it shows [set-2], then press [ENTER] key, operate step by step refer to following table:

| Item | Display | Parameter description | Remark |
|------|----------|---|--------------------------|
| 1 | [C ABCD] | Control parameter setting ¹⁰ | For example: [C 0101] |

⁹ When D of parameter H set as 0, parameter A***** is disabled; If D of H is set as 1, then indicator will output 20mA analog signal when it reaches the value A***** set

| | | | |
|----|-----------------------|---|--------------------|
| 2 | [Pt 0] | Cycle times ¹¹ | |
| 3 | [t0 **] ¹² | Delay time before charge | |
| 4 | [t1 **] | Delay time at fast feed finish | |
| 5 | [t2 **] | Delay time at slow feed finish | |
| 6 | [t3 **] ¹³ | Output time for dot-makeup | |
| 7 | [t4 **] | Output time for interval of dot-makeup | |
| 8 | [t5 **] | Output time for OK range | |
| 9 | [t6 **] | Delay time at discharge finish | |
| 10 | [t7 **] | Delay time when next cycle begins | |
| 11 | [L*****] | Zero range ¹⁴ | |
| 12 | [A*****] | Set point for material 1 | |
| 13 | [b*****] | Ahead value for fast feed of material 1 | |
| 14 | [C*****] | Ahead value for slow feed of material 1 | |
| 15 | [d*****] | Q of ok range for material 1 | Refer to Footnote2 |
| 16 | [P*****] | Set point for material 2 | |
| 17 | [q*****] | Ahead value for fast feed of material 2 | |

- ¹⁰ A: Plus or minus scale selection, 0-plus scale;1-minus scale
B: Ahead value auto correction selection,0-no correction;1-correction
C: Not OK range deal selection:0-not deal, continue cycle;1-wait until it reaches ok range
D:Dot-makeup or not when it's lack of weight,0-no;1-yes

| | | | |
|----|----------|---|--------------------|
| 18 | [r*****] | Ahead value for slow feed of material 2 | |
| 19 | [t*****] | Q of ok range for material 2 | Refer to Footnote2 |
| 20 | [Prt *] | To print above parameter set value or not | 0- NO 1- Yes |

Note: After calibration and these three-group parameters are set, indicator could work properly.

4.2 Calibration¹⁵

Press [Calib] key, indicator will display [CALIB],it indicates that it's at calibration status. Press [ENTER] key, then calibrate step by step as followed table:

- ¹¹ One cycle is from charge to discharge, times is from 0~99 while 0 means times is limitless

- ¹² From t0 to t7, value set is from 0.0~9.9 seconds; always leave these parameter as default setting, they are time to control the total process more precisely

- ¹³ When D of C parameter set as 0, parameter t3 and t4 are disabled

- ¹⁴ Indicator will treat as discharge finish when tare weight is less than zero range
Print and accumulation will only function when tare weight is more than zero range

- ¹⁵ Calibration head must be put on to save calibration data

| Item | Display | Parameter description | Remark |
|------|----------|--|--|
| 1 | [dC *] | Decimal point (0~3) | Press [ENTER] after input |
| 2 | [E *] | Division: 1/2/5/10/20/50 | Press [ENTER] after input |
| 3 | [F*****] | Full range | Press [ENTER] after input |
| 4 | [r 0] | Keep former zero 0- Reconfirm current zero 1- Skip zero confirmation | Input 0, then go to step 5 (recommended) Input 1, then go to step 6 |
| 5 | [noLoAd] | Zero confirmation ¹⁶ | |
| 6 | [AdLoAd] | Load weight | Press [ENTER] when stable indicator is on |
| 7 | [000000] | Input loaded weight value | Press [ENTER] after input |
| 8 | [*****] | Display current weight value | Exit calibration status |

5. INSTRUCTION FOR OPERATION

¹⁶ Ensure there is no load and stable indicator is on

5.1 Turning on

When indicator is powered on, it will display 0~9, then it comes to weighing status. If the unloaded scale divates from zero point but still within auto zero range, then indicator will come to zero automatically;

Before Weighing

Make sure that:

- The load cell signal cable is connected and properly secured.
- The scale is turned on.

5.2 Zero manually

If the unloaded scale divates from zero after auto zero when turned on, but it's still within manual zero range and the stable indicator is on, press [ZERO] key, then indicator will come to zero and zero indicator will be on;

5.3 Tare

At weighing status, when the current display is positive and stable, press [TARE] key will tare off the current weight and indicator will display 0, zero indicator is on

5.4 Date/time set

Press [SET] key, and then press [ENTER] key and set date, then press [ENTER] key and set time.

5.5 Start/Stop

Press [START] key or short connect Pin 1 and Pin 2 as listed above, indicator will enter into automatic control status; press [STOP] key or short connect Pin 1 and Pin 3 as listed above, indicator will exit automatic control status;

5.6 Manual work mode

When scale is ready for weighing, short connect Pin 1 and Pin 4 of control socket (Indicator I3 will be on), then short connect Pin 1 and Pin 6 of control socket, (Indicator I5 will be on), then it will start charge material. When the loaded material reaches OK range, then short connect Pin 1 and Pin 5 of control socket (Indicator I4 will be on), then short connect Pin 1 and Pin 7 of control socket, (Indicator I6 will be on), then it will start discharge material. This is one cycle in manual work mode.

5.7 Automatic work mode

When scale is ready for weighing, press [START] key or short connect pin 1 and pin 2 of control socket to enter into automatic control mode. Always short connect Pin 1 and Pin 6 of control socket (Indicator I5 will be always on) if there is no required for charge material, and indicator will begin charge automatically. Always

short connect pin 1 and pin 7 of control socket (Indicator I6 will be always on) if there is no required for discharge material only when O6 is on. Then after o6 is on, indicator will begin discharge automatically. When indicator check that rest material in the hooper is within zero range, it will begin the next cycle automatically.

5.7 Input/Output hardware check

At inner code display status, user can check whether the hardware of input/output connectors are good or not. When there is input for I1, then O1 will be on; when there is input for I2, then O2 will be on...when there is input for I6, then O1~O7 will be on. If O indicator is not on, then it's not good.

6. OPERATION ERROR CODES

| | |
|-------|---|
| Err 1 | Can't meet requirement of tare |
| Err 2 | Can't meet requirement of zero |
| Err 3 | Incorrect input for date/time |
| Err 4 | EEPROM chip is damaged |
| Err P | Printing cable is not connected or printer error, print any key to exit |

7. Appendix

| Command | | Note | Format | Example |
|---------|----------------|-----------|-------------------|-------------------|
| A | PC send | handshake | 02 AD 41 XH XL 03 | 02 41 41 30 30 03 |
| | Indicator send | handshake | 02 AD 41 XH XL 03 | 02 41 41 30 30 03 |
| B | PC send | To read | 02 AD 42 XH XL 03 | 02 41 42 30 33 03 |

| | | | | |
|---|----------------|--------------------|--|---|
| | | gross weight | | |
| | Indicator send | Send gross weight | 02 AD 42 ** ** ** ** ** ** ** ** ** XH XL 03 | 02 41 42 2B 30 30 30 2E 30 30 30 30 36 03 |
| C | PC send | To read net weight | 02 AD 43 XH XL 03 | 02 41 43 30 32 03 |
| | Indicator send | Send net weight | 02 AD 43 ** ** ** ** ** ** **~ XH XL 03 | 02 41 43 2B 30 30 30 2E 30 30 30 30 37 03 |
| D | PC send | To read tare eight | 02 AD 44 XH XL 03 | 02 41 44 30 35 03 |
| | Indicator send | Send tare weight | 02 AD 44 ** ** ** ** ** ** **~ XH XL 03 | 02 41 44 2B 30 30 30 2E 30 30 30 30 30 03 |
| E | PC send | To tare | 02 AD 45 XH XL 03 | 02 41 45 30 34 03 |
| | Indicator send | Tare | 02 AD 45 XH XL 03 | 02 41 45 30 34 03 |
| F | PC send | To zero | 02 AD 46 XH XL 03 | 02 41 46 30 37 03 |
| | Indicator send | Zero | 02 AD 46 XH XL 03 | 02 41 46 30 37 03 |

| | | | | |
|---|-----------------|-------------------|-------------------|-------------------|
| | | | | |
| G | PC send | To start | 02 AD 47 XH XL 03 | 02 41 47 30 36 03 |
| | Indicator send | start | 02 AD 47 XH XL 03 | 02 41 47 30 36 03 |
| H | PC send | To stop | 02 AD 48 XH XL 03 | 02 41 48 30 39 03 |
| | Indicator send` | Stop | 02 AD 48 XH XL 03 | 02 41 48 30 39 03 |
| I | PC send | To charge | 02 AD 49 XH XL 03 | 02 41 49 30 38 03 |
| | Indicator send | Begin charge | 02 AD 49 XH XL 03 | 02 41 49 30 38 03 |
| J | PC send | To discharge | 02 AD 4A XH XL 03 | 02 41 4A 30 42 03 |
| | Indicator send | Begin discharge | 02 AD 4A XH XL 03 | 02 41 4A 30 42 03 |
| K | PC send | To Pause/Continue | 02 AD 4B XH XL 03 | 02 41 4B 30 41 03 |
| | Indicator send | Pause/Continue | 02 AD 4B XH XL 03 | 02 41 4B 30 41 03 |

| | | | | |
|---|----------------|-----------------------------|-------------------|-------------------|
| L | PC send | To accumulate | 02 AD 4C XH XL 03 | 02 41 4C 30 44 03 |
| | Indicator send | Accumulate | 02 AD 4C XH XL 03 | 02 41 4C 30 44 03 |
| M | PC send | To print | 02 AD 4D XH XL 03 | 02 41 4D 30 43 03 |
| | Indicator send | Print | 02 AD 4D XH XL 03 | 02 41 4D 30 43 03 |
| N | PC send | To print accumulation value | 02 AD 4E XH XL 03 | 02 41 4E 30 46 03 |
| | Indicator send | Print accumulation value | 02 AD 4E XH XL 03 | 02 41 4E 30 46 03 |
| O | PC send | To print formula | 02 AD 4F XH XL 03 | 02 41 4F 30 45 03 |
| | Indicator send | Print formula | 02 AD 4F XH XL 03 | 02 41 4F 30 45 03 |
| P | PC send | To print calibration rate | 02 AD 50 XH XL 03 | 02 41 50 31 31 03 |

| | | | | |
|---|----------------|-------------------------------------|-------------------------------|-------------------------------|
| | Indicator send | Print calibration rate | 02 AD 50 XH XL 03 | 02 41 50 31 31 03 |
| Q | PC send | To read content of calibration rate | | |
| | Indicator send | Send content of calibration rate | 02 AD 51 NN XH XL 03 | 02 41 51 30 32 30 03 |
| R | PC send | To read parameter for batching | 02 AD 52 NN XH XL 03 | 02 41 52 30 32 33 03 |
| | Indicator send | Send parameter for batching | 02 AD 52 NN C1 C2 C3 XH XL 03 | 02 41 52 30 30 30 30 31 33 03 |
| S | PC send | To read | 02 AD 53 NN XH XL 03 | 02 41 53 30 32 32 |

| | | | | |
|---|----------------|--------------------------------------|----------------------------------|----------------------------------|
| | | accumulation value | | 03 |
| | Indicator send | Send accumulation value | 02 AD 53 NN C1 C2 C3 XH XL 03 | 02 41 53 30 30 30 30 31 32 03 |
| T | PC send | To write content of calibration rate | 02 AD 54 NN C1 C2 C3 XH XL 03 | 02 41 54 30 30 30 32 31 37 03 |
| | Indicator send | Write content of calibration rate | 02 AD 54 NN C1 C2 C3 XH XL 03 | 02 41 54 30 30 30 32 31 37 03 |
| U | PC send | To write content of calibration rate | 02 AD 55 NN C1 C2 C3 XH XL 03 | 02 41 55 30 32 35 35 31 36 03 |
| | Indicator send | Write content of calibration rate | 02 AD 55 NN C1 C2 C3 XH XL 03 | 02 41 55 30 32 35 35 31 36 03 |

| | | | | |
|---|----------------|-----------------------------|--|---|
| | | | | |
| V | PC send | To clear accumulation value | 02 AD 56 XH XL 03 | 02 41 56 31 37 03 |
| | Indicator send | Clear accumulation value | 02 AD 56 XH XL 03 | 02 41 56 31 37 03 |
| W | PC send | To read date | 02 AD 54 NN C1 C2 C3 XH XL 03 | 02 41 54 30 30 30 32 31 37 03 |
| | Indicator send | Send date | 02 AD 54 NN C1 C2 C3 XH XL 03 | 02 41 54 30 30 30 32 31 37 03 |
| X | PC send | To read time | 02 AD 58 XH XL 03 | 02 41 58 31 39 03 |
| | Indicator send | Send time | 02 AD 58 C1 C2 C3 C4 C5 C6 C7 C8 XH XL 03 | 02 41 58 30 34 3A 31 35 3A 32 36 31 44 03 |
| Y | PC send | To write date | 02 AD 59 C1 C2 C3 C4 C5 C6 C7 C8 XH XL 03 | 02 41 59 30 35 2D 30 37 2D 32 36 31 45 03 |
| | Indicator | Write date | 02 AD 59 C1 C2 C3 C4 | 02 41 59 30 35 2D |

| | | | | |
|---|-------------------|------------------|---|---|
| | send | | C5 C6 C7 C8 XH XL 03 | 30 37 2D 32 36 31 45 03 |
| Z | PC send | To write time | 02 AD 5A C1 C2 C3 C4 C5 C6 C7 C8 XH XL 03 | 02 41 5A 30 39 3A 34 30 3A 32 36 31 32 03 |
| | Indicator send | Write time | 02 AD 5A C1 C2 C3 C4 C5 C6 C7 C8 XH XL 03 | |